

GUARANTEE
PLEASE KEEP YOUR RECEIPT AS THIS WILL
BE REQUIRED FOR ANY CLAIMS UNDER THIS
GUARANTEE

- This product is guaranteed for 3 years.
- In the unlikely event of breakdown, please take it back to the place of purchase, with your till receipt and a copy of this guarantee.
- The rights and benefits under this guarantee are additional to your statutory rights which are not affected by this guarantee.
- Holmes Products Europe undertakes within the specific period, to repair or replace free of charge, any part of the appliance found to be defective provided that:-
 - We are promptly informed of the defect
 - The appliance has not been altered in any way or subjected to misuse or repair by a person other than a person authorised by Holmes Products Europe.
- No rights are given under this guarantee to a person acquiring the appliance second hand or for commercial or communal uses.
- Any repaired or replaced appliance will be guaranteed on these terms for the remaining portion of the guarantee.

THIS PRODUCT IS MANUFACTURED TO
COMPLY WITH THE E.E.C. DIRECTIVES
73/23/EEC, 89/336/EEC and 98/37/EEC.

 **BIONAIRE®**

Holmes Products (Europe) Ltd
1 Francis Grove
London SW19 4DT
England

Fax: +44 (0)20 8947 8272
Email: info-europe@theholmesgroup.com
Website address: www.theholmesgroup.com/europe
UK - Free phone Customer Service Helpline - 0800 052 3615



9100010004537
BASF1314/1714IUK04EM1

 **BIONAIRE®**

PEDESTAL
stand fan

BASF1314/1714



INSTRUCTION MANUAL

U.K. and IRELAND

PLEASE READ AND SAVE THESE INSTRUCTIONS

IMPORTANT INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be taken including the following:-

- Use the fan only for purposes described in the instruction manual.
- To protect against electrical shock, do not immerse the fan, plug or cord in water or spray with liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the electrical outlet when not in use, when moving the fan from one location to another, before putting on or taking off parts and before cleaning.
- Avoid contact with any moving parts
- Do not operate in the presence of explosive and/or flammable fumes.
- Do not place the fan or any parts near an open flame, cooking or other heating appliance.
- Do not operate any appliance with a damaged cord, plug, after the appliance malfunctions, or has been dropped/damaged in any manner.
- The use of attachments not recommended or sold by the appliance manufacturer may cause hazards.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or come into contact with hot surfaces.
- To disconnect from the electrical supply, grip the plug and pull from the wall outlet. DO NOT pull on the cord.
- Always use on a dry, level surface.
- Do not operate without the fan grills properly in place.
- This product is intended for household use ONLY and not for commercial or industrial applications.

ASSEMBLY INSTRUCTIONS (See Fig 1.)

Base/Pole assembly

You will need the base cover (O), round weighted insert (P), pole (K,M), pole ring (N) washer (S) and L-shaped locking lever (Q).

1. Slide the bottom end of the pole through the pole ring.
2. Turn the base cover upside down and place the round weighted insert into the base cover.
3. Insert the threaded end of the L-shaped locking lever into the hole of the washer, round weighted insert and through the base cover.
4. Whilst holding the base cover and round weighted insert with one hand, connect the

pole to the base, sliding the L-shaped locking lever into the bottom of the pole with you other.

5. Turn the L-shaped locking lever clockwise to securely attach the pole to the base.
6. Set the base on the floor, weight side down. Push the pole ring down until it sits directly on the base.

Fan head assembly

You are now ready to assemble the fan head

1. Unscrew rear grill mounting nut (D) before positioning the rear grill (F) over the motor shaft (G) making certain that the notches at the top and bottom of the rear grill, fit over the prongs on the motor housing (H).
2. Secure the rear grill in its place using the rear grill mounting nut (D). Turn this nut clockwise and tighten firmly.
3. Slide the fan blade (B) with the hollowed interior of the blade facing toward the rear grill, firmly onto the motor shaft. The top of the motor shaft should lie even with the centre of the fan blade.
4. Now use the securing screw (C) (already attached to the Fan Blade) to lock the blade into place. Tighten the screw into the side hole of the fan blade, against the motor shaft, until both the blade and screw are secure.
5. Centre the front grill (A) by aligning the Bionaire® logo on the logo plate so that it is horizontal and parallel with the floor. Then, holding the front grill against the rear grill, push the black grill ring (E) into place at the top and bottom of the fan. (Push directly on the black grill ring, not on the grills themselves). Finish securing the grill ring in the same manner until both grills are joined underneath the black ring.

Final assembly

1. Slide the inner pole extension (K) up from the outer pole (M). Insert the pole locking knob (L) into the hole on the outer pole, to securely hold this position.
2. Place the fan head assembly into this extension pole, inserting the neck of the fan into the pole opening. Turn the fan head's neck until the head is securely locked into place.
3. Add the tilt adjustment knob (J) to the hole in the fan head's neck. Tighten when the fan head is in your desired position.

Converting to a table fan -

Model 1314 only: On model 1314 an additional short pole (R) is supplied which allows the fan to be converted into a table fan. To change to this short pole, remove the fan head assembly from its position on top of the inner pole and unscrew the L-shaped locking lever at the base. Remove the long pole, replace with the short pole and reassemble as detailed above.

OPERATING INSTRUCTIONS

1. Set the fan base on a dry level surface
2. Make sure the Selector (Speed) Control is in the OFF position. Selector (Speed) Control is located on the top of the fan motor housing.
3. Plug the cord into a suitable 220-240V. AC outlet.
4. The SPEED is adjusted by turning the Selector (Speed) Control to the desired setting:- O-III-II-I.
5. The OSCILLATION control is located on the top of the fan motor housing. To start oscillation, push the control knob down. To stop oscillation, pull the control knob up.

ADJUSTMENT

Tilt adjustment

Follow these instructions to tilt the fan head for upward angle air movement.

1. To change the tilting angle of the fan head, simply loosen the tilt adjustment knob (J)
2. Move the fan head to the desired angle, then firmly tighten the knob to lock in place.

Height adjustment

Follow these instructions to adjust the height of the fan.

1. Turn the pole locking knob (L) anticlockwise to loosen the pole.
2. Adjust the pole to the desired height and firmly tighten the locking knob in a clockwise direction.

CLEANING AND MAINTENANCE

Follow these instructions to correctly and safely care for your Bionaire® fan. Please remember:-

- Always unplug the fan before cleaning or assembly.
- Do not allow water to drip on or into the fan motor housing.
- Be sure to use a soft cloth, moistened with a mild soap solution.
- Do not use any of the following as a cleaner: petrol, thinners or benzene.

Fan Blade cleaning

(See instructions for fan head assembly)

1. To access the fan blade, remove the front grill and securing screw.
2. Clean the fan blade, front and rear grills with a soft moist cloth.
3. Replace the fan blade, tighten screw and securely fasten the front grill.

Fan head, base and pole cleaning

Using a soft, moist cloth, with or without a mild soap solution, carefully clean the fan base, pole and head. Please use caution around the motor housing area. Do not allow the motor or other electrical components to be exposed to water.

FAN STORAGE

Your fan can be stored either partially disassembled or assembled.

It is important to keep it in a safe, dry location.

- If stored disassembled, we recommend using the original (or appropriately sized) box.
- If stored assembled or partially assembled, remember to protect the fan head from dust.

FITTING A REPLACEMENT PLUG (UK ONLY)

The wires in this mains lead are coloured in accordance with the following code:

Blue - Neutral
Brown - Live

This appliance is fitted with a 13 amp plug.

The fuse should be rated at 3 amps and ASTA approved to BS1362.

However if the plug is unsuitable, it should be removed from the supply cord and an appropriate plug fitted as detailed below:


As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:-

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Black.

The wire which is coloured Brown must be connected to the terminal which is marked with the letter L or coloured Red.

NB. Neither wire should be connected to the terminal in your plug which is marked with the letter E or by the Earth symbol (⊕) or coloured Green or Green and Yellow. If in doubt consult a qualified electrician.

If any other plug is used, a 3 amp fuse must be fitted either in the plug or adaptor or at the distribution board.



BASF1314/1714

Fig. 1

