

User Manual

USB Flash Drive P89035 (MD 86167)

Scope of Delivery

Please check the items received in the box and inform us **within 7 days** from purchase if anything is missing. You should receive the following items:

- 8 GB USB Flash Drive
- Documentation

System Requirements

- Slot: USB port (USB 1.1/2.0)
- Operating system: Microsoft Windows® XP/Vista®/ Windows®7

Safety Instructions

Please read this chapter carefully and observe all listed notes. This ensures a reliable operation and long life expectancy of your **USB Flash Drive**. Keep these instructions with your device at all times. In the event that you transfer ownership of this device, please provide these instructions to the new owner. If you are experiencing technical problems with your device, please contact the **MEDION help desk on 1 300 884 987**.

Data Security

Note: Every time you update your data make back-up copies on an external storage medium. The supplier does not assume liability for data loss or damage to data storage units, and **no claims can be accepted** for damages resulting from the loss of data or consequential losses.

Operational Safety

- Follow the operating instructions of your computer.
- Keep the device away from **humidity** and **avoid vibration, dust, heat**, and direct sunlight, in order to prevent operational interference.
- Never open the case. This would void all warranty claims and it could possibly cause the destruction of the unit.
- Do not allow **children** to play with electrical devices **without supervision**. Children do not always recognize possible dangers.
- Before operating the device after a **transport**, allow it to become acclimatized. High temperature and humidity deviations can lead through condensation to moisture build up, which can cause an **electrical short**. Fasten down the plug cover before transportation.

Electromagnetic Compatibility

- While connecting the device, the **guidelines** for electromagnetic compatibility must be followed. Keep at least 1 meter distance from high frequency and magnetic sources of interference (TV, loudspeakers, mobile phones, etc.), to avoid operation disruption and data loss.

Cleaning Instructions

Normally cleaning of this device is unnecessary.

- **Attention!** This device does not contain parts that must be serviced or cleaned.
- Make sure the USB Flash Drive does not become contaminated. Do not use solvents, corrosives, or spray cleansers. If necessary, clean the casing with a moist cloth.

Recycling



Device

At the end of its life, the appliance must not be disposed of in household rubbish. Enquire about the options for environmentally-friendly disposal



Packaging

Your device is packaged to protect it against damage during transportation. The packaging is manufactured from materials that can be sent to a specialist recycling facility and disposed of in an environmentally-friendly way.

Getting Started


Connecting

Remove the protective cover of the USB Flash Drive and connect the device with an available USB port.


The USB Flash Drive will be recognized and the operating system assigns the letter of an empty drive. Now you can use the device like a diskette drive (copy data, delete, etc.).

Removing USB Flash Drive

With some operating systems it may be necessary to **sign off the device**. The installed USB Flash Drive is displayed in the taskbar:



Right click with the mouse “Unplug or Eject Hardware” and choose the appropriate entry. The instruction for device removal will follow:



Customer Service

Errors and Possible Causes

USB Flash Drive is not recognized:

- Is the device connected correctly?
- Check in the Windows® device manager, whether the USB units are correctly linked. If necessary re-install the USB controller.

Data can not be read / written:

- Did you format the USB Flash Drive with another computer? Different formats (FAT/FAT32/HFS) may be incompatible. Save the data and reformat the USB Flash Drive with a compatible format.

Do You Require Additional Support?

If the suggestions in the above section have not solved your problem, please contact the service hotline and we will attempt to help you solve the problem. However, before you contact the MEDION help desk on 1 300 884 987, please keep the following information available:

- How is your computer configured?
- What additional peripherals do you use?
- What messages, if any, appear on your screen?
- What software were you using when the error occurred?
- What steps have you already undertaken to solve the problem?
- If you have been given a customer number previously, please quote this.

What Your 1 Year Warranty Means

Great care has gone into the manufacture of this product and it should therefore provide you with years of good service when used properly. In the event of product failure within its intended use over the course of the first year after the date of purchase, we will remedy the problem as quickly as possible once it has been brought to our attention. In the unlikely event of such an occurrence, or if you require any information about the product please contact us via our after sales support services, details of which can be found in this manual and on the product itself

Warranty

The receipt serves as proof of first purchase and should be kept in a safe place. It is required should you need to make use of the warranty. If the product is passed onto another user, then they shall be entitled to warranty services for the remaining period of the warranty. The receipt of purchase as well as this declaration should be passed onto the new user.

We guarantee that this equipment is in perfect working order and from a technical point of view it complies with the descriptions in the enclosed documentation. Upon production of the receipt, the remaining period of warranty shall pass on from the original parts to the respective replacement parts. If you hand in this equipment to make use of the warranty, you must remove all programs, data and removable storage media. Products which are sent without accessories will be replaced without accessories.

The warranty obligation does not apply in the case of the problem being caused by an accident, a catastrophe, vandalism, misuse, incorrect use, ignoring the safety and maintenance regulations, changes by software, viruses or another piece of equipment or accessories or by other modifications not approved by ourselves. This limited warranty declaration replaces all other warranties of express or implied nature. This includes the warranty of saleability or the suitability for a certain purpose but is not limited to this. In some countries the exclusion of implied warranties is not permissible upon principle. In this case the validity of all express and implied warranties is limited to the warranty period. Once this period has expired, all warranties become invalid. In some countries limiting the period of validity for implied warranties is not permitted, so that the above limitation does not come into force. If you have any questions with regard to these warranty conditions, please contact us.

Liability Limitations

The contents of this manual are subject to unannounced changes caused by technical progress. Manufacturer and sales shall not be responsible for any damages which have been caused as a result of omissions or errors in the information provided in this manual.

Under no circumstances shall we be liable for any of the following:

1. Claims made against you by third parties based on loss or damage.
2. Loss or damage to your blanks, recordings or data.
3. Economic follow-on damage (including lost profit or savings) or associated damage even in the case that we have been informed of the possibilities of this type of damage.

In some countries the exclusion or limitation of accompanying or follow-on damage is not legally accepted so that the above limitations do not come into force.

© 2009 All rights reserved. This manual is protected by Copyright. The Copyright is owned by **Medion**®.

Trademarks:

MS-DOS® and **Windows**® are registered trademarks of **Microsoft**®. **Pentium**® is a registered trademark of **Intel**®.

Other trademarks are the property of their respective owners.

Medion® makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Medion® shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Medion® assumes no responsibility for the use or reliability of its software on equipment that is not furnished by **Medion**®. This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of **Medion**®.

Information in this document is subject to change without notice.

MEDION®
MEDION Australia Pty Ltd
St. Leonards, NSW 2065
Australia

MEDION Help Desk: 1300 884 987
Operating Hours: Monday to Friday
8:30 AM to 6:30 PM EST

E-Mail: australia@medion.com
www.medion.com.au

