

User Manual

Guide

Attention-----1-2

To make sure you can use it safely, please read it before using.

Storage device

Support storage device -----3

Packing list-----3

List of accessories and gift box

Technical Parameter-----4

Products diagram-----5-6

Learn about the key functions of product

Using preparation-----7

Charging

Power on/ off

Operation method-----8-10

Connect with your Bluetooth device

Player music

Hand-free answer

Revert original state

Trouble shooting-----11

Know how of trouble shooting

Physical Photos of T5 bluetooth wireless speaker-----11-12

Using note

Main function Parameter

Product Function

1. Support Bluetooth function
2. Support Bluetooth hand-free answer function
3. Support AUX line in
4. Wireless transfer can reach 10 M
5. Support MINI USB changing, also can connect with PC to operate file in the TF card .
6. Support TF card to player MP3 format
7. Support track memory function (Only for TF card)
8. Built in bass diaphragm
9. Double LED light displayer
10. Outlay BL-5C battery (3.7V/1000MAH)

Technical Parameter

Speaker Type	wireless	
speaker system	Dual channel additional base boost	
Feature	Bluetooth Function ,Broadcom Chip .Compare with Iphone,IPAD same as Chip and solution. Support wireless Bluetooth, can compatible with various audios(Laptop,mobile,IPAD,IPOD),receiver can reach 10 Meter	
Power	Outlay NOKIA BL-5C battery 1000ma/H	
Charging	MINI USB port 5V/500MA	
Aux In	support	
RMS	3Wx2	
Technology Parameter	frequency response	160HZ-18KHZ
	degree of distortion	< 0.1% (1K/1W/3.7V)
	S/N	> 75dB
	AUX sensitivity	500MV
	Bluetooth versions	V2.1+EDR
	Bluetooth Agreement	A2DP1.2
	Bluetooth	2.4GHz -- 2.48G HZ

	Frequency	
	Bluetooth distance	10m
	Battery Volume	BL-5C 3.7V/1000MAH
other feature	Built in Bass Beat Vents , fit with Bluetooth V2.1+EDR standard	
Speaker Size	128x72x65mm	

Button map

Front view

1. Speaker

Top view

1、MIC Microphone

2、  PRE

3、  Play/Pause

4、  Next

5、  Hand-free answer/ matches

6、  -

7、  +

Back view

1、 OFF/ON

2、  DC 5V mini USB port

3、 AUX IN port

4、 TF card slot

5、 Battery cover





bottom View



1. Close anti-skid soft silica gel



2.bass beat vents


Side View



Button Operation Instruction


1.  Next
2.  Pause/Mute
3.  Pre
4.  hand-free answer


① When calling come in ,short press  ; can get the calling , ,Long press  ; also can reject calling .

② In-call , long press  : can turn to Phone answer, then long press  : can turn to Bluetooth hand-free answer .

③ When hand-free answer , short  : can drop in-call

④ when playing , short press  : invalid ; Long press  : go Into the matching state ,also cancel other

5.  : VOL+ ,long press , fast VOL+

6.  : VOL- ,long press , fast VOL-

7. POWER: ON: open; OFF : Closed. After closed power , can't play , but can be charging .



Using preparation

Charging


Please follow order to charge the device .

Use Mini USB line connect with device , other side connect to PC or adaptor USB port .

When charging , red indictor can bright .

When full charging , red indictor can die , change to blue light .

When full , first take adaptor out of socket , then take out USB line .



- The load battery to the attention of alignment battery shrapnel
- This product use BL-5C

Load Battery

Open battery cover with device , put BL-5C Li-battery put into it follow sketch map , then close battery cover .

Note :

- When battery low level , indicator light turn to Red , then fast flicker , remind you fast charging the device .
- When battery no power , device will be stopper , rehabilitate work again after charging .

- It spent 3-4 hours to charge every time , according less power level , charging time will be different .
- It need full 12 hours to charge it at first time , to promise full activate battery .

●Open Power

Put switch to : ON , open power , blue indicator will bright .

●Closed Power

Put switch to : OFF , closed power , indicator light will die .

Operator Method

Connection Device

● First use , matching with your Bluetooth device

First use or matched device had cancel , device don't have memory match device ;After opening the product, the blue indicator is blinking rapidly, it means it is searching matching Bluetooth devices; Please open Bluetooth device on your phone or IPAD and reach equipment. When reaching "T5"device, click to link , the prompt to enter a password, enter "0000", and confirm. When the blue light indicator turns slowly twinkle, whereby means connection now. After connection, you can play music on your phone or IPAD ,enjoy the fun .

Note : Maybe the method of operation with some Bluetooth device are different from it .

●Auto connect your bluetooth device

If use normally first time , bluetooth device had saved device which matched before , open and auto connect with matched device , no need input password again . If after search 20 seconds , there don't search device which matched before , then auto turn to match state .It shall be carried out again paired connection . When matching , purple light flashes a few .

Note : 1. A portion of the device does not support automatic connection, maybe need to match and connect.

2. There may be some equipment in the connection when prompted to choose or confirm, only simply press the tip of operation .

●Relieve existing connection

If you want to relieve an existing connection, reconnect to another device. Please close the original Bluetooth device, and then long press hands-free key

for 3 seconds, until the indicator light turns blue flash, according to the matching and connecting method can connect the new equipment.


●Via Bluetooth playing

After the device successful connection, which can operate your Bluetooth devices, playing beautiful music. During playing , the indicating lamp is bright purple. You can use this product keys to control your Bluetooth devices.

Note: there may be some Bluetooth devices (such as mobile phone version) does not support via Bluetooth to play music, may also have some devices do not support through Bluetooth control equipment. These are part of the equipment problems of its own, does not belong to the product quality problem.


●Via AUX external audio playback

After turn on the power, via using the included AUX audio cable plug into the AUX socket, another end into your source to the output port of the device, can realize the connection. To start playing your device, you can enjoy the beautiful music. You can use this machine volume and keys to adjust the volume size.



●Via TF playing

Turn on the power, insert your TF card, can be played automatically. You can use this machine on the key to achieve the corresponding operation..



This machine is automatic conversion mode design. When you did not inserted with TF card and AUX line, the system defaults to the Bluetooth mode; when you insert the TF card, the system automatically into the card reading mode. When you pull the TF card, the system will automatically turn for Bluetooth mode; when you insert the AUX line, the system automatically enter AUX mode. When you unplug the AUX line, the system will automatically enter the TF card mode or a Bluetooth mode.





Hands-free answer

●In-Call hands-free

When you connect the device is a mobile phone, you can use this product to achieve hands-free calls.

When an incoming call, the product will automatically pause playback, horn " bell, bell " bell, or mobile phone customized ringing tone. (bell content with the mobile phone related)

When an incoming call, short press the hands-free key can be switched on to call. According to the hands-free key can reject a call.

In-call, long press / / /  can increase or decrease the volume.

In-call, press the hands-free key can be transferred to the mobile phone call, then according to the hands-free key return hands-free calls.

In-call, press the hands-free key can hang up the phone.


Hang up after, this product will automatically resume the playback.

●Calling hand-free answer

When you connect the device is a mobile phone, you can also through the product hands-free and talk to each other.

Power down, this product will automatically pause playback, horn to make mobile phone ring tones, or customized ringing tone. (bell content with the mobile phone related) call operation method with the call of the same operation.

图①



图②



Trouble shooting

Fast solution method of Machine shooting

Problem	Reason	Resolution
Can't power on	Battery is died	please charge battery
	Battery damaged	Change new battery
can't connect with Bluetooth device	password error	Please enter correct password (password is 0000)
	the name of Bluetooth device incorrect	Make sure its correct.
	Equipment is not the last paired devices	Long press hand-free button, before cancel connected device, blue light flash several, into pairing mode, and then search for the connection.
	4. Can't find device	<p>This product has been connected with other equipment, please close the other device with Bluetooth function,</p> <p>Then according to the hands-free key remove old paired devices, re search connector.</p> <p>Your Bluetooth device does not support audio playback, please</p>

		according to the requirements of the installation and use of.
	5. starting up Can't auto connect	<p>1 some Bluetooth device does not support automatic connection, the need to manually connect,</p> <p>2 some Bluetooth devices will be prompted, according to the prompts to connect.</p>
	TF card inside device	Can't connect under TF card inside , please extract TF card
Play sound is not normal	Play sound the sound off and on	<p>1 please keep the machine with your Bluetooth device within a distance of 10 meters, without any obstacle barrier.</p> <p>2 please don't put this product close to a strong magnetic or metallic material.</p> <p>3 near the strong electromagnetic waves or wireless network (Wi Fi) interference, please try to avoid the environment.</p>
Can't play	Connect with device but can't play	<p>1 your Bluetooth device does not support the playback, or did not start playing function.</p> <p>The 2 part of the Bluetooth device needs to be installed to play the audio driver, and according to the requirements of the installation and use of.</p>
Insert TF card can't play	Wrong insert TF card	Please recognize socket adjacent to the TF Card directional signs, according to identify TF card insertion direction.
	No mp3 File in the TF card	Device only support MP3 format file
	Local AUX model	Under AUX mode, can't play TF card , please extract AUX line .

Packing list

Thanks for your buy our product T5 bluetooth speaker, enjoy the amazing music.

T5 device-----1pc

USB line-----1pc

User manual-----1pc

Warranty card-----1pc

Certification-----1pc



