

 □iPod
 □iPhone
 □iPad

Extreme\*

Ultra-slim backup battery with built-in Lightning and Micro USB cables



## SAFETY INSTRUCTIONS

Please read the following carefully before using the Extreme Trio 10,000. Incorrect use or incompatibility with device may result in reduced battery performance or damage to your device.

- 01. Please check the voltage compatibility of this product (4.75V~5.25V DC) and your device.
- 02. Do not insert any metallic object into the Extreme Trio 10,000. This may cause the unit to short out.
- 03. Please use the Extreme Trio 10,000 within the following temperature ranges: -10 40°C (14 104°F) 04. Do not disassemble or mishandle product.
- 05. Do not place product near fire or high-temperature environments, to avoid risk of fire or explosions.
- 06. Avoid leaving product in a humid environment.
- 07. Keep product out of reach of children and pets.
- 08. Product will heat up slightly when charging and discharging.
- 09. Product will charge more quickly with a 2.1A AC charger. It will take a longer to charge the product through your computer.
- 10. Marked capacity is based on internal 3.7 V standard battery.
- 11. In case of abnormalities during usage, stop using the product immediately and contact our service
- Thank you for purchasing this iWALK product. In order for your product to operate properly, please read all instructions and usage information contained in this manual prior to use.

# **SPECIFICATIONS**

Product Name : Trio10000

Model No: UBO10000 Capacity: 3.7V 10,000mAh (37W)

Battery Type: Lithium polymer battery

Input: 5V / 1.0-2.4A (Only 6.5 hours for charging Trio if using 2.4A charger, not included)

#### Output: 5V, 3.4A

- Built-in USB charging cable, Mono Output Universal USB Port: 0.5-2.4A (Max)
- Built-in lightning charging cable, Mono Output Built-in Micro USB Cable: 0.5-2.4A (Max)

4.5 Times | 2.5 Times | 0.8 Times

- USB output connector, Mono Output Built-in Micro USB Cable: 0.5-2.4A (Max)

(total voltage of 3 ports: 5V / 3.4A)

Dimensions: 145 x 78 x 13mm (5.7 x 3.1 x 0.5 in)

Weight: 224g (7.91 oz)

best charging of Trio, please use an AC adapter

with at least 5V / 1.5A output.



Q & A

- Q: Why won't the Extreme Trio 10,000 power on if not used for an extended duration?
- A: When the Extreme Trio 10,000 is left unused for an extended duration, it will discharge gradually until no power remains. The Extreme Trio 10.000 will function normally after 2-3 minutes of charging. We suggest charging the product every 3 months to maintain its best functionality.
- Q: Why does the product heat up when it is charging / discharging?
- A: This is a common occurrence, due to power consumption, and will not affect product's functionality. The product will not overheat due to its built-in overcharge protection circuitry.

### Contact us!

We know our products better than anyone

Head Office :U2O Building, Huanzhu Road 385, Jimei, Xiamen, Fujian, China, 361021 Korea Office : 407, Woolim Lions Valley, 144-4, Seongnam-Si, Korea U.S. Office : 90 Gordon Drive, Syosset NY, 11791 U.K. Office : 1 Consort Road, Birmingham, B30 3HD, UK

Head Office HP: +86-592-5030-771 Visit: www.iwalk.net / E-mail: Service@iwalk.net

9

**iWALK** 





charging after your device is almost fully charged.



fully charged. \_\_H will blink when Trio begins charging, and remain on LCD screen while Trio is charging.



Thank you for purchasing this iWALK product.

Our product's warranty period is 12 months starting from the date of purchase. Within the warranty period, free service will be provided if the product has any quality problems (requiring warranty card with distributor's official stamp and valid S/N).

Paid service: customer will incur a repair charge in the following cases:

- No valid warranty card or warranty card incompatible.
- No S/N or S/N incompatible with warranty card.
- Malfunction caused by artificial damages (like external impact or submerging product into water, etc).
- Misuse of the product. User has not followed the instructions in the owner's manual.
- Product disassembled or repaired by individual or unauthorized service center.
- Damages caused by storing the product in a hot or humid environment.

no.		Address	
t name			
no.			
f purchase		Customer service	
acturer		date	

(Please complete warranty card and use for any future warranty service)