AUGUST <sup>®</sup> User Manual	User Manual Thank you for purchasing this August product, please follow the instructions below to use the device.	1. To play MP3 music from a USB stick, MMC or SD card, insert the card or stick into the card reader or USB port. (Please note the transmitter supports up to 8GB memory cards or USB sticks.)
CR100 Car MP3 Player & FM Transmitter with Card Reader/USB	Positive Pole Negative Pole USB Port USB Port USB Port LCD Previous/Vol- FM Frequency- EM Frequency+	<ol> <li>Plug the device into your car's cigarette lighter socket, the device will automatically turn on and start to play any MP3 music files stored on the card or stick.</li> <li>The device's transmission frequency is shown on the LCD screen. Tune your car's radio to the matching frequency to start playback via the stereo.</li> <li>To alter the transmission frequency, use the A- / B+ buttons on the device or CH- / CH+ on the remote control. Changing frequency can help to improve signal quality.</li> <li>The PREV, NEXT buttons can be used to skip forward and backwards through stored tracks and CH button is used to jump to another track randomly. PLAY/PAUSE button pauses and resumes playback.</li> <li>To set the volume, press and hold PREV or NEXT on the device or use the volume buttons on the remote control.</li> </ol>
	-1-	-2-
	<ol> <li>To change EQ settings press the EQ button on the remote to cycle through: NORMAL, POP, ROCK, JAZZ, CLASSIC and COUNTRY.</li> <li>To select a specific song, type in the number of the track you would like to play, it will start the playback after 4 seconds. For example: pressing number "2", it will start to playback the second song in the track.</li> <li>Pressing and holding the PLAY/PAUSE button switches the playback mode between: Single (repeats the current track continuously), Random (plays all tracks in a random order), Folder (plays all tracks in</li> </ol>	11. Specifications         FM Frequencies Range       87.5 – 108MHz         Input Ports       USB SD/SDHC/MMC Card Reader         Card Reader       Support SD/MMC card
		USB Port Support USB memory stick in FAT format and up to 8GB
		Supported File Type MP3
		Power Input 12 / 24 V
	<ul> <li>10. To connect your MP3 player, mobile phone or other multimedia player to your car's FM radio, use the 3.5 mm audio cable supplied to connect from your player's headphone socket to the device's 3.5mm audio in.</li> </ul>	Please note the above instructions are only intended for reference. August International Ltd reserves rights to revise product specifications, features and design without notice. For any further queries, please telephone August International Ltd's helpline +44 (0)845 250 0586 or email service@augustint.com
	-3-	-4-