

FULL ONE-YEAR LIMITED WARRANTY ON ARSENAL FIREARMS® WEAPONS MANUFACTURED BY ARSENAL FIREARMS Srl

FROM ARSENAL FIREARMS TO YOU – This warranty is extended by Arsenal Firearms Srl to the original purchaser and first owner within One (1) year warranty period and applies to products purchased from any authorized Arsenal Firearms dealer in the United States or Canada.

WHAT WE DO – If your Arsenal Firearms product fails because of a manufacturing defect in material or workmanship within one (1) year after the date of original retail purchase, we will repair without charge to you. Parts and labor are included. If we are unable to repair firearms, we will replace it with another or we refund the original purchase price to you.

HOW TO OBTAIN SERVICE – An international network of Arsenal Firearms Authorized Service Centers for Arsenal Firearms products has been established to assure you of fast and efficient service if a warranty problem occurs. The addresses of Arsenal Firearms Authorized Service Center and Arsenal Firearms Service Department for Arsenal Firearms products are attached to this User Manual. Only the Arsenal Firearms Authorized Service Center and the Arsenal Firearms Product Service Department are authorized to make repairs within the scope of this warranty without charge. To expedite the return of your firearms we encourage you to send it to the nearest listed Arsenal Firearms Authorized Service Center.

You will be required to establish your date of purchase to receive warranty service. PLEASE BE SURE TO KEEP YOUR DATED SALES SLIP, CREDIT CARD RECEIPT, CANCELED CHECK, A COPY OF THE FIREARMS TRANSACTION RECORD 4473, OR OTHER DEFINITIVE DATED PROOF OF YOUR DATE OF PURCHASE.

WHAT IS NOT COVERED – This warranty does not cover costs of repairs to your firearm or its replacement when damage is unrelated to defects in material or workmanship, nor does it cover wear and tear or unreasonable use or abuse by you including (but not limited to) failure to provide proper care or maintenance, alteration non authorized in writing by Arsenal Firearms, damage through use of improper or overloaded ammunition or obstructed or damaged barrels. Arsenal Firearms Srl reserves the right to inspect the product prior to making any adjustment covered by this warranty. This warranty does not apply to products purchased outside the United States or Canada nor does it apply to products purchased in either the United States or Canada but not used in the United States or Canada. This warranty only applies to the first and original buyer/owner of the related firearm. IN NO EVENT SHALL Arsenal Firearms Srl BE LIABLE FOR CONSEQUENTIAL END USE DAMAGES, ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE IN EFFECT ONLY FOR DURATION OF THIS WARRANTY. ALL SUCH WARRANTIES TERMINATE WHEN THIS WARRANTY TERMINATES. SOME STATES, HOWEVER, DO NOT ALLOW LIMITATIONS ON HOW LONG AND IMPLIED WARRANTY LASTS, OR EXCLUSIONS OF INCIDENTIAL OR CONSEQUENTIAL DAMAGES, SO SUCH LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHT WHICH VARY FROM STATE TO STATE (OR PROVINCE I).

FUNDAMENTAL NRA RULES FOR SAFE GUN HANDLING

1. ALWAYS KEEP THE GUN POINTED IN A SAFE DIRECTION 2. ALWAYS KEEP YOUR FINGER OFF THE TRIGGER UNTIL READY TO SHOOT 3. ALWAYS KEEP THE GUN UNLOADED UNTIL READY TO USE

ARSENAL FIREARMS srl

Via X Giornate n.14 25063 Magno di Gardone Val Trompia (BS) Italia Tel. +39 0306152945 Fax +39 0306152713 www.arsenalfirearms.com

info@arsenalfirearms.com



AF2011 - A1 SAFFTY AND INSTRUCTION MANUAL EFORE USING THIS FIREARM **READ AND FOLLOW THESE** INSTRUCTIONS.

Dear and valued ARSENAL Customer,

Thank you for purchasing a fine Arsenal Firearm Pistol. The AF2011 series of double barrel pistols are unique firearms: they will offer you a wide variety of shooting experiences and an exciting range of target applications.

The pistols are innovative weapons, and they must be handled as such: please do make the time to read this Owner's and Instruction Manual and use it to inspect and familiarize yourself with your new firearm.

Dry firing of your new double barrel pistol is acceptable without the magazine in position if you wish to explore the firearm prior to test firing at the range, or for safe handling when demonstrating the gun to others.

Thank you for choosing an exclusive Arsenal Firearms pistol. We wish you good shooting!



1	Frame		19	Recoil spring guide (2)
2	Slide		20	Slide stop
3	Barrel right		21	Front Sight
4	Barrel left		22	Recoil spring (2)
5	Barrel link		23	Recoil spring plug (2)
6	Barrel link pin		24	Firing pin spring (2)
7	Ejector right		25	Firing pin (2)
8	Ejector left		26	Extractor right
9	Ejector pin	-	27	Extractor left
10	Trigger pad (2)		28	Firing pin stop right
11	Trigger bow (2)		29	Firing pin stop left
12	Magazine catch	-	30	Rear sight
13	Magazine catch spring	•	31	Disconnector (2)
14	Magazine catch lock		32	Sear (2)
15	Plunger tube		33	Sear pin
16	Plunger spring	•	34	Hammer
17	Slide stop plunger		35	Hammer pin
18	Safety lock plunger		36	Safety lock

de (2)	37	Hammer strut	
	38	Hammer strut pin	
	39	Grip safety	
	40	Mainspring housing	
ıg (2)	41	Mainspring housing pin	
(2)	42	Hammer spring (2)	
	43	Mainspring cap	
	44	Mainspring housing pin retainer	
	45	Mainspring cap pin	
ght	46	Sear spring	
ft	47	Bushing grip screw	
	48	Grip, right	
	49	Grip, left	
	50	Grip screw (4)	
	51	Magazine body	
	52	Magazine base plate	
	53	Barrel bushing right	
	54	Barrel bushing left	

	In Canada certain warranties are required by Provincial law: this warranty is in addition to and not a modification of or a subtraction from
	 any required Canadian warranty, and it does not exclude or limit required warranties or any of the rights of remedies that are available in Canada under Canadian law.
PISTOL SERIAL NUMBER:	INSTRUCTIONS FOR RETURN – Failure to follow the instruction below will not prevent you from obtaining warranty service. These instruc- tions are designed to assure you of the best possible service. If for any reason you should have to return the firearms, please use extreme caution and make certain that it is UNLOADED . Please return the complete firearm.
CALIBER:	 Package the firearm securely to prevent damage in transit. Use original factory case to secure transport. Ensure that a letter is securely and obviously attached to the firearm. This letter should include your full name, address and telephone number where you may be reached both during normal business hours and at your residence, and include a thorough description of the problem that you encountered with your firearm so that we may make proper repairs. Record any alterations or gunsmith work done or your pistol before damage. Include your prepaid insurance and UPS/FedEx Next Day Air tracking receipts with your instructions for repair. You will be reimbursed for documented shipping and insurance costs directly from the Warranty service. Please include a photocopy of your proof of date of purchase (sales slip, credit card receipt and canceled check, BATF form 4473, Etc. include with your letter the date that the firearm was originally purchased at retail. Do not send the original proof of purchase, as the copy
FIRST OWNER NAME AND ADDRESS:	sent will be retained. 5. If you live in the United States, send your firearm to one of the Arsenal Firearms Authorized Service Center for Arsenal Firearms products If you live in Canada, send it to one of the Arsenal Firearms Authorized Service Centers in Canada. 6. WHERE TO GET FURTHER HELP – If you wish further help or information concerning this warranty, please write or call the USA Produc Service Department at the following address: For Arsenal Firearms Sr
	Name and Surname
DEALER/RETAILER NAME AND ADDRESS:	Arsenal Model and Serial Number
ADDICESS:	Date of Purchase
	Dealer Name and Address
INFO ON PREFERRED	How did you learn about Arsenal pistols?
AMMUNITION:	Do you own other Firearms products, if yes, short list
	Do you want other Arsenal firearms availability info
	What is your main shooting activity





LIST OF SECTIONS

Notice - Disclaimer of liability	p.03
Important	p.03
Cautions	p.05
General handling cautions	p.05
Range cautions	p.07
Loading cautions	p.07
Shooting cautions	p.08
Malfunctions cautions	p.11
Cleaning and storage cautions	p.11
Gun abuse cautions	p.12
AF2011-A1 AND SUBSEQUENT MODELS FIELD STRIPPING PROCEDURE	p.13
Limited Lifetime Service Agreement	p.32

Arsenal

READ AND UNDERSTAND ALL THE FOLLOWING PRECAUTIONS BEFORE REMOVING THIS FIREARM FROM ITS PACKAGE. THIS ARSENAL FIREARM PRODUCT IS CLASSIFIED BY THE ALCOHOL TOBACCO AND FIREARM DIVISION OF THE INTERNAL REVENUE SERVICE, U.S. TREASURY DEPARTMENT, AS A FIREARM OR DANGEROUS WEAPON; IT IS, THEREFORE, POTENTIALLY LETHAL!

WARNING: IF THIS FIREARM IS CARELESSLY OR IMPROPERLY HANDLED, UNINTENTIONAL DISCHARGE COULD RESULT AND COULD CAUSE INJURY, DEATH, OR DAMAGE TO PROPERTY.

CAUTION: CAREFULLY READ THIS INSTRUCTION MANUAL WHICH GIVES BASIC ADVICE ON THE PROPER HANDLING AND FUNCTIONING OF THIS ARSENAL FIREARM PRIOR TO LOADING AND FIRING. However, your safety and the safety of others (including your family) depends on your mature compliance with that advice, and your adoption, development and constant employment of safe practices.

If unfamiliar with firearms, seek further advice through safe handling courses run by your local gun clubs, NRA approved instructor, or similar qualified organizations. AF2011-A1/LS/MC-2013ENG

NOTICE - DISCLAIMER OF LIABILITY

Arsenal Firearms shall not be responsible for injury, death, or damage to property resulting from either intentional or accidental discharge of this firearm, or from its function when used for purposes or subjected to treatment for which it was not designed. Arsenal Firearms will not honor claims involving this firearm which result from careless or improper handling, unauthorized adjustment or parts replacement, corrosion, neglect, or the use of wrong caliber ammunition, or the use of ammunition other than original high quality commercially manufactured ammunition in good condition, or any combination thereof. Arsenal Firearm will not honor claims involving this firearm for any reason or cause when such claims are made by the second or subsequent owner.

IMPORTANT

Before it left the factory this firearm was tested, carefully inspected, and packaged. Arsenal Firearms cannot control product handling after it leaves the factory; therefore, please examine this firearm carefully at the time of purchase to insure that it is unloaded and undamaged. The dealer will be pleased to assist you in making this examination and endeavor to answer your further questions.

This instruction manual should always accompany this firearm and be transferred with it upon change of ownership.

WARNINGS

Arsenal & Firearms

!WARNING!

AF2011-A1/LS/MC-2013EN0

DO NOT ATTEMPT TO FIELD-STRIP YOUR AF2011-A1 SECOND CENTURY DOUBLE BARREL PISTOL IF YOU HAVE NEVER DISASSEMBLED A SEMIAUTOMATIC PISTOL OR A COLT 1911-TYPE PISTOL BEFORE. PLEASE REFER TO AN ARMOURER OR EXPERIENCED SHOOTER-GUN OWNER IF IN DOUBT. AF2011-A1/LS/MC-2013ENG

Arsenal Firearms

We want you to enjoy your Arsenal Firearms pistol, but we want you to enjoy it safely. You may be an experienced safe shooter already familiar with the procedures in this instruction manual, or you may never have handled a gun before. Either way we urge you to READ THIS ENTIRE INSTRUCTION MANUAL CAREFULLY. YOU MUST FOLLOW THE SAFETY INSTRUCTIONS FOR YOUR SAFETY AND THE SAFETY OF OTHERS.

WARNING: When you squeeze the trigger, you must expect the gun to fire, and you must take full responsability for firing it. Your care can avoid accindental discharge, and you will thereby avoid accidental injury and death.

CAUTIONS

GENERAL HANDLING CAUTIONS

1. ALWAYS HANDLE YOUR PISTOL AS IF IT WERE LOADED so that you never fire it accidentally when you think it is unloaded.

2. NEVER POINT YOUR PISTOL AT ANYTHING YOU DO NOT INTEND TO SHOOT so that if it fires accidentally, injury, death, or damage to property will be prevented.

3. NEVER TAKE ANYONE'S WORD THAT A GUN IS UNLOADED: check for yourself with fingers off the trigger and gun pointed in a safe direction, so that you never fire the



gun accidentally when you think is unloaded.

4. ALWAYS MAKE SURE YOUR PISTOL IS NOT LOADED AND SLIDE IS LATCHED OPEN BEFORE LAYING IT DOWN, OR HANDING IT TO ANOTHER PERSON, so that it cannot be fired when it is unsafe to do so.

5. ALWAYS KEEP AND CARRY YOUR PISTOL EMPTY, WITH THE HAMMER FORWARD except when you intend to shoot, so that your pistol cannot be fired when you do not mean to fire it.

6. ALWAYS BE AWARE OF POSSIBLE RISK FROM DROPPING YOUR PISTOL. Some parts of the mechanism could be damaged. You may not see the damage but if it is severe, the pistol may discharge and cause injury, death, or damage to property. If your pistol has been dropped, have it examined by a competent gunsmith before using it again.

7. NEVER LEAVE PISTOL COCKED READY TO FIRE as this condition is extremely dangerous, and pistol could easily be accidentally discharged, causing injury, death, or damage to property.

8. NEVER LEAVE A LOADED PISTOL UNATTENDED. Someone, especially a child, may fire it and cause injury, death, or damage to property.

AF2011-A1/LS/MC-2013ENG

9. ALWAYS INSTRUCT CHILDREN TO RESPECT FIREARMS. If you teach your children to shoot, teach them or get them trained by a qualified instructor to treat and use the pistol properly, and always supervise them closely. Always stress safety so that your children will not fire the pistol when it is unsafe to do so.

RANGE CAUTIONS

10. ALWAYS BE SURE YOUR BACKSTOP IS ADEQUATE to stop and contain bullets before beginning target practice so that you do not hit anything outside the range shooting area. THINK! What will you HIT if you MISS the target?

11. ALWAYS PUT A KNOWLEDGEABLE AND RESPONSIBLE PERSON IN CHARGE TO MAINTAIN SAFETY CONTROL WHEN A GROUP IS FIRING ON A RANGE. Obey his commands so that discipline is mantained to reduce the likelihood of accidents.

12. ALWAYS CARRY YOUR PISTOL EMPTY WITH SLIDE LATCHED OPEN WHILE ON A RANGE until preparing to fire, keep it pointing towards the backstop when loading, firing and unloading, to eliminate the risk of injury, death, or damage to property.

LOADING CAUTIONS

13. ALWAYS BE SURE BARREL BORE, CHAMBER AND ACTION ARE CLEAN AND



CLEAR OF OBSTRUCTIONS. Clean a fouled pistol immediately so that it will function correctly and safely.

14. ALWAYS USE ONLY CLEAN, DRY, ORIGINAL HIGH QUALITY COMMERCIALLY MANUFACTURED AMMUNITION IN GOOD CONDITION WHICH IS APPROPRIATE TO THE CALIBER OF YOUR PISTOL. Gun and ammunition manufacturers design their products within exacting engineering safety limits. Handloads and remanufactured ammunition are sometimes outside those limits and can be so unsafe as to blow up the chamber, slide and receiver and cause injury, death, or damage to property.

SHOOTING CAUTIONS

15. NEVER DRINK ALCOHOLIC BEVERAGES OR TAKE DRUGS BEFORE OR DURING SHOOTING, as your vision, coordination and judgment could be seriously impaired making your gun handling unsafe.

16. ALWAYS SEEK A DOCTOR'S ADVICE IF YOU ARE TAKING MEDICATION, to be sure you are fit to shoot and handle your pistol safely.

17. ALWAYS WEAR AND ENCOURAGE OTHERS TO WEAR EAR PROTECTION WHEN SHOOTING, especially on a range. Without ear protection, the noise of even one shot from your pistol, and other guns close to you, could leave a "ringing" in the ears for

Arsenal Firearms

WARNINGS

some time after firing, while the cumulative long term effect could be permanent hearing loss.

18. ALWAYS WEAR AND ENCOURAGE OTHERS TO WEAR PROTECTIVE SHOOTING GLASSES. Flying particles could damage eyes and cause blindness; but protective shooting glasses should prevent such injury.

19. ALWAYS KEEP THE SAFETY ON WHEN PISTOL IS LOADED AND COCKED UNTIL YOU ARE READY TO FIRE. This will minimize risk of an accidental discharge.

20. ALWAYS KEEP CLEAR AND KEEP OTHERS CLEAR OF THE EJECTION PORT. Spent cartridges are ejected with enough force to cause injury. The ejection port must also be unobstructed by your hand to insure safe ejections of live rounds. Never place fingers in ejection port; they could be burned by hot metal or injured by the slide moving forward.

21. NEVER SQUEEZE THE TRIGGER OR PUT YOUR FINGER IN THE TRIGGER GUARD UNTIL YOU ARE AIMING AT A TARGET AND READY TO SHOOT. This will prevent you firing the pistol when it is pointing in an unsafe direction.

22. ALWAYS BE ABSOLUTELY SURE OF YOUR TARGET AND THE AREA BEHIND IT BEFORE YOU SQEEZE THE TRIGGER. A bullet could travel through or past your tar-



get up to 1 ½ miles... if in doubt, don't shoot. THINK! What will you hit if you miss the target?

23. NEVER SHOOT AT A HARD SURFACE SUCH AS A ROCK, OR A LIQUID SURFACE SUCH AS WATER. A bullet may ricochet and travel in any direction to strike you, or an object you cannot see, causing injury, death or damage to property.

24 NEVER DISCHARGE A FIREARM NEAR FLAMMABLE MATERIAL Flame and sparks erupt from the firearm when discharged. They could start a fire or cause flammable liquids and gases to explode.

25. NEVER FIRE YOUR FIREARM NEAR AN ANIMAL unless it is trained to accept the noise; an animal's startled reaction could injure it or cause an accident.

26. NEVER INDULGE IN "HORSEPLAY" WHILE HOLDING YOUR PISTOL as it may be accidentally discharged.

27. NEVER WALK, CLIMB OR FOLLOW A COMPANION WITH YOUR PISTOL COCKED READY TO FIRE, out of its holster, or with the hammer in any position other than forward on an empty chamber, to eliminate risk of accidental discharge. When hunting, hold your pistol so that you can always control the direction of the muzzle.

MALFUNCTION CAUTIONS

28. FAILURE TO FIRE: ALWAYS HOLD PISTOL, KEEPING IT POINTED TOWARD THE TARGET OR A SAFE AREA AND WAIT 30 SECONDS when pistol fails to fire. If a hangfire (slow ignition) has occurred, round will fire within 30 seconds. If round does not fire, remove magazine, eject round and examine primer; if firing pin indent on primer is light, off center, or non-existent, have pistol examined by a competent gunsmith before firing again. If firing pin indent on primer appears normal (in comparison with similar previously fired rounds) assume faulty ammunition; segregate misfired round from other live ammunition and empty cases, reload and carry on firing.

NOTE: dispose of misfired rounds in accordance with ammunition manufacturer's instructions

29. NEVER USE YOUR PISTOL IF IT FAILS TO FUNCTION PROPERLY, AND NEVER FORCE A JAMMED ACTION, as a round may explode causing serious injury, possible death, or severe damage to your pistol.

CLEANING AND STORAGE CAUTIONS

30. ALWAYS MAKE SURE YOUR PISTOL IS NOT LOADED BEFORE CLEANING, STOR-ING, TRAVELING, LAYING IT DOWN, OR HANDING IT TO ANOTHER PERSON. so that



it cannot be fired when it is unsafe to do so.

31. ALWAYS KEEP AND STORE YOUR PISTOL AND AMMUNITION IN SEPARATE LOCKED RECEPTACLES OUT OF REACH AND SIGHT OF CHILDREN AN UNTRAINED PEOPLE, to minimize the risk of pistol and ammunition being easily available for loading an firing.

GUN ABUSE CAUTION

32. NEVER ABUSE YOUR PISTOL by using it for any purpose other than shooting.

33. NEVER DRY FIRE THE PISTOL WHEN THE SLIDE IS REMOVED FROM THE RE-CEIVER, and do not alter parts as the level of safety could be reduced.

NOTE: Please note that we have chosen to use the word "SQUEEZE" in this instruction manual instead of "PULL" or "PRESS" when trigger movement is described; this is simply to remind you of the need for a gentle squeezing action to achieve accuracy. AF2011-A1 AND SUBSEQUENT MODELS FIELD STRIPPING PROCEDURE



!WARNING!

DO NOT ATTEMPT TO FIELD-STRIP YOUR AF2011-A1 SECOND CENTURY DOUBLE BARREL PISTOL IF YOU HAVE NEVER DISASSEMBLED A SEMIAUTOMATIC PISTOL OR A COLT 1911-TYPE PISTOL BEFORE. PLEASE REFER TO AN ARMOURER OR EXPERIENCED SHOOTER-GUN OWNER IF IN DOUBT.

AF2011-A1/LS/MC-2013ENG





1

Before attempting to field strip your pistol, make sure you have selected a flat and stable surface, with enough light and free from foreign small parts. **Make sure there is no loose ammunition close to the gun** and that you are focused and not distracted from other issues. Please try and do this when alone.



Lift the gun from the security carry case pointing the muzzles **towards a safe direction**.







5

Firmly gripping both the frame and the front part of the double slide, cock the action far enough to have clear access and visibility of the 2 barrel chambers. By repeating this procedure two or three times, **make sure that there are no rounds chambered in the barrels.**



Fully cock the double hammer until it stops.

Remove the double magazine

by pressing the push button latch on the left side of the pistol.

3





While you hold firmly the single spur double hammer, pull the trigger and release the hammer until it stops **on half-cock safety position**.

Arsenal



AF2011-A1/LS/MC-2013ENG



9

Paying attention to the **recoil spring pressure**, carefully release the pressure on the special Take Down Tool until both the barrel busing and the recoil spring guide rod eject from the slide housing.



8

7

Keeping a firm pressure on the recoil spring guide rod with the special Take Down Tool, rotate counter clock-wise the left barrel bushing until it stops.

While firmly holding the pistol's front

spring guide rod until it comes flush

with the front face of the slide.

special Take Down Tool as shown in the picture and push down the right recoil

portion with one hand, engage the



10 Remove the left barrel bushing.

Arsenal Firearms





Remove the left recoil spring guide rod.

12 Remove the left recoil spring. AF2011-A1/LS/MC-2013ENG





13

While firmly holding the pistol's front portion with one hand, engage the special Take Down Tool as shown in the picture and push down the right recoil spring guide rod until it comes flush with the front face of the slide.

Arsenal Krearms



Keeping a firm pressure on the recoil spring guide rod with the special Take Down Tool, rotate counter clock-wise the right barrel bushing until it stops.



Paying attention to the **recoil spring pressure**, carefully release the force on

the special Take Down Tool until both the barrel busing and the recoil spring guide rod eject from the slide housing.







Remove the left recoil spring guide rod.







(18) Remove the left recoil spring.

17

22



(15)

(16)

23







While holding the front portion of the pistol with one hand, fully cock the double hammer.

)

20

Move the slide rearward until the slide stop latch top index engages the take down notch on the left side of the slide.

AF2011-A1/LS/MC-2013ENG





21

22

While keeping the slide firmly into position, with the index finger of the frame gripping hand push out the slide stop cross pin.

Arsenal



Remove the slide stop cross pin.

24







23

Remove the double slide by pushing it forward until it comes clear of the grip frame.



AF2011-A1/LS/MC-2013ENG





25

Remove the right recoil spring rod assembly.

26

Remove the left recoil spring assembly.

Arsenal 💞 Firearms









28 Lower the right barrel link.







Push out the left barrel from the front portion of the slide.



29

Remove the left barrel from the slide.





Push out and remove the right barrel from the slide.

I

31

32



The filed stripping of your double barrel **AF2011 Second Century** pistol is now complete and the pistol

is ready for cleaning. Please do not disassemble the pistol any further unless you are an experienced armourer: ANY FURTHER AF2011-A1/LS/MC-2013ENG

UNAUTHORIZED DISASSEMBLY AND/OR INCORRECT RE-ASSEMBLY OF THE PISTOL MAY CAUSE PERMANENT DAMAGE, DANGEROUS OPERATION AND INJURY TO THE SHOOTER AND OTHERS. ANY UNAUTHORIZED DISASSAMBLY OF THE PISTOL WILL VOID THE WARRANTY: THE MANUFACTURER WILL NOT ACCEPT ANY CLAIMS ARISING FROM INCORRECT RE-ASSEMBLY OF THE PISTOL BY UNAUTHORIZED PERSONNEL.

!WARNING!

THE AF2011-A1 SECOND CENTURY DOUBLE BARREL PISTOL HAS BEEN DESIGNED AND MANUFACTURED TO FUNCTION AND PERFORM FLAWLESSLY OVER YEARS OF OPERATION AND FOR THOUSANDS OF ROUNDS: UNDER NO CIRCUMSTANCES THE PISTOL MUST BE DISASSEMBLED AND RE-ASSEMBLED WITH ONLY ONE SEAR AND ONE DISCONNECTOR PLUNGER.

BY DOING SO, THE OWNER/SHOOTER WILL SERIOUSLY ENDANGER HIMSELF AND OTHERS WHILE USING THE PISTOL. AGAIN THE MANUFACTURER WILL ACCEPT NO CLAIMS ARISING FROM THE PISTOL BEING OPERATED WITH ONE SEAR AND ONE DISCONNECTOR ONLY.

Arsenal



LIMITED LIFETIME SERVICE AGREEMENT

Arsenal Firearms repair any factory defective part(s) of your AF-2011 A1 but cosmetic corrections and grip replacement will be made only during the first year. This agreement will not apply to your AF2011-A1 when it is alterated, abused, wilfully damaged or damaged by overpressure ammunition. Moreover, this agreement will not apply to those parts of your Arsenal Firearms that have been "tuned" or "gunsmithed" for performance, other than customized tuning and other services provided by Arsenal Firearms Shop. This agreement is not transferable, its benefits apply only to the original retail purchaser.

HEALTH AND ENVIRONMENTAL WARNING

Discharging firearms in poorly ventilated areas, cleaning firearms, or handling ammunition may result in exposure to lead and other substances known to cause birth defects, reproductive harm, cancer, and other serious physical injury. Have adequate ventilation at all times. Wash hands thoroughly after exposure.