

SNO CONE MACHINE .

02/2014 CE www.CarnivalKingSupplies.com

SNO CONE MACHINE MANUAL



General Safety Precautions

To ensure safe operation, read the following statements carefully. These precautions should be followed at all times. Failure to follow these precautions could result in injury.

- To reduce risk of injury or damage to the unit:
- 1. Do not operate unattended.
- 2. Unit must be only used in a flat, level position.
- 3. This machine must not be operated by anyone under the age of 18.
- 4. This machine must be connected to grounded socket
- 5. Unplug unit and turn off before cleaning or moving.
- 6. Do not spray controls or outside of unit with liquids or cleaning agents.
- 7. Do not operate if unit has been damaged or is malfunctioning in any way.
- 8. This unit has sharp cutting blades, be very careful when cleaning.
- 9. Do not spray controls or outside of unit with liquids or cleaning agents.
- 10. Do not clean the unit with steel wool.
- 11. When not in use, do not leave the machine running for more than 60 minutes.

Sno Cone Machine Specs $C \in$

Item #	382SCM250
Overall Dimensions	16.5"W x 25"H x 13.5"D
Cabinet Dimensions	16.5"W x 14.5"H x 13.5"D
Voltage	120V

Function and Purpose

This unit is intended to be used for crushing ice in commercial foodservice operations only. It is not intended for household, industrial or laboratory use.

Before using this equipment it must be cleaned and **dried thoroughly**. Clean all surfaces before use. Failure to clean surfaces before using the unit could cause food contamination.

This Ice crusher is intended for crushing ice cubes for use in beverages, ice cubes should be a maximum of 2 inches in diameter. Larger pieces should be broken up before processing through the machine.



SNO CONE MACHINE MANUAL

INSTALLATION AND OPERATION INSTRUCTIONS

- 1. Locate the Ice crusher in a place where it cannot be pushed off counter.
- 2. Keep the area at the front of the Ice crusher clear for unobstructed access during operation.
- 3. Keep unit and power cord away from open flames, electric burners or excessive heat.
- 4. Use only grounded electrical outlets matching the nameplate rated voltage.
- 5. Do not use an extension cord with this equipment.
- 6. Do not spray controls or outside of unit with liquids or cleaning agents.

Operation

- 1. Position the Ice crusher ensuring sufficient workspace.
- 2. Open the door and wipe the acrylic tank with a dry cloth, check that the blade is firmly installed.
- 3. Lift the handle to open the ice holder, place ice cubes into the holder and close the lid.
- 4. Press the switch to start the unit, depress the handle to push the ice cubes through the blade.
- 5. Crushed ice will be directed into the acrylic tank
- 6. Ice may be removed by opening the door and using a scoop.

Warning

ELECTRIC SHOCK HAZARD

Keep water and other liquids from entering the inside of the equipment. Liquid inside the equipment could cause an electrical shock.

Warning

Sharp blades, do not place hands in or near the ice holder while the motor is running.

Cleaning

To maintain the appearance and increase the service life, clean your unit daily.

NOTE: Do not clean the unit with steel wool.

- 1. Allow the unit to cool completely before cleaning.
- 2. Unplug the unit.
- 3. Do not immerse the cord, plug or controls in water or any other liquid.
- 4. Do not clean the machine with solvents or chemicals that can contaminate the ice.
- 6. Using a damp cloth or sponge dipped in soapy water to clean the unit and well; rinse thoroughly.

7. Dry thoroughly after cleaning.

Warning

Do not spray water or cleaning products. Liquid could contact the electrical components and cause a short circuit or an electrical shock. Do not use unit if power cord is damaged or has been modified.

WWW.CARNIVALKINGSUPPLIES.COM • INFO@CARNIVALKING.COM

SNO CONE MACHINE MANUAL



90 Day Replacement Warranty

This warranty is not effective if damage occurs because of accident, carelessness, improper installation, lack of proper set-up, supervision when required, or if the equipment is installed or operated in any manner contrary to the installation and operating instructions. Work performed by unauthorized personnel or unauthorized service agencies voids this Warranty.

This warranty does not apply to any warranty claims made on products sold or used outside of the United States.

