

Rider Service Line (toll free in the US): 877-775-4832 International Telephone: 509-427-4950 40 SW Cascade Ave., Suite 45, Stevenson, WA, USA 98648


Rider Service Hotline: riderhotline@slingshotsports.com

For further instructions go to: www.slingshots.com

PRODUCT SUPPORT

The graph above shows the recommended wind range for the REV. Due to the depondenced by Slingshot. Regardless of your height, weight or skill level Slingshot encourages you to adhere to all safety notes in this user manual. No kite is 100% encourages you to adhere to all safety notes in this user manual. No kite is 100% encourages you to adhere to all safety notes in this user manual. No kite is 100% encourages you to adhere to all safety notes in this user.

: ATOM TMATRO TM:



and continue to pull down until it rest securely against the round plastic ball. Double check that your Surefire bungee leash is seated properly by pulling to the outside of the red handle on both sides.

- Fold the oval stainless steel ring over the Amsteel loop and secure the end of the stainless steel oval ring into the plastic tubing of the red safety handle.
 Grasp the red safety handle and pull it over the stainless steel oval ring and continue to pull down until it rest and continue to pull down until it rest
- Insert the front half of stainless steel oval ring in the Amsteel loop.

Pull on the chicken loop to assure a

the end of the safety release knob and

Feed the safety pin into the opening at

safety release knob at the same time.

opening next to the safety release knob. Fold safety pin over and pull back the

Feed the safety pin through the

SUREFIRE BUNGEE RESET

proper reboot.


release the knob.

LOCK-N-LOAD REBOOT



To completely disconnect yourself from the kite, firmly grasp the red safety handle on the Quick Release Surefire Bungee leash and pull towards you in the same direction the arrow indicates.


SUREFIRE BUNGEE RELEASE




LESEL

The Rev is equipped with a NEW patent pending below the bar focus on rider System placing the nience. Connect your Quick Renience. Connect your Quick Renience Surefire Bungee leash to the ring with the red oh-shit handle located on your chicken loop. To depower the kite completely, pull the red Lock-n-load Safety pull the red Lock-n-load Safety pull the sky without power. You from the sky without power. You will still be connected to the kite will still work without power. You will still be connected to the kite

SAFETY CENTER SYSTEM







SAFETY

rangled. (see diagram)

Connect the grey center lines to the front bride attachment points. (see diagram)

Connect the red and white outside lines to the rear attachment points. Make sure the rear attachment points attachment point sand the white fly line is attachment point and the white fly line is

Before connecting the lines to the kite, visually check that the bridle is not

connected to the white attachment point.

Unwind lines off of the bar and straighten out as usual.

(see diagram)

weather climates)

weather climates)








KILE SELNE

MIND BYNCES

WARNING



VISION OF SUCH A PERSON. The use of this product exposes the user to many unavoidable and unexpected risks, dangers and hazards. The suppliers of this product are not responsible for any damages to property or any personal injury caused by any use, misuse, abuse, or irresponsible use of this product. Kiteboarding is an extreme sport. Power kites, their lines and control equipment can be dangerous to flyers and to anyone in the vicinity of their use. Kiteboarding must be taken seriously and we recommend that, at least in the early stages of use, you seek the guidance of professional instructors and experienced kiteboarders. Improper and/or unreasonable use of this kite may result in serious injury or death to yourself and others. Do not use your kite near powerlines, airports or streets, and keep your kite flying lines away from people and obstacles. Always fly in an open area, observe wind and weather conditions, particularly in circumstances where you may encounter offshore, onshore winds or strong winds. Do not attempt to use your kite on water until you are confident and comfortable with the use of a trainer kite on land. Spend time to become familiar with the operation of your kite and remember that you are responsible for its operation and

for safety of those around you. Never attach yourself or tie yourself permanently to the kite lines. The kite is not intended for use as a flying device nor indeed is it intended as a means of flotation.

IMPORTANT INFORMATION FOR THE SAFETY OF YOU AND THOSE AROUND YOU, PLEASE READ THE FOLLOWING SAFETY REMINDERS BEFORE OPERATING YOUR SLINGSHOT KITE.

The use of this equipment could result in risk of serious bodily injury or death to yourself or those in close proximity to you. Slingshot strongly recommends that beginners take a lesson from a certified school. This product is designed and manufactured for recreational use on water or snow only. Slingshot advises that you closely inspect your equipment for signs of wear and tear before each use. If there are any signs of wear and tear, replace or repair them immediately. Contact www.slingshotsports. com for more information. Never put yourself in a situation where breakage of any of the components would put you or anyone else in danger. Although these kites have a huge wind range, flying this kite in over powered condition can be dangerous and is not recommended. Slingshot strongly recommends using appropriate protective gear including a certified helmet, flotation devise, and wetsuit in cool water Make sure you use properly designed and manufactured parts from reputable suppliers. (Harnesses, helmets, etc.) Study the current conditions including, waves, tides, currents, and weather forecasts before going kiteboarding. Become familiar with any new kiteboarding location by talking to the locals and asking questions. Study the weather conditions and know your launch ing and landing zones.

RELEASE OF LIABILITY, CLAIM WAIVER AND ASSUMPTION OF RISK AGREEMENT

By assembling this product, you are agreeing to: 1) be bound to the terms set forth below; and 2) require anyone using this product to be bound by such terms. If you are unwilling to be bound by these terms, return this product (before use) for a full refund. WARNING: Slingshot LLC® products SHOULD NOT be used in proximity to persons or objects within the radius of a fully extended kite at any time.

ASSUMPTION OF RISK

Use of this product and any of its components involves certain inherent risks, dangers and hazards, which can result in serious personal injury and death. In using this product you freely agree to assume and accept any and all known and unknown risks of injury while using this equipment. The risks inherent in the sport can be greatly reduced by abiding by the Warning Guidelines listed in this User's Guide and by using common sense.

RELEASE AND WAIVER OF CLAIMS AGREEMENT

In consideration of the sale of this product to you, you hereby agree to the fullest extent permitted by law as follows: To waive any and all claims that you have or may in the future have against Slingshot Sports LLC resulting from use of this product and any of its components. To release Slingshot Sports LLC from any and all liability for any loss, damage, injury or expense that you or any users of this product may suffer, or that your next of kin may suffer, as a result of the use of this product, due to any cause whatsoever, including negligence or breach of contract on the part of Slingshot Sports in the design or manufacture of this product.

ARBITRATION

In further consideration of the sale to you of this product and any of its components you hereby agree to submit to binding arbitration any and all claims, which you believe you may have against Slingshot Sports arising from the use of any Slingshot LLC® equipment. The arbitration shall be pursuant to the rules of the American Arbitration Association, Arbitration shall be commenced within one (1) year from the date on which any alleged claim first arose. Further, the arbitration shall be held in the state of Washington unless otherwise mutually agreed to by all parties. The submission to the American Arbitration Association shall be limited and the arbitration award may be enforced by any court of competent jurisdiction.

BINDING EFFECT OF AGREEMENT

In the event of your death or incapacity, this Agreement shall be effective and binding upon your heirs, next of kin, executors, administrators, assigns and representatives.

ENTIRE AGREEMENT

In entering into this Agreement, you are not relying upon any oral or written representations other than what is set forth in this agreement and User's Guide.





RELATED ITEMS

SST FUSE

SX SUREFIRE SPREADER BAR SHORTY

