



Travel Hair Straightener

SY-PP5

Instructions Manual

WELCOME

Thank you for purchasing the Travel Hair Straightener SY-PP5. In order to fully benefit from this product please read the following instructions carefully and store this user manual in a safe place for future reference.

HOW TO USE THE SY-PP5

Prior to using the new hair straightener, please follow the following instructions for your hair to be straightened in the correct way:

- Wash and towel-dry your hair.
- Comb your hair thoroughly. Do not use hairspray or any flammable chemical hair products.
- Divide the hair into strands. Separate hair strands by using the separation combs to shape the hair strands from below.
- Gradually work along the hair strands to create a uniform hair style.

Switching on the unit

- Insert the mains plug and switch on the device using the On / Off switch.
- It takes approximately 1 minute for the temperature to reach the level set.

Switching off the unit

- Switch off the device using the on / off switch.
- Remove the plug from the socket.
- Let it cool down completely before storing away

Styling Tips

- Use the straightener on dry hair and work with small sections. Hold your hair firmly and begin at the roots, sliding the straightener downwards. Work smoothly to avoid creating tangles in the middle of the section.
- Tip: For short and curly styles, use a spray gel.
- To smooth and tame very curly hair, only use the straightener on the lengths and leave the roots curly. For this kind of style, follow the shape of your hairstyle. The straightening plates can also be used to accent certain sections (fringe, movement etc.)

CLEANING AND MAINTENANCE

- **Danger of electric shock!** Switch off the unit before it is cleaned and pull out the plug.
- **Danger of burns!** It is essential to let the unit completely cool down before storing away.
- Before cleaning, always disconnect the device from the mains.

- Never immerse the device in water or use near places where water is present.
- Device protection! Do not use sharp or abrasive cleaning agents.
- You can clean your device with a slightly damp cloth and dry it with a soft dry cloth.
- If the straightening plates get dirty, use a few drops of washing- up liquid to help clean them. Make sure that you remove all washing-up liquid residues from the straightening plates when drying.

SAFETY

ATTENTION: Do not use this appliance near places where water may be present.

- If using the appliance in a bathroom, unplug after use as the proximity of water can be dangerous even if the appliance is switched off.
- Do not immerse the appliance in water or other liquids.
- Do not use the appliance if the cord is damaged.
- Do not leave the appliance unattended when plugged in.
- Be careful when handling the unit and avoid contact of the hot surfaces of the appliance with the skin, in particular the ears, eyes, face.
- Careful adult supervision is required when the appliance is used on, by or near children or any disabled persons.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
- After use, do not coil the cable around the appliance as this may cause damage to the cable.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- This appliance is intended to be used in household and indoor.

CORRECT DISPOSAL OF THIS PRODUCT



This marking indicates that this product should not be disposed with other household wastes through the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

SPECIFICATIONS

17X70mm White Ceramic plates On/off switch Max temperature: 180 degrees Less than 2 minutes to heat up Uniform heating over plates Indicator light Voltage: 220-240V, 50Hz Power: 20-25W

DECLARATION OF CONFORMITY

Manufacturer Name: Satyatrade S. L. Address: Pol. Ind. La Raya. C/ Guadalquivir, 2. Camarma de Esteruelas, 28816 Madrid Tel: 902 430 967 Fax: 91 8864285 NIF: B83254763 Manufacturing country: China Sytech® SY-PP5 complies with the following directives:

EMC Standard: Directive 2004/108/EC

EN 55014-1:2006+A1:2009 EN 55014-2:1997+A2:2008 EN 6100-3-2:2006+A2:2009 EN 61000-3-3:2008

LVD Standard: Directive 2006/95/EC EN 60335-1:2002+A1:2004+A11:2004+A2:2006 +A12:2006+A13:2008+A14:2010 EN 60335-2-23:2003+A1:2008 EN 62233:2008

ROHS standard: 2002/95/EC Restriction of Hazardous Substance

Signed: Ajeet Nebhwani Utamchandani Sole Administrator

the.