

holi

Quick set-up guide:

- 1) Install you lamp 30 cm (12 inches) from the wall. Plug the USB cable to the charger then the charger to the wall plug.
- 2) Hold the central button for 3 seconds. Holi will start blinking.
- 3) In your iPhone/iPad Settings page, go to Bluetooth and select HOLI
- 4) Download HOLI APP from the APPSTORE

LEGAL NOTICES

Holi® is a registered trademark of FiveFive SAS.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by FiveFive is under license.

“Made for iPod,” “Made for iPhone,” and “Made for iPad” mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance.

iPad, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

SAFETY INSTRUCTIONS:

WARNING: Please read the following safety warnings and cautions carefully to ensure your personal safety and prevent property damage. You should read all the safety and operating instructions before operating this appliance. Retain this handbook for future reference and adhere to all warnings in the handbook or on the appliance.

CAUTION: To reduce the risk of electric shock, do not try to open the device or the Power Supply. There are no user serviceable parts inside. Refer servicing to qualified service personnel only.



The lightning flash with an arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of un-insulated dangerous voltage within the product's enclosure that maybe of sufficient magnitude to constitute a risk of electric shock.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

FIRE AND ELECTRIC SHOCK HAZARD:

- Only use your holi indoor.
- Do not expose your holi to liquid, moisture, humidity or rain. Do not use your holi near any source of water for example next to a bathtub, sink, sauna, steam room, pool. Exposure of your holi to moisture could result in electric shock.
- Take care that objects do not fall and liquids are not spilled into the enclosure through any openings. Liquid filled objects such as vases or bottle should not be placed on or near your holi
- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint or insert foreign objects into your holi. Such actions could result in electric shock.
- Do not use your holi if it has fallen or if the screen is damaged.
- Only use the power-adaptor provided with your holi. Before plugging it to the mains always control that the voltage indicated on the power-adaptor is within range of the mains voltage.
- Locate the appliance away from naked flames or heat producing equipment such as radiators, stoves or other appliances (including other electronic devices) that produce heat. This device is likely to produce heat so you are advised to locate it away from any flammable material or any object that may react to heat.
- Unplug the power supply unit from the mains supply before cleaning.
- Do not leave your holi in direct sunlight for extended period of time.
- If an abnormal smell or smoke is detected from the appliance, turn the power off immediately and unplug the unit from the wall outlet. Stop using it and contact your dealer immediately.
- Holi is designed for use in moderate climates. Do not use when the room temperature is below 10°C (50°F) or above 40°C (100°F).

- Do not place holi on a bed, sofa, rug or similar soft surface, or in an enclosed bookcase or cabinet, since ventilation may be impeded. We recommend a minimum distance of 100 mm (4 inches) around all sides and top to provide adequate ventilation.

FALL HAZARD:

- Only place your holi on a flat and stable surface.
- Do not place your holi on high surfaces such as shelves.

CAUTION:

- The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.
- Do not use abrasive cleaners to clean your holi because this could cause scratches and damage. The case should normally only require a wipe with a soft, damp, lint-free cloth. Do not use paint thinners or other chemical solvents for cleaning or furniture cleaning sprays or polishes as they can cause indelible white marks
- Do not bring your holi in to contact with any sharp objects because this could cause scratches and damages.
- Do not insert anything into your holi. This may damage the internal components.
- Do not attempt to repair, modify, or disassemble your holi yourself, it does not contain any user-serviceable components. Your holi should be serviced by qualified service personnel when A) the power supply cord or the plug has been damaged, or B) objects have fallen, or liquid has spilled into the appliance, or c) the appliance has been exposed to rain, or D) the appliance does not appear to operate normally or exhibits a marked change in performance, or E) the appliance's enclosure shows any sign of damage.
- Do not attempt to replace any light-sources, they are built-in and are not changeable.
- Use only the manufacturer supplied power-supply to connect to your Holi. Other chargers may look similar, but using them could result in electric shock and could damage your holi.
- Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.

EPILEPTIC WARNING:

- A very small percentage of individuals may experience epileptic seizures when exposed to certain light patterns or flashing lights. Exposure to certain patterns or flashlights while using holi, may induce an epileptic seizure in these individuals. Certain conditions may induce previously undetected epileptic symptoms even in persons who have no history of prior seizures or epilepsy.
- If you, or anyone in your family, have an epileptic condition, consult your physician prior to using holi. If you experience any of the following symptoms while using holi -- dizziness, altered vision, eye or muscle twitches, loss of awareness, disorientation, any involuntary movement, or convulsions -- IMMEDIATELY discontinue use and consult your physician before resuming watching.

FCC STATEMENT



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) This device must accept any interference received, including interference that may cause undesired operation.

FCC CAUTION

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

To locate the FCC and IC identification numbers, please look on the underside of your hofl.

EU DIRECTIVES CONFORMANCE STATEMENT



This product has been designed to meet the IEC 60065 international electrical safety standard as well as CE and RoHS regulations.

RECYCLING



The crossed-out wheel bin symbol on the product, literature, or packaging reminds you that all electrical and electronic products, batteries, and accumulators must be taken to separate collection at the end of their working life. This requirement applies to the European Union and other locations where separate collection systems are available. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please do not dispose of these products as unsorted municipal waste, but hand it in at an official collection point for recycling.

WARRANTY INFORMATION

Manufacturer information: FiveFive (RCS Lyon 539 435 388)

37 rue de la Bourse – 69002 Lyon - France

<http://www.myfivefive.com> - contact@myfivefive.com

What is covered

FiveFive warrants this product to be free from defects in materials and workmanship subject to the terms set forth below. FiveFive will repair or replace (at FiveFive's sole option) this product or any defective parts in this product. Repairs or replacements as provided under this warranty are the exclusive remedy of the consumer. FiveFive shall not be liable for any incidental or consequential damages for breach of any express or implied warranty in this product. Except to the extent prohibited by law, this warranty is exclusive and in lieu of all other express and implied warranties whatsoever including, but not limited to, the warranty of merchantability and fitness for a practical purpose. Some countries or US states do not allow the exclusion or limitation of incidental or consequential damages or implied warranties so the above exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other statutory rights.

Duration, validity of warranty and procedure:

Warranty is limited to 2 years but actual duration may vary from country to country or according to local regulations. Consult your dealer or distributor to know the warranty duration in your country. Always ensure that you retain a valid proof of purchase. To benefit from this limited warranty you must send back a proof of purchase and the warranty card enclosed in your product within fourteen days after the purchase.

To obtain warranty service, please contact FiveFive's authorized dealer from which you purchased this product. If your dealer is not equipped to perform the repair of your FiveFive product, your dealer can return it to FiveFive or its authorized service agent. Should you wish to return your product yourself, you firstly need to contact FiveFive to get proper instructions and a return number (RMA). You will need to ship at your cost, in either its original packaging or packaging affording an equal degree of protection. Proof of purchase in the form of a bill of sale or receipted invoice, which is evidence that this product is within the warranty period, must be presented to obtain warranty service

NEED HELP?

VISIT www.MYFIVEFIVE.COM/HOLI

Or contact us support@myfivefive.com

PURCHASE MORE PRODUCTS OR ACCESSORIES AT WWW.MYFIVEFIVE.COM/STORE

BECOME A FAN OF HOLI AND FIVEFIVE ON FACEBOOK OR TWITTER, VISIT [@myfivefive](https://twitter.com/myfivefive)