

## **NEW TECHNOLOGYTM METER**

NTM-0

**Current Loop, Signal or External Powered** 

Replaces: Any 1/8 DIN D.P.M. or A.P. M.



**Note**: See model NTM-B for vertical 1/8 DIN display.



Build Your Own Part Number/User's Manual or Receive a Quote at:

http://www.otekcorp.com/ configurator/nts/

#### **FEATURES:**

- \*Automatic Tricolor Bar with Intensity Control
- \*4 Digits (9.9.9.9 or -1.9.9.9)
- \* InPt FALL Alarm with Run Time Stamp
- \*Self Diagnostics
- \*Isolated Serial I/O
- \*USB/RS485
- \*Configurable Bar Direction (Up/Down/Center Zero)/
- \*Only 100mW@5VDC!
- omy room was v
- \*Intensity Control
- \* Math functions  $(+, -, x, \sqrt{, \div, X}$ -Y tables, polynomials)
- \*Averaging: None to 255
- \*Addressable: 8 Characters
- \*Many Power Input Options

#### (External Powered Models Only)

- \* >30 Isolated Input Signals
- \*4 Relays or O.C.T.
- \*4-20mA/30V Output
- \*Ethernet
- \*µSD Flash Memory: 32 GB
- \*Lifetime Warranty


**DESCRIPTION:** The <u>New Technology Meter (NTM)</u> series combines over 40 years of experience with the latest ASIC uC and ultra-efficient multicolor LED technology to bring you into the 21st century. The **NTM** external power series features over 30 signal conditioners (1" square) which are housed in many industry's standard packages to replace form, fit and function any analog or digital panel meter. If not, we'll make it!

Our patented hardware and firmware gives you the highest reliability (we have a lifetime warranty) at the lowest cost, with features such as: automatic (programmable) tricolor bargraph (like a traffic light); automatic signal fail detect (open or short); indication and serial transmission with run time stamp and units ID, isolated retransmission (4-20mA), and universal power inputs (5-32VDC or 90-265VAC). The **NTM** Series offers several math functions such as X-Y tables, polynomials and log-anti-log functions.

The **NTM** signal and external power series also feature isolated USB, RS485 or ethernet, open collector transistors (4/channel) and SPDT relays (4/channel). You can tell us your custom needs and we'll make it (or might already have it)!

The **NTM-0** is available in either a loop (4-20mA), A.C. signal or external power version. The external powered versions can accommodate 4 relays, isolated DAC and power for the analog output (per channel), include >30 signal conditioners and isolated input power options, as well as ethernet and flash memory (μSD). Standard factory set color changes are: red: <10, >90%, yellow: <20, >80%, green: >20, <80% of F.S. Use digit 14, option 9 for custom configuration (you can change it with simple commands).

#### NEW TECHNOLOGY METER BLOCK DIAGRAM/CHANNEL



520-748-7900

FAX: 520-790-2808

E-MAIL:sales@otekcorp.com http://www.otekcorp.com



4016 E. TENNESSEE ST. TUCSON, AZ. 85714 U.S.A.



## THE PRODUCTS

All New Technology products share the same innovations proven by an independent NQA1 qualifier. The difference between the models is their mechanical features (see Block Diagram and mechanical drawings). Some can only be displays, some can only have 1 channel, some can have relays, DACs, ethernet and flash memory, and some require an external power source. But all products contain the New Technology, which consumes less than 1% of comparable digitals (10-80mW for loop/signal powered versions) and approaches the power consumption of analog meters.

#### WHAT CAN YOU DO WITH OTEK'S NEW TECHNOLOGY?

**Note on Otek's Powerless**<sup>TM</sup> **Technology**: If your signal cannot supply  $\geq 10$ mW ( $\sim 3$ V/3mA), contact us or use external power models.

#### 1. One Channel Models: -0, -4, -B, -D, -F, -L, -M, -N, -P, -S

& -X: Implement any math function, X-Y table (25 point), polynomials (9th order), offset, tare, zero, scale, log & antilogarithmic to affect the unit's display at will. Some examples are: change the display & data using any combination as commanded by your algorithm, such as  $\pm \frac{1}{\sqrt{X}}$  or set a variable or linearize the display using X-Y tables or polynomials. This works well for odd shape containers. You can also change the reading from oF to °C or °K or compress/expand the display (and data out) using the log and antilog functions. In addition, you can change the factory default alarm pointers and colors or delete them. Zero & Span potentiometers are in**cluded** for manual adjustment. **Note:** Models -D and -F only offer internally accessible USB serial I/O for configuration and mathematical functions. Use digit 14 option 9 and specify your custom calibration.

# OTEK's New Technology series is only limited by your needs and imagination. Just give us a call at 520-748-7900 or email us at sales@ otekcorp.com and give us the challenge to develop the best algorithm for your process.

## 2. Two Channel Models: -1, -2, -3 and -5 through -9 &

-A: Note: Also available in models with 3 or 4 channels. Features include all those of the single channel models and each channel is 100% isolated from each other. In addition, you can add, subtract, multiply, divide, find the square root between channels. You can also use one channel to monitor/control the input signal and the second channel to indicate deviation, differential such as PID, alarm override or one channel setpoint can be used to control another channel function. You can also use one channel as a backup if the other channel becomes disabled or use them as volume & flow ( $\sqrt{}$ ) monitors/ controllers. The New Tech**nology** two channel models are also perfect as REM/RAD indicators/controllers (also see our RPM series with logantilog functions for radiation monitoring).

Contact OTEK for algorithms and formulas or any idea you wish to share with our audiences via our Youtube or Facebook page posts.

#### 3. Three Channel Models:

-3, -5, -7, -8 and -A: Note: Also available on 4 channel models -5, -7 & -8. Otek's New Technology three channel models perform all the functions outlined in #1 and #2. Further, one channel can indicate the input variable and the other two channels can be setpoint indicators/controllers (Hi, Hi-Hi, Low and Low-Low limits), or subject the input/ output to any mathematical function or algorithm such as **PID** or display the input vs. output and derivative, or switch scales when the input reaches a limit/band such as for flow-volume-pressure or temperature. Monitor Volts, Amps and Watts AC or DC or any of 3 variables, including Hertz, lead/lag, power factor, peak/valley or for synchronizing of power lines with the bipolar (center zero) tricolor bargraph.

The New Technology series brings Process Automation Control (PAC) within your reach and affordability. These models are compatible with any DCS/SCADA system using their USB/RS485/Ethernet I/O options and allow for ease of interface with wireless systems.

#### 4. Four Channel Models:

-5, -7 and -8: The four channel models offer all of the functions outlined in #1, #2 and #3. However, with the additional channel available, the New Technology barmeters rival flatscreens with superior HMI/MMI functionality and ease of viewing/analysis of any combination of 4 variables. For example, Volts/ Amps/Watts/Hertz or temperature/pressure/pH/humidity. The four channel models can also be used to monitor/control the product of the other 3 variables, making them ideal for the petrochemical industry.

**Data Logging**? Some models offer optional μSD memory to record 24/7 anything available via the serial I/O. Maximum capacity (and growing) is 32 GB!

#### REDUNDANT CONTROL:

Because all channels are 100% isolated from each other, you can use any multi-channels model as a redundant controller. If you need the "Democratic vote," algorithm, contact OTEK or see our Model **TRC** (Triple Redundant Controller).

\_2\_

**520-748-7900** FAX: 520-790-2808

E-MAIL:sales@otekcorp.com http://www.otekcorp.com



4016 E. TENNESSEE ST. TUCSON, AZ. 85714 U.S.A.



#### **Description, Notes & Order (Continued)**

#### Digit 5, Serial I/O & Memory:

Settings: 8N1N, 1200-19,200 Baud, ASCII.

#### LOOP/SIGNAL POWER ONLY:

**Digit 5, Serial I/O: Option 0, USB:** Complies 100% with V2.0 and if digit **10,** option **1** is selected (USB powered) then digit **5** must be option **0**.

**Digit 5, Option 1, RS485**: Complies with industry standard and requires 5VDC@<3mA and a terminating 330 Ohm resistor at first and last unit in the BUS.

#### **EXTERNAL POWER ONLY:**

**Digit 5, Option 2 Ethernet:** Complies with 10 Base-T/100Base-TX RJ45 up to 19,200 Baud. Maximum power consumption is <300mA@5V (1.5W).

**Digit 5, Options 3 & 4: uSD Flash Memory:** Internal μSD flash memory with up to 32 gigabytes capacity. You can store selected data at-will via serial command and download it as required. A 32 GB card logging 3 times per second can hold approximately 4 year's worth of data

Need a Transmitter? See model **TNT** 



#### **DIGIT 6. GRADE:**

Industrial Grade (Options 0 or I) is per these published specifications. Grades M and E per agreed specifications. Option **M & E** typically include an EMI/ RFI shield all around and filtered connectors to meet EPRI-TR-102323-R3 (requiring ~2" deeper case). OTEK will build to certain nuclear or MIL-Standards but testing and confirmation of compliance, if required, will need to be done by third party and at customer's expense. Option **0** is 94VO plastic, option "I" is aluminium nickel plated to Mil-Specs. Typical Mil-Specs: 461, 462, 169, 901, 801, RTCA-160, I EEE344, etc.

#### **Other Important Data:**

**Math Functions:** +, -, x,  $\div$ ,  $\sqrt{}$ , Polynomials to 9th order, 25 Point X-Y table, zero, offset, span and tare. You can add, subtract, multiply, divide (etc.) one channel to/from another channel and display the result in the other channel (i.e. V (Ch.1)xA(Ch.2)=W(Ch.3).

**Signal Failure Alarm:** Requires approximately 1 minute of normal (midscale) operation for it to alarm the display and output the serial data after the signal (Powerless<sup>TM</sup>) has ceased.

Serial I/O: Setting: 8N1N, 1200-19,200 BAUD, 8 Character Address

**PID:** Programmable (best with >dual channel models) automatic or manual with external 10K Ohm potentiometer (option **56**).

#### **Other Important Data: (Continued):**

**High Quality:** No matter their size or number of channels all use the same (SV & V) firmware, hardware and commands. No matter their grade (Industrial, Mil-Spec, Nuclear) they all carry a **lifetime warranty** 

## **Industrial Grade Common Electrical Specifications**

#### **Input & Display:**

\*A/D: Accuracy, Linearity & Resolution: +/- 0.05% of F.S. 12 Bits, Conversion Rate: 40/sec, Averaging: 0-255, zero, span, offset, tare, math functions, 25 point X-Y tables & polynomials (9<sup>th</sup>)

\*Bargraph: 51 Automatic Tricolor (R/Y/G) Segments

\*Digits: Four Full Digits (9.9.9.9 & -1.9.9.9).

\*Typical Power Consumption of Display: 10-80mW@3.3V

\*Temperature Coefficient:

+/-50PPM/°C

\*Operating Temperature: -10 to +60; Storage: -20 to +70°C

\*CCMR: >90dB@50-60Hz

\*Isolation: >500VDC to any other I/O & P.S.

\*Humidity: 5-95% RH non-condensing

\*Front Panel: NEMA 3. NEMA 4x on request.

\*Failed Signal Detect: ~ 20 seconds after > 1 minute "On" @50% of F.S.

**Note 1:** See page 13 of the master catalog for environmental specs vs. housing, bar length and digit size.

**Note 2**: E and M grades are the same as Industrial unless otherwise specified.

-3-

**520-748-7900** FAX: 520-790-2808 E-MAIL:sales@otekcorp.com http://www.otekcorp.com



4016 E. TENNESSEE ST. TUCSON, AZ. 85714 U.S.A.



### Industrial Grade Common Electrical Specifications (Continued)

## AVAILABLE ON EXTERNAL POWER MODELS ONLY:

#### **Outputs:**

\*Analog Output: Accuracy & Linearity: ±0.1% F.S.; ±0.1 LSB, Range: 3-24mA (max. load: <1K Ohm).

\*Analog Output Temperature Coefficient: +/-50PPM°C

\*Analog Output Isolation To All Other I/O & Power: >500VDC

\*Relays: 4 Each/Channel (except P and TNT {2}): SPDT Form C, 1A Max @ 120VAC/30VDC resistive load only, Contact Protection: 300VAC/DC on all contacts. Speed: +40mS (main loop).

O.C.T. (Open Collector Transistors): VCE Max: 30VDC; Ice Max: 30mADC, Speed: +40mS (main loop).

**Note 1:** Relays & O.C.T. P.O.D. (~100 mS) and can be set for fail safe operation (normally on).

**Note 2:** See Digit 11 for default set points and User's Manual for command set via serial control.

#### SEE CUSTOMIZED USER'S MANUAL FOR SPECIFIC CONNECTIONS AT:

http://www.otekcorp.com/ configurator/nts/

#### **INPUT SIGNAL SPECIFICATIONS (Digits 8 & 9)**

#### INPUT SIGNALS (Digits 8 & 9):

<u>Note</u>: Otek's exclusive <u>Input Fail</u> detect (open or short) is standard on all inputs. Use option 29 and specify if you want it disabled (also field configurable).

<u>Important Note</u>: Actual connection will vary. See the User's Manual or the NT Catalog for specific connection information.

Option 00 For Loop Power Only: Option 00, Loop Powered: Burden: < 4V; Range: 3-26mA; Accuracy & Linearity: ±0.05% of F.S.

## Options 01 through 14 for A. C. <u>Signal Powered Only</u>

Important Note: C.T. are sensitive and limited to the secondary (output) impedance. OTEK A.C. signal powered products present and input impedance of ~0.2 Ohms (~1v@5A). Make sure your C.T. can drive a >0.3 Ohm load without saturating or losing linearity. Contact Otek for assistance. Best C.T. to use: >100:5.

**Option 01, VAC (P.T.):** Burden: <100mW; Range: 30-150V/40-100Hz; Accuracy & Linearity: ±0.2% of F.S. Best operating range to specification: 90-150VAC.

**Option 02, 5 AMP A.C. (C.T.):** Burden: <100mW; Range: .3-5A; Accuracy & Linearity: ±0.2% of F.S. Best operating range to specification: 1-5 Amps.

Option 03, Watts A.C. (C.T. &

**P.T.):** Burden: <100mW, Range: >30<750W/50-60Hz; Accuracy & Linearity:  $\pm 0.2\%$  of F.S. at 90-140VAC & 1-5AAC. Worst case:  $\pm 3\%$  outside this range. Best operating range to specification: 100-500 Watts.

Option 04, Hertz VAC: Burden: <100mW, Range: >30V<150V & >30<500Hz; Accuracy & Linearity: ±0.2% of F.S.

**Option 05-14:** Same as options **01** through **04** above.

## AVAILABLE ON EXTERNAL POWER ONLY

Option 20: 4-20mA: The burden on the loop is only 0.5V@20mA (25 Ohm) and you can use the math functions for converting to flow, instantaneous or totalizer.

Accuracy:  $\pm 0.1\%$  of F.S.

<u>Options 21-24:</u> VDC: Input impedance is 1 Mega Ohms on all VDC ranges.

Input impedance 1M  $\Omega$  Range: Per Option

Accuracy & Linearity: ±0.05% of F.S.

Options 25 & 26, mADC: Since the NTM is 2V full scale (2,000 Counts) the "Shunt" resistors used are 100 Ohms for 10mA and 10 Ohms for 100mADC.

Input impedance **25**:  $50\Omega$ ; **26**:  $5\Omega$ ; Accuracy & Linearity:  $\pm 0.05\%$  of F.S.

#### Option 27, Watts DC:

VZin:  $10M \Omega/AZin$ :  $1.0\Omega$ , 5W

Range: 1W

Accuracy & Linearity: ±0.1% of F.S.

#### Option 28, Watts DC (1Vx1V):

VZin: 1M for both inputs

Range: 0-1V

Accuracy & Linearity: ±0.1% of F.S

-4-

520-748-7900

FAX: 520-790-2808 E-MAIL:sales@otekcorp.com http://www.otekcorp.com



4016 E. TENNESSEE ST. TUCSON, AZ. 85714 U.S.A.



## INPUT SIGNAL SPECIFICATIONS (Digits 8 & 9)

#### AVAILABLE ON EXTERNAL POWER MODELS ONLY

Option 29: Custom: Use this option to describe any custom input, scale or modification to the <u>NTM</u> and contact us for feasibility and cost.

Options 30-34, Volts RMS: Here we use a <u>True RMS-DC</u> Converter for accurate ( $\pm$  0.1%) measurement of sine waves up to 10KHz. For 10-20KHz and SCR accuracy is  $\pm$  1%.

VRMS: Zin:  $1M\Omega$  Range; per options;

Accuracy & Linearity: ±0.1% of F.S.

Options 35-37, Amps RMS: We use a True RMS-DC Converter for accurate  $(\pm 0.1\%)$  measurement of sine waves up to 10KHz. For 10-20KHz and SCR accuracy is  $\pm 1\%$ .

Zin: **35** (**1A**):  $2\Omega$ ; **36** (**1A**):  $0.2\Omega$ ; **37**: 0.(0.1A)  $04\Omega$  (Range: Per option Accuracy & Linearity:  $\pm 0.1\%$  of F. S.

#### Options 38 & 40, Watts RMS:

Here we use a <u>True RMS-DC</u> Converter for accurate ( $\pm$  0.1%) measurement of sine waves up to 10KHz. For 10-20KHz and SCR accuracy is  $\pm$  1%. Input impedances vs. range are the same as for VDC & mADC ranges.

#### Option 38 (1Vx1VAC):

Zin:  $1M\Omega$  for both inputs Range: 1V

KIVIS

Accuracy & Linearity: ±0.2% of F.S.

**Note:** Always use P.T. & C.T. for options 33, 34, 40, 42, 43 and 44.

#### **Option 40 (120VACx5AAC C.T.):**

Zin: 1M for V &  $0.04\Omega$  for I

Range: 0-750W

Accuracy & Linearity: ±0.2% of F.S. **Note**: Option 40 (120V/5A) includes the shunt (0.04 Ohms/20W) on connector only for 5A C.T.

Options 41-44, Hertz: We use an F-V to accept frequencies up to 20KHz and amplitudes from 1-400V peak or dry contact or open collector transistor (O.C.T.). For 50 to 440 Hz power line frequency measurement, use Option # "44."

#### Option 41 (10KHz/5V Logic):

Zin: 1M

Range: 30-10KHz

Accuracy & Linearity: ±0.1% of F.S.

#### Option 42 (120V, 40-100Hz):

Zin: 1M

Range: 50-150VC/30-100Hz Accuracy & Linearity: ±0.1% of F.S.

#### Option 43 (240V, 30-100Hz):

Zin 1 M; Range: 100-260V/30-100Hz Accuracy & Linearity: ±0.1% of F.S.

#### Option 44 (120V, 500 Hz):

Zin: 1 M

Range: 50-150V/300-500Hz

Accuracy & Linearity: ±0.2% of F.S.

Option 45: Strain-Gage (≥300 < 4K Ohm): These are typically "Monolithic" S-G that require constant voltage (preferably) excitation. We use 4.096V for high stability and accuracy. Use option 29 and specify your S-G sensitivity and the NTM display at Zero and Full Scale.

Excitation: 4.096V, 50 PPM/°C

Range:  $\pm 300\text{-}4\text{K}\ \Omega$ 

Accuracy & Linearity: ±0.1% of F.S.

Note on S-G: Some S-G offer +/-1VDC or 4-20mA condition output. Use Option 29 and specify.

#### **Option 47: RTD (PT100): Note**:

For options 47 & 48 you can change °C to °F and RTD type via serial port.

We excite your 2 , 3 or 4 wire RTD with  $200\mu A$  to avoid the "self heating" effect. The range of the <u>NTM</u> is the same as your <u>RTD</u> typically  $-200^{\circ}C$  to  $+800^{\circ}C$  ( $-328+1562^{\circ}F$ ). You can place the decimal point at will (typically -200.0 to 800.0. The <u>PT100</u> has a temperature coefficient of 0.00385 Ohms/Ohm/ $^{\circ}C$ . (For legacy 0.00392 TC (known as ANSI 392) contact **OTEK** and use Option "29".

Accuracy:  $\pm 0.5\%$  of F.S. plus sensor's error.

Note: For 2 wire, jump - S to -E and +S to +E. For 3 wire only jump -S to -E.

-5-



E-MAIL:sales@otekcorp.com http://www.otekcorp.com







#### AVAILABLE ON EXTERNAL POWER MODELS ONLY

Option 48: RTD (PT1000): Same as PT100 except it is 1000 Ohms at 0°C instead of 100 Ohms @ 0°C. The same technique is used for copper RTD (10 Ohm), contact OTEK. Same connection as Option 47 apply.

Accuracy:  $\pm 0.5\%$  of F.S. plus sensor's error

**Note**: For long distances (> 300') use a 4-20mA transmitter such as our model **TNT** from our **N**ew **Technology** series.

Option 50: Thermocouple (Type J): This TC has a range of -210 to +760°C (-350 + 1390°F). Its color is white (+) and Red (-), cold junction (CJ) is at the connector. Make sure the connections from the NTM and your TC are as close to the NTM entrance as possible to avoid errors. If you short out the NTM will read the ambient temperature at the junction due to its

**Note:** You can change °C to F and TC type via serial port.

built-in C.J.C.

Accuracy:  $\pm 2^{\circ}$  F.S. of signal input.

Option 51: TC (Type K): This is yellow (+) and red (-) and has a range of -270 + 1370°C (-440 + 2500°F). The same notes as Option 50 apply.

Accuracy: + 1° F.S. of signal input

Option 52: TC (Type T): This blue (+) and red (-) TC has the range of  $-270^{\circ} + 400^{\circ}$ C (-440 + 750°F). Same notes as Option 50 apply.

Accuracy:  $\pm 2^{0}$  F.S. of signal input.

**Option 53: pH (Acidity):** We use a FET input ( $10^{15}$ ) amplifier and calibrate the **NTM** for 0-14.00 pH using the Industry's standard  $\pm 413$  mV =  $\pm 7$ pH co-efficient.

Note: Not temperature compensated, contact OTEK for auto temperature compensation.

Accuracy: ±0.05% of F.S.

Option 54: ORP (Oxygen Reduction Potential): Our FET amplifier (10°) accepts the industry standard 2000mV F.S. of the probe and the NTM displays it in % (0-100.0%).

Accuracy: +0.05% of F.S.

Option 55: %RH: This conditioner is designed to interface to a typical (capacitance type) 2-3pF/% of RH made by several manufacturers. Use Option "29" and contact OTEK to specify your sensor's specifications.

Accuracy: + 0.05% RH of signal input.

Need the Transmitter?

DRT

CTT TNT Option 56 Resistance (0-10K Ohm):

Want a simple 4-20mA transmitter? Just connect a 10K Ohm (others on request) potentiometer to the **NTM** and control any 4-20mA input valve, motor, transducer, etc. Accuracy & Linearity is ±0.1% of F. S. Standard Calibration: 0-10K Ohms=4-20mA. Use option #29 and specify your calibration. Ideal for linear transducers.

Option 58: Serial Input Remote Display/Controller: Here you can use the unit as a remote display & controller with modified ASCII to alpha-numeric display for DCS SCADA, PLC systems.

See the user's manual for simple commands to use the <u>NTM</u> in PAC (Process Automation Control) applications.

If You Don't See It Ask For It!



-6-

**520-748-7900** FAX: 520-790-2808

E-MAIL:sales@otekcorp.com http://www.otekcorp.com



4016 E. TENNESSEE ST. TUCSON, AZ. 85714 U.S.A.



**Digit 10 (Power Input):** 

#### **LOOP & SIGNAL POWER ONLY:**

**Digit 10, Option 0, Powerless, No Power Required:** The **Input Fail**detect/Alarm (patent pending) flashes
the display "INPT FAIL" (InPt
FRIL)" and transmits this serial message for ~20 seconds, after which it
will cease. This feature is available
in all Powerless<sup>TM</sup> models. If desired,
use option **9** on Digit **14** and specify
"input fail detection." Signal Fail
Requirement: Unit must be "On" for
at least 1 minute at >50% of full scale
for it to operate.

#### **EXTERNAL POWER ONLY:**

Digit 10, Option 1, USB Powered: The NTM series requires > .1<1.5 Watts/Channel (worst case, fully loaded) meaning that you can power it through the USB port, but this option eliminates the isolation from USB to input signal. Analog output remains isolated contact OTEK for more details or use options 2-4.

**Digit 10, Option 2, 5VDC:** 5VDC is used to drive the relays (<50mA/relay) and/or the DAC via internal isolated 5-30VDC-DC (<200mA). If you order relays and analog out, you will need ~300mA/channel. This option is also isolated from the input signal.

**Digit 10, Option 3, 7-32VDC:** Same as option **2** but with wide input range of 7-32VDC. Efficiency: >80%.

**Digit 10, Option 4, 90-265VAC:** This option accepts 50-60Hz. For 100-300VDC or 400 Hz, use Digit **10**, option **9** and specify. Efficiency: >80%.

**Digit 11 (Control Outputs):** 

## AVAILABLE ON EXTERNAL POWER ONLY

Digit 11, Control Outputs: Option 1: Open Collector Transistors (O.C.T.): They are NOT isolated from each other (common emitter) but are isolated between channels and can sink a maximum of 30 mA and sustain a maximum of 30V<sub>CE</sub> (the O.C.T. are normally used to drive S.S.R.). When you order option 2 (Relays), we use the O.C.T. to drive the relays.

**NOTE**: You can use the internal isolated 5VDC power to drive loads with the O.C.T. Total maximum current available is 50mADC.

**Digit 11, Option 2: Relays:** are S.P.D.T. (1C) and can switch maximum resistive loads of 1 Amp @ 120 VAC or 30 VDC. They include 300V varistors at their contacts; inductive loads must be attenuated by the user.

#### **AUTOMATIC BAR COLORS:**

**Limits/Colors Factory default** (% of Full Scale): Also see digit 14.

**Low-Low Limit** (<**10%**): Red Bar, OCT1/K1 "ON"

Low Limit (<20%): Yellow Bar, OCT2/K2 "ON"

**High Limit (>80%):** Yellow Bar, OCT3/K3 "ON"

**Hi-Hi Limit (>90%):** Red Bar, OCT4/ K4 "ON"

**Digit 11 (Control Outputs): (Continued)** 

**Safe Area** (>20<80%): Green bar will follow signal input and if outside the limits, it will change its color to the limit's color (yellow or red).

See commands in the user's manual to customize your bargraph colors.

For other configurations, use option **9** on Digit **14** (field configurable). Max power consumption per relay: 50mA@5VDC (0.25W). See Digit **14**.

**External Control:** You can control the O.C.T./Relays via the serial port at will with simple commands. They don't have to be assigned to the bar colors/set points, but are by default.

#### Notes:

1. Digit 11 is governed by Digit 7 (# of Channels) & Digit 4 (Housing).

Reason: Digit 11 can NOT have more channels than permitted by Digit 7 or it cannot fit in the housing (Digit 4).

<u>Note</u>: Some models only offer 2 relays (see the ordering information). You can assign any relay to any limit.

SEE CUSTOMIZED USER'S MANUAL FOR SPECIFIC CONNECTIONS at:


http://www.otekcorp.com/configurator/nts/

\_7\_

520-748-7900

FAX: 520-790-2808 E-MAIL:sales@otekcorp.com http://www.otekcorp.com







#### **Description, Notes & Order (Continued)**

#### **Digit 12 (Analog /Power Output): AVAILABLE ON EXTERNAL POWER ONLY**

#### Digit 12, Analog Output, Option 1:

This isolated output is factory set to follow the input (0-F.S. in=4-20 out) but can also be set for other outputs or serially controlled by simple commands via the serial port. For other outputs, use option 9 and specify, including reverse scale (4-20=20-4), bipolar and PID. Power consumption: 200mA@5VDC (1W). Accuracy & Linearity:  $\pm 0.5\%$  of full scale.

**Analog Output External Control** (Use Option 9 and specify): A) 0-100mVDC in=4-20mA out; B) 0-10K Ohm in=4-20mA out; C) Use options 58, 68, 78 or 88 and control it via serial port.

#### Digit 12, 30 VDC Out, Option 2:

Use this option to power your 4-20mA transmitter or other transducer. Maximum current is 25mADC. It's isolated and is the same power source we use for 4-20mA out. Power consumption: 200mA@5VDC (1W)/channel.

1. This digit 12 is governed by digits 4 (Housing) & 7 (# of Channels). Reason: Digit 12 cannot have more outputs than input channels (Digit 7), which is governed by Digit 4 (Housings).

#### Digit 13 (Scale Plate):

**Digit 13, Scale Plate:** Option **0** is a standard scale plate that reads 0-100%. Use option 9 for custom printing and contact Otek.

#### **Digit 14 (Range/Calibration):**

**0**= Factory Default: 0-Full Scale Input =0-100% bar and 0-100.0 digits. Colors: <10>90%: Red; <20>80%: Yellow; >20<80%: Green. Use Option 9 (custom) and contact Otek. Also see Control Outputs (Digit 11).

Bargraph Default: 0-full scale=0-100%. You can program it for single pointer, or three or five bars via the serial port.

> Need Explosion Proof? See Model NTM-X



#### ABOUT OUR INPUT FAIL DETECTION

Only available on Powerless<sup>TM</sup> models. While in normal operation, we store excess energy and use it to power the NTM if and when the signal fails (post mortem).





Need a Transmitter? See model NTT



-8-

520-748-7900 FAX: 520-790-2808

E-MAIL:sales@otekcorp.com http://www.otekcorp.com



4016 E. TENNESSEE ST. TUCSON, AZ. 85714 U.S.A.

> MADE USA



#### NTM-0 LOOP POWER VERSION ORDERING INFORMATION 5-18-15

#### 1 CHANNEL **LOOP** POWERED DISPLAY **NOTES:** NTM-0 1. USB I/O is powered by VUSB. OTEKS SPM/BDM 1/8 DIN Case RS485 requires 5V@~3mA. 2. Otek will build to certain nuclear or MIL-Standards but testing and confirmation of compliance, if 5 6 7 8 9 10 11 12 13 14 required, will need to be done by NTM-0 - - 0 0 0 - 0 0 a third party and at customer's RANGE/CALIBRATION expense. SERIAL I/O (1) -0.....Standard 0.....USB-└9.....Custom (Contact OTEK) 1.....RS485-9.....Custom (Contact OTEK)-SCALE PLATE -0.....Standard (0-100%) GRADE & CASE (2)\* └9.....Custom (Contact OTEK) 0......Industrial & Plastic-I.....Industrial & Metal ANALOG/POWER OUTPUT M.....To Mil-Spec & Metal (Contact OTEK) -0.....None E.....To Epri-Nuclear & Metal (Contact OTEK) 9.....Custom (Contact OTEK) **CONTROL OUTPUTS** # OF CHANNELS -0.....None \*Grades E, M & 9 1.....One might require an 9......Custom (Contact OTEK) POWER INPUT N.R.E. fee. -0.....Powerless<sup>TM</sup> (No Power)

#### NTM-0 SIGNAL POWER VERSION ORDERING INFORMATION 5-18-15

#### NOTES:

1. USB I/O is powered by VUSB. RS485 requires 5V@~3mA.

INPUT SIGNAL

00......4-20mA, All Channels=Input, Loop Power -

2. Otek will build to certain nuclear or MIL-Standards but testing and confirmation of compliance, if required, will need to be done by a third party and at customer's expense.

3. For other ranges and inputs or powered versions, see the external power model.

\*Grades E, M & 9 might require an N.R.E. fee.

#### 1 CHANNEL **SIGNAL** POWERED DISPLAY

OTEKS SPM/BDM 1/8 DIN Case

NTM-0

ance, done omer's	$ \begin{array}{ccc} 5 & 6 & 7 \\ \mathbf{NTM-0} & \square & \square & \square \end{array} $	8 9 10 - 🖵 🖵 🖸	<b>P</b> - <b>P P P</b>
outs or external	SERIAL I/O (1) 0USB— 1RS485— 9Custom (Contact OTEK)—		RANGE/CALIBRATION  -0Standard  -9Custom (Contact OTEK)  SCALE PLATE
ITo Epr	SE (2)*		
1		· —   : —	POWER INPUT 0Powerless™ (No Power)

-9.

**520-748-7900** FAX: 520-790-2808

E-MAIL:sales@otekcorp.com http://www.otekcorp.com



4016 E. TENNESSEE ST. TUCSON, AZ. 85714 U.S.A.



#### NTM-0 EXTERNAL POWER VERSION ORDERING INFORMATION 5-18-15

**NOTE:** Please READ BEFORE building part number:

1. If digit 10 is option 1, then digit 5 must be option 0 or 3. USB I/O is powered by VBUS (3mA). RS485 requires 5V@~3mA.

\*Grades E, M & 9 might require an N.R.E. fee.

#### 1 CHANNEL **EXTERNAL** POWERED CONTROLLER

NTM-0

OTEKS SPM/BDM 1/8 DIN Case

mA). RS485 5 6 7 8	9 10 11 12 13 14
NTM-0 ☐ ☐ ☐ - ☐	
SERIAL I/O (1)  0	RANGE/CALIBRATION  -0Custom (Contact OTEK)  SCALE PLATE  -0Standard (0-100%)  -9Custom (Contact OTEK)
9Custom (Contact OTEK)	7Custom (Contact OTEK)
GRADE (2)*  0	ANALOG/POWER OUTPUT 0
# OF CHANNELS (3) 1One — 9Custom(Contact OTEK)  INPUT SIGNAL (3)	CONTROL OUTPUTS 0
204–20mA (All Channels Same Input) 21100mV DC F S	POWER INPUT (1)
22	1Non-Isolated USB
2310VDCF.S.—	
24100VDCF.S.—	3Isolated 7-32VDC
2510mADC F. S.	4Isolated 90-265VAC
26100mADC F.S.	9Custom (Contact OTEK)
27Watts DC (1Vx1A)F.S.——	i '

31.....1V RMS F.S.

.....RTD(PT100)-

48......RTD (PT1000)-50.....TC (Type J)-

51.....TC (Type K)

52.....TC (Type T)

53.....pH (0-14.00) 54......ORP(0-2000mVDC)

55.....% RH (Specify Sensor)-

 Build Your Own Part Number/Receive a Quote at:


http://www.otekcorp.com/configurator/nts/

#### **NOTES** (Continued):

- 2. Otek will build to certain nuclear or MIL-Standards but testing and confirmation of compliance, if required, will need to be done by a third party and at customer's expense.
- 3. For 400 Hz line, use option 29 and specify input. Peak & Hold to 50KHz function on request.



#### NTM-0 MECHANICALS AND TYPICAL CONNECTIONS



#### SEE CUSTOMIZED USER'S MANUAL FOR SPECIFIC CONNECTIONS at:

http://www.otekcorp.com/configurator/nts/



-11-

**520-748-7900** FAX: 520-790-2808 E-MAIL:sales@otekcorp.com http://www.otekcorp.com

