

Etekcitcity® M535 Wired Optical Mouse

User's Manual

The Etekcitcity® wired optical mouse is a great choice for personal or business use. Ergonomically designed and featuring a moveable thumb rest, it minimizes hand fatigue for all-day comfort. Featuring adjustable DPI sensitivity and back/forward buttons, this mouse is a practical and attractive upgrade to your computer's peripherals.

Compatible with: Windows XP/Vista/7/8, Mac OSX

Operating instructions

- Connect the USB plug to any available USB port on your computer.
- Wait until the computer automatically recognizes and installs the mouse.
- That's it! You should now be able to use your new mouse.

Installing driver software (Windows PCs): To activate the cursor-center function or reconfigure the other buttons, you need to install the driver and software from the included CD.

- Insert the CD into your computer's disc drive, open the disc contents, and run the setup program. Follow the on-screen prompts to install the mouse driver and software. When finished, you can run the program to change the function of the mouse's buttons.
- Several preset functions may be selected from in the drop-down menu for each button. You can use the "Single Key" or "Combo Key" to map any key or combination of keys to a mouse button.
- **The software is also available for download:** <http://tinyurl.com/etekcitym535>

Cursor-center: Once the driver/software is installed, the button on the top of the mouse marked with a cursor icon will cause the cursor to snap to the center of the screen. Simply press the button whenever you wish to relocate the cursor to the center of your display.

DPI: Press the button labeled 'DPI' on the top of the mouse to switch between sensitivity modes. The modes are indicated by a change in the color of the pulsing light on the thumb rest: green (1000 DPI), red (1500), blue (2000), and purple (3000).

Thumb rest: To adjust the thumb rest depth, press and hold the button on the bottom of the mouse labeled 'PRESS'. The thumb rest should pop out to its furthest depth. While holding the 'PRESS' button, move the thumb rest to the desired position, and then release the 'PRESS' button. The thumb rest should lock into place.

By default, the thumb rest buttons will perform back and forward functions for use in a web browser or file explorer. The '<' button toward the front of the mouse will go back a page, and the '>' button toward the back will go forward a page. Use the included software to reconfigure these buttons if desired.

Specifications

- Interface: USB 2.0/3.0
- Cable length: 5ft.
- Sensitivity: 1000/1500/2000/3000 DPI
- USB report rate: 500Hz
- Size: 118 x 84 x 44mm
- Keystroke life: ≥10 million clicks
- Power: 5V ≤100mA