



Kickr I™ User Manual

Technical Specifications

Configuration

1 panel solar charger with regulated USB output

Power

1.75 Watt photovoltaic unregulated,
1.5 Watt, 5 Volt System regulated
0.3 Amp output

Dimensions

Size 215.9 mm x 190.5 mm x 18mm
Weight: 159g (0.35lb)

Cautions and Warnings

- Avoid immersion in water. If water is splashed on the modules, dry them immediately with a dry cloth or towel.
- Avoid splashing water in or around the USB box area. If exposed to water, immediately shake or blow water from the box.
- Do not bend or crease the modules
- Avoid partially shading modules under load to prevent reduction in power.
- Artificially concentrated sunlight (i.e. with a magnifying glass or by other means) shall not be directed onto the modules.
- Do not cut, scratch, or puncture the modules, hinges, or end terminal.
- Do not stand on or walk on the modules or end terminal.
- Do not drop or allow objects to fall onto the modules, hinges, or end terminal.
- Do not attempt to open, or otherwise dismantle the USB box.

Apple™ Product Warning

When charging Apple™ consumer devices (i.e. iPods, iPhones, iPads, etc.), a time-out will occur when the Kickr does not receive direct sunlight onto its panels. This will result in an incompatibility message on your Apple™ product. To resume charging, please unplug and re-plug the unit into the Kickr.

What Can EnerPlex Kickr™ I Do?

The EnerPlex Kickr™ I can charge most devices that are USB enabled, such as smartphones. For best results, we advise that you use the Kickr product to re-charge power banks (i.e. batteries) and then use the power bank to pow-

er or re-charge your USB device such as a smartphone. Some examples:

- Jumpr™ Mini 1,350 mAh battery ~ 7 hours
- Jumpr™ Stack 4,800 mAh battery ~ 9 hours
- Jumpr™ Classic 4,000 mAh battery ~ 21 hours

Getting Started

1. Firmly connect the charging cord from the device you are charging into the USB port on the EnerPlex Kickr™ I.
2. Place the unit you are charging in the provided pouch on the Kickr™ I.
3. For best results, position and angle your EnerPlex Kickr™ I in a location where it will receive maximum exposure to the sun
4. When finished charging, disconnect the charging cord from the USB port.

Other EnerPlex Gear: See the latest at www.goenerplex.com