
User Manual - English:

Art. No. 71.613

Mini Party Set

General Instructions:

- Also read Safety Instructions before use!
- Ideal for Disco Parties
- works on 3pcs AA batteries (not incl.)
- 71.613 includes: > Rotating Disco Light
 - Rotating Police / Disco Light
 - Rotating Mirror / Disco Light



Connecting Power to Operate:

- Remove the battery cover
- Fit 3 pcs of AA (1,5V) batteries per product to ensure the correct polarity
- Covering the batteries as well as turning on the switch

CAUTION:

- Put the Disco Lights on a Flat and Firm Place
- Indoor Use only!
- Plastic Construction
- Do not attempt to replace the LED bulbs
- Keep Battery Box dry
- Keep away from Children and Animals

Technical information:

Voltage: 4,5 Volt per Product



Manufacturer / Supplier will not be liable in the event that personal injury or consequential damage results from failure to observe these safety guidelines and the incorrect use of the device.













