


Qual

**GTR Multifunctional Model Car
Bluetooth Speaker**



User Manual

Thank!

Thank you for purchasing this GTR Bluetooth Speaker.
This product is the newest generation of Bluetooth stereo speakers
which can provide you high quality bass effect and musical pleasure.




Cautions

- Before using this product, please read this part and the rest of the instruction sheet thoroughly, to ensure safety and proper usage.
- Be careful with the product's edge, concave and convex parts, metal parts and packaging materials to avoid any possible damage or injury.
- Do not place this product at where children and infants can access or touch, and avoid the product or part of the product being put into their mouths.
- Do not try to open or fix the product by yourself during the warrantee period.
- Do not use alcohol, thinner or volatile liquid to clean or wash the product. The product should be placed in a dry and ventilated environment.
- Do not put this product in a hot and humid environment(such as bathroom).
- Do not insert any items such as pins into the product.
- Keep your hand dry when you use this product to avoid electric shock.
- Avoid colliding the product with other objects.
- Do not use this product in a dangerous environment.
- Immediately stop using this product when unexpected occurs.




Package Contents

- GTR Bluetooth Speaker
- Gas station power adapter




D

Main Part Diagram / Front




D

Main Part Diagram / Back



D

Main Part Diagram / Mic & Speaker




F

G


D

Main Part Diagram / Car top



D

Main Part Diagram



D

Main Part Diagram

- A** Main switch
- B** Signal Light (Blue Tooth Pairing Indicator)
- C** Headlight (Work Status Indicator)
- D** Tail Light(Charging Indicator)
- E** Fuel Tank Cover (Charging Hole)
- F** Mic
- G** Speaker
- H** Car Top (Play, Pause, Pickup Call, Hang up, Bluetooth Sensing)
- I** DC Plug
- J** Battery Indicator
- K** AC Plug



Operating Procedures

- Turning on and Bluetooth automatically pairing- Switch on electricity, then engine will sound off and the two Headlights(white) will flash slowly. Bluetooth will be automatically turned on after activation. If no mobile phone's Bluetooth is detected within 15 seconds, Bluetooth Speaker will automatically get into pairing status. Then Headlights(white) and Signal Lights(red) will flash alternately.
- Manual Bluetooth pairing status: Switch on electricity, wait till the engine sound finishes. After a "De" sound, push the Car Top till the Headlights (white) and Signal Lights(red) flash alternately. If so it indicates the Bluetooth Speaker is in Bluetooth pairing status.
- Connect a mobile phone to the Bluetooth speaker: Turn on your mobile phone and its Bluetooth searching. Find "GT-R" and connect. Password is "0000". Once connection is done, the Headlights(white) are on.
- Play music: Turn on mobile phone's music player, Bluetooth Speaker will play the music. Tab the Car Top to pause and tab again to play again.
- Pick up call: When there is incoming call, tap the Car Top to pick up the call. Tap the Car Top again to end the call. During music playback, tap the Car Top to pick up a call and music will resume playing after the call ends.



Operating Procedures

- Charging: 30 seconds after Bluetooth Speaker is on, if you hear “Dong, Dong” sound it means its battery level is low. Please charge it as soon as possible. To charge, connect the AC Plug to your AC supply, then open the Fuel Tank Cover and plug in the DC Plug. When the battery is being charged, the Tail Lights show red and the Battery Indicator on the Gas Dispenser flashes a diagram that shows the battery level charged. Once the battery is full, the red Tail Lights are off and the Battery Indicator shows static, full battery diagram.



Product Specifications

Item	Specification	Remarks
Sound	Built-in Stereo System	
Speaker Power	2 x 3W	
Frequency Response	150Hz -20kHz	
Speaker	40mm / 4Ω	
Signal-To-Noise Ratio	> 75dBA	
Distortion (%)	< 1.0%	
Max play Duration	About 10 hours	
Battery Type	Lithium Battery	
Battery Capacity	1200mAh	
Charging Voltage	4.2V ±0.05V	
Charging Duration	5V x 2hour	
Weight	713g	
Size	260mm x 105mm x 80mm	



Frequently Asked Questions

Why does the Bluetooth Speaker show “low battery” when I turn it on?

Make sure battery is fully charged. Before turning it on for the first time please charge it for more than 8 hours till the red Tail Lights are off.

Why does the Speaker have no sound after Bluetooth has finished pairing up?

First please check if your equipment has successfully paired up with the Bluetooth Speaker. Then let them do the pairing again.

Why is there “Dong, Dong, Dong” sound during music playback?

When battery level is lower than 3.3V, “Dong, Dong, Dong” occurs. Please charge the Speaker immediately.

When battery level is lower than 3.3V, “Dong, Dong, Dong” occurs. Please charge the Speaker immediately.

Make sure battery is fully charged. Before turning it on for the first time please charge it for more than 8 hours till the red Tail Lights are off.

Why doesn't the Speaker have any response when I tap the Car Cover?

Please turn off the Speaker and after 10 seconds turn it back on.
