



## User manual for the rain capes C-AF and C-AFX

You receive the following accessories with your rain cape:


adapter ring: A49, A52, A55, A58, A62

C-ring adapter (split)


focus assisting ring

To be able to use the camera in the cape properly, please follow the instruction:

1. remove the sunshade from your lens.
2. fasten the focus assisting ring at the lens  
This ring assists you using the lens while the camera is in the rain cape. You can either use it for the focus or for the zoom function of the lens. Place it on that part of the lens where you need it.  
Fasten the ring around the lens by means of the provided rubber rings. Pull them as far as possible to the next hook of the ring.  
If you are using lenses with a very small diameter, you might have to make the ring shorter by cutting a piece off.
3. Screw the matching A-ring adapter into the filter thread of your lens (pic. 1).
4. Place the C-ring adapter around the A-Ring (pic. 2).



pic. 1




pic. 2

5. Place the camera in the rain cape and push it with the adapter against the front glass. The camera is now mounted in the rain cape.
6. You can close the rain cape by means of the zippers.
7. If you are using the C-AFX rain cape, you can now mount a flash on top of your camera.  
The C-AFX should always be closed completely while in use.
8. The C-AFX rain cape can either be used freehand (pic. 3) or mounted on a tripod (pic. 4).



pic. 3



pic. 4

If you are using larger lenses than 62mm diameter, you can order the ewa-marine special adapter rings C-A67 and C-A72 from your local dealer .