

## Ricoh 2100Li with Nera WorldCommunicator and F77

---

This document describes the programming of the Ricoh Fax 2100Li for use with the Nera WorldCommunicator and Nera F77.



Ricoh Fax 2100Li



Nera WorldCommunicator



Nera F77

The Ricoh Fax 2100Li is a Group 4 ISDN fax, 64 kbps, which can also send and receive Group 3 faxes. The 2100Li has four different MSN numbers, two for G4 and two for G3. This makes very suitable for use with the Nera equipment. The Group 3 supports speeds of up to 33.6 kbps (Super G3).

### Hardware set-up

Follow the hardware set-up instructions in the Ricoh user's manual. Connect the ISDN cable to the RJ45 port on the Nera equipment.

### Set-up of ISDN interface

The NWC is delivered from the factory with MSN 60 as the 64 UDI service. This is used for the Group 4 fax. MSN 40 is default for 3.1 kHz service that is used for the Group 3 fax. If you want to use other MSN numbers, please refer to the Nera user's manuals.

On the fax do the following:

Push [Users Tools] [▶][▶][▶]

The display will show:

User Tool Main Menu 4. Key Op. Tools	◀▶
---	----

Push [OK] and key in the access code [2] [2] [2] [2] [OK].

Use [▶] 12 times until the display shows:

Key Op Tools 13. ISDN G3/G4	◀▶
--------------------------------	----

ISDN G3/G4  
2. G4 Own number 1 

G4 Own number 1  
60

ISDN G3/G4	
6 I-G3 Own number 1	◀▶

I-G3 Own number 1

Push [Users Tools]

**When sending a fax you must first choose if you want to send a Group 4 or Group 3 fax. When sending a Group 4 fax you must be sure that the fixed side is also a Group 4 fax.**

For further programming of the Ricoh fax, please refer to the User's Manual.