

User Manual of Sunglasses Camera

● Product Accessories

- Sunglasses camera
- USB cable
- Charger
- User manual CD
- A clip
- Glasses bag and cloth

● Picture & Buttons



1. Power on/Off/Photo 2. Record/save key 3. Camera 4. Indicator Light
5. Micro SD card slot 6. USB port 7. Power Light 8. Reset

● Technical Data

- 1) Main functions: recording video and audio at the same time, taking photo, USB drive, sunglasses, web camera
- 2) Quality Polaroid Lens from brand makers
- 3) Video format: AVI, 640*480
- 4) Photo format: JPEG, 2560*1920
- 5) External memory: SD card 1GB-8GB
- 6) USB: 2.0 (Hs)
- 7) Charging time: 2.5-3 hours
- 8) Battery use time: Polymer Li battery. can use 2-3 hours continually
- 9) Operation systems: No need for driver installation if the operating system is Windows ME/ 2000/ XP/ Vista or above (windows98 is excepted)
- 10) Highly recommended for journalists, traffic police, travelers, business, students

● Operation

Before switching on, insert the Micro SD card.

◆ Switch on

Press the Power on/Off/Photo for 4-5 seconds till the red LED turns on and come to standby mode.

◆ Recording video and audio

1) Start to record

Press record/ save key one time shortly, the red light turns off and the green light flashes continually, it start to record.

2) Stop and Save

Press record/ save key one time shortly, the red light keeps on with the green light off. The video files will be saved automatically and the camera back into standby mode.

◆ Taking Photo

Under standby mode, press the Power on/Off/Photo one time, the green light turns on, then it turns off after several seconds and the red light turns on, indicating one photo is taken and saved, the camera back into standby mode.

◆ Switch Off

Press the Power on/Off/Photo for about 4-5 seconds will switch off the device manually, or insert the pin into the RESET hole, the device will power off.

◆ Reset

Insert the clip into the RESET hole to restart the device once it does not work normally under incorrect operations.

◆ Web camera

The camera can be use as a web camera. Before using it please install the STK02N 2.0 exe which can be found in the user manual CD. Under power on model connect the camera with computer; then it can be used as a web camera.

◆ Charging

1) Under power-off mode or standby mode, connect the camera with computer by

USB cable to charge it. If the camera is low- electricity, the red light will flash slowly. The camera can also be charged by a charger.

- 2) Usually a full charge requests 3-4 hours. The red LED light turns on when recharging while turns off when battery is full charged. Please charge it first before using it when the camera has been standing idle for long time.

◆ **Playback video**

Connect the camera to your computer via USB cable to play back video.

◆ **Setting time**

- 1) Connect the camera to computer via USB cable
- 2) Insert the manual CD and establish a file named SetTime.TXT according to the format 2009.12.12 12:12:12
- 3) Then copy it to the manual CD, The time of camera will be updated when you restart it again.

● **Attention**

- 1) The system will save the video file firstly then turn off if it is low power when taking video.
- 2) When taking video continually, the system will automatically generate a new video file after each operation.
- 3) The time of computer recognizing the device is different according to its different system and configuration, so please do not operate during the recognizing. If the device can't be recognized, please check the computer's operation system, device drivers, USB port and the USB cable to see if they are normal, and then connect the camera again.