

Owner's manual

MAP560 MAP360

Navigation

Copyright The information contained herein may be changed at any time without prior notification. This manual nor any parts thereof may not be reproduced for any purpose whatsoever without the express written consent of Clarion, nor transmitted in any form either electronically or mechanically, including photocopying and recording. © Copyright 2006, Clarion All rights reserved.

Table of contents

1	Introdu	uction	3
	1.1	Search facilities and conventions	4
	1.2	Liability	4
	1.3	Trademarks	5
2	Before	you begin	7
	2.1	The basic principle of navigation	8
	2.2	Important safety information	9 9
3	Operat	ing the navigation software	11
	3.1	Software keyboard	. 12
	3.2	Command buttons	
	3.3	Lists	. 18
4	User m	odes	23
	4.1	Two different user modes	. 24
	4.2	Changing the user mode	. 24
	4.3	Standard mode	. 26
	4.4	Extended mode	. 26
5	Naviga	tion	27
	5.1	General information on navigation	. 28
	5.2	Starting Mobile Map	. 29
	5.3	Basic settings	. 32
	5.4	Indicating a destination 5.4.1 Entering an address 5.4.2 Selecting a point of interest 5.4.3 Indicating destinations on the map 5.4.4 Favourites 5.4.5 Recent destinations 5.4.6 Using your home address	. 36 . 37 . 44 . 47 . 49
	5.5	Destination management	. 50 . 51 . 52
	5.6	Indicating several destinations (Itinerary with stages) 5.6.1 Indicating route points	. 53 . 54 . 56

		5.6.4 Displaying the itinerary on the map	
	5.7	Starting navigation	
6	Workir	ng with the map	67
	6.1	Selecting a map	68
	6.2	Operating the map	
	6.3	Representation of the map in navigation mode	
	6.4	Displaying additional information on the map	
7	Useful	functions for navigation	81
	7.1	Adding a stage point during navigation	82
	7.2	Next destination	
	7.3	Blocking a route section	
8	Config	uring Mobile Map	85
	8.1	Settings	86
		8.1.1 User mode	87
		8.1.2 Map information	
		8.1.3 Route information	
		8.1.4 Signpost information	
		8.1.5 Speed limit	
		8.1.7 Representation	
		8.1.8 Touch screen calibration	
		8.1.9 Automode	
		8.1.10 Routing options	92
		8.1.11 Itinerary	
		8.1.12 Time zone	
		8.1.13 Format	
		8.1.14 Home address	
		8.1.15 Radio-Mute	
9	Glossa	ıry	95
10	Index		97

1 Introduction

Topics covered in this chapter:

1.1	Search facilities and conventions	page 4
1.2	Liability	page 4
1.3	Trademarks	page 5

Introduction - 3 -

1.1 Search facilities and conventions

Find information quickly

This manual offers the following search facilities:

- ⇔ In the footnote at the bottom of the page, you may check which chapter and which section you are actually reading.
- A glossary at the end of the manual contains explanations on the technical terms used in this manual.
- An index at the end of the manual allows precise search for the information contained in this manual.

Conventions

This manual uses different font styles and symbols to highlight important paragraphs and to ease its use.

Font	Use
bold	Buttons, icons, names of entry fields, and elements of the software's user interface. Also used for highlighting warnings and notices.
bold italic	Registered names and trademarks.
SMALL CAPITALS	Window and dialogue box titles.
underlined italic	The name of the user mode which is concerned by the current section. You need not reed sections that don't concern the user mode you are currently working with.

Symbol	Use
	Indicates hints and notes that may ease the use of <i>Mobile Map</i> .
\$	Indicates additional information.
8	Warns against dangers that might cause damage to objects and persons.

1.2 Liability

Limitation of liability

The software and the manual are subject to change without notice. Clarion may not be liable for the correctness of the information contained in this manual nor for damages resulting from the use of this manual.

To improve the quality of our products and our services, we appreciate all suggestions for improvement and all error notices.

1.3 Trademarks

Registered trademarks

All brands and trademarks mentioned in this document are possibly registered by third party and subject to the current legislation and to the rights of their respective owners without reservation. All mentioned names of products, societies, or brands may be registered trademarks of their respective owners. Every right that is not explicitly accorded is reserved.

The absence of an explicit labelling of registered trademarks does not allow the conclusion that this brand was not subject to the rights of third party.

⇔ Outlook, Windows and ActiveSync are registered trademarks of the Microsoft Corporation.

Introduction - 5 -

2 Before you begin

Topics covered in this chapter:

2.1	The basic principle of navigation	page 8
2.2	Important safety information	page 9
	Safety information on navigation	
	Safety information on handling the PNA	
	Safety information on the installation in the vehicle	

User's manual Table of contents • 7

2.1 The basic principle of navigation

in folded maps is over. From now on *Mobile Map*, your

navigation system, will guide you, based on satellite information,

quickly and safely to your destination.

GPS-based navigation

The **G**lobal **P**ositioning **S**ystem (GPS) has originally been developed in the 70ies, as a weapon guidance system for the American forces.

The GPS is based on 24 satellites, which are in orbit round the earth and which are permanently emitting signals. The GPS receiver receives these signals and calculates, based on the runtime of the signals, his distance from the respective satellites. This information serves for calculation your current geographic position.

The signals of at least three satellites are needed to determine the longitude and the latitude. With the signals of at least four satellites the elevation may be calculated, too. The determination has an accuracy of about 3 yards.

Navigation with GPS

The delivered maps contain the geographic coordinates of the points of interest, streets and towns they represent. Thus the navigation system can calculate a route from a given start point to a given destination point.

In case your navigation system receives the signals of at least three satellites it may determine your current position and represent it on the map. This position may then serve as start point for navigation purposes.

As the determination and representation of your position is carried out once a second, you may watch your movements on the map.

2.2 Important safety information

Note

In your own interest, read the following notices and safety information carefully before starting up your navigation system.

2.2.1 Safety information on navigation

Use of *Mobile Map* is executed at your own risk.



Caution: To protect yourself and others from accidents please do not operate the navigation system while driving!



Caution: You must not look at the display except when it is absolutely safe to do so!



Caution: The road layout and the traffic signs are absolutely prior to the instructions of the navigation system.



Caution: You must not follow the instructions of *Mobile Map* except when the circumstances and the road traffic regulations allow doing so. *Mobile Map* will guide you to your destination even when you have left your planned itinerary.



Note: We recommend effecting route planning before beginning the journey. If you are on the road and you want to establish a new itinerary, please drive to the next parking site!



Note: If you have not understood the instructions or if you are not sure about what to do next you may quickly refer to the map or arrow view of your navigation system.

2.2.2 Safety information on handling the PNA



Caution: As it is not waterproof, do not expose your navigation device to water! For example, protect it from rain, snow or hail when you are on your way by bike or on foot.



Caution: Disconnect the navigation device from the power supply when you are leaving the car parked for a long period of time. Failure to do so might result in a dead battery since the internal GPS receiver constantly consumes electricity.



Note: Do not use any harsh solvents for cleaning the PNA. A damp, lint-free cloth is sufficient!

Before you begin - 9 -



Note: Do not unplug by pulling the cable. This might damage the cable!

2.2.3 Safety information on the installation in the vehicle



Caution: Do not fix the holder within the deployment zone of airbags.



Caution: When you install the holder, please check that it may not constitute any safety risk, even in case of an accident.

3 Operating the navigation software

Topics covered in this chapter:

3.1	Software keyboard Character keyboard Mobile phone keyboard	page 12
3.2	Command buttons Command buttons with caption	page 14
3.3	Lists	page 18

3.1 Software keyboard

Survey

A software keyboard appears at the bottom of the screen when text entries are necessary. Choose the character keyboard or the mobile phone keyboard.





Select a software keyboard by tapping the respective icon at the right hand side of the screen. The icon of the active keyboard appears pressed.

3.1.1 Character keyboard





You may carry out all entries with your finger on the character keyboard. But you may enter capital letters only.

You need not enter small letters or special characters when entering a destination's town or street name. *Mobile Map* replaces these characters automatically. When you are looking for, e.g., a French town called "Héroïnès", simply type "HEROINES".

Entering a space, deleting a character...

Tap the icon to enter a space character.

Tap the icon to delete the character at the left of the cursor.

Switching between character and number entry...

Tap the 123 icon to enter numbers, e.g. for a postcode.

Tap the icon to return to the character entry mode.

Special characters

Tap the Sym icon to enter a special character.

The special characters keyboard appears.



As soon as you have entered a special character the letter keyboard reappears.

You need not enter special characters when entering a destination's town or street name but they may be helpful for entering names for saved destinations and itineraries.

Moving the cursor

If you want to delete another character than the one to the left of the cursor position, or if you want to insert a character at another place than at the end of the text, you have to move the cursor to the respective place.

Just tap the place where you want to have the cursor.

3.1.2 Mobile phone keyboard





You may carry out all entries with your finger on the mobile phone keyboard. But you may enter capital letters only.

As on a mobile phone, each key is designed to enter several letters with it. The position of a letter on a key caption indicates how often you must tap this key to enter the respective letter.

E.g., to enter an "S", tap the "PQRS" key four times.

You need not enter small letters or special characters when entering a destination's town or street name. *Mobile Map* replaces these characters automatically. When you are looking for, e.g., a French town called "Héroïnès", simply type "HEROINES".

Entering a space, deleting a character...

Tap the ____ icon to enter a space character.

Tap the icon to delete the character at the left of the cursor.

Switching between character and number entry...

Tap the icon to enter numbers, e.g. for a postcode.

Tap the icon to return to the character entry mode.

Special characters

When you tap a key, a line above the software keyboard appears which lists all characters that may be entered by this key. The active character is highlighted.



If, e.g., you want to type "Ø", tap the "MNO" key repeatedly until "Ø" is highlighted in the line above the software keyboard.

You need not enter special characters when entering a destination's town or street name but they may be helpful for entering names for saved destinations and itineraries.

Moving the cursor

If you want to delete another character than the one to the left of the cursor position, or if you want to insert a character at another place than at the end of the text, you have to move the cursor to the respective place.

Just tap the place where you want to have the cursor.

3.2 Command buttons

Icons The following buttons appear at the bottom of every *Mobile Map* screen:

∡ Return

Main screen

Tap this icon to return to the previous screen. This icon is not available on the **Main screen**.

Tap this icon to open the main screen. This icon is not available on the MAIN SCREEN.

GPS

The **GPS** symbol is placed at the bottom of the screen. The different GPS-icons have the following significance:

Symbol	Significance
No GPS	The GPS receiver is switched off - OR – an external GPS receiver is not connected correctly.
No signal	A GPS receiver is connected, but the received signals are not convenient for navigation purposes (e.g. because you are in a closed building).
GPS ready	The signals are convenient. Navigation may begin.

Tap the **GPS** icon to display the current GPS status:



Entry	Significance
GMT	G reenwich M ean T ime Time of London ignoring daylight saving time.
Longitude / Latitude	Current position: Indication of east longitude and north latitude.
Satellites	Number of received satellites. At least three satellites must be received for navigation purposes.

Entry	Significance
HDOP	Horizontal Dilution of Precision: Indicates the quality of position determination. Theoretically any value from 0 to 50 may occur. The smaller the value, the more accurate is the position determination (value 0 = no deviation from the real position). Values up to 8 are convenient for navigation purposes.
Speed	Indicates your current speed.
Position	Indicates the address of your current position.
Save	Tap this button to add the current address to the FAVOURITES .
Quit	Tap this button to quit the GPS screen.

Energy

The **Energy** icon is placed at the bottom right corner of the screen. The colour of the icon and the symbol displayed on it have the following significance:

Colour/Symbol	Significance
≤ #	The device is connected to an external power supply. The battery is charged. The LED on the device shines green.
4	The device is connected to an external power supply. The battery is being charged. The LED on the device shines red.
	The device is being supplied by its internal battery. The charge state of the battery is sufficient. The number of green segments on the battery indicates its charge state (2 or 3 segments).
	The device is being supplied by its internal battery. The charge state of the battery is weak. The number of green segments on the battery indicates its charge state (0 or 1 segment). A message window informs you when the charge state of the battery becomes insufficient.


- 16 - Command buttons

Switching the GPS receiver on / off

The GPS receiver consumes energy. This is of significance when the system is operated in battery mode, e.g. when you are on your way on foot or by bike. Switch therefore the GPS receiver off when you do not need it for a certain time.

1. Tap the **Energy** icon on the lower right corner of any screen.

The **Energy** screen opens:



- 2. Tap the Off button to switch the GPS receiver off.
- 3. When the GPS-symbol in the upper right corner becomes red, tap the **Cancel** button.



Note: Switching the GPS receiver on works the same way.

3.2.1 Command buttons with caption

Command buttons

You will find command buttons with captions on almost every screen of *Mobile Map*. There is three groups of command buttons:

1. Command buttons with a defined functionality.

These buttons are designed to execute a functionality, which is indicated by their caption. They are normally buttons like Save, OK, Cancel, Select map, One destination etc.

2. Buttons to select one of two possibilities.

These buttons are designed to select one of two possibilities. Normally, the current state is indicated by the caption of the button. They are normally buttons like **User mode**, **Yes-No**, **On-Off**.

When you tap one of these buttons, the caption switches to the other possibility. This change must be confirmed by clicking another button (normally **OK** or **Save**) before the current screen closes.

3. Buttons to enter data.

Subsequently, these buttons will be referred to as entry fields. The caption either your last entry or <please select>. They are buttons like Town, Street, Category (of a POI) etc.

When you tap an entry field, another screen with a software keyboard, a list, or with both of them opens where you can make your entries. This entry must be confirmed by clicking another button (normally **OK** or **Save**) before the entry screen closes. Your entry becomes then the caption of the entry field.

For information on the use of the keyboard, please refer to "Software keyboard", page 12.

For information on working with lists, please refer to "Lists", page 18.



3.3 Lists

Survey

There are many cases where you have to select an entry from a list

If, for example, you have not completely entered the name of a town before tapping **OK**, a list appears which contains all towns beginning with your entry or having it into their names. The postcode of the towns is also indicated in order to allow you to choose the correct one if there is more than one town with the same name.

Entry with focus

One of the entries has the focus. This entry is written in bold. Moreover, there is often some additional information on that entry in a 2^{nd} or 3^{rd} line. In a list of towns, there is indicated the county the respective town belongs to.

Icons

At the right hand side of lists, there are three icons:



OK: Tap this icon to confirm the selection of the entry with the focus (which is placed directly at the left of the OK icon).



Up: Tap this icon to scroll the list one item up.



Down: Tap this icon to scroll the list one item down.

- 18 -

Example

Search for BICKNOR.

1. In the Main Menu tap One destination.


The **Destination** screen opens.

2. Tap Address.

The **Address** screen opens.

3. Tap the **Town** entry field.

The software keyboard appears.



4. Enter the letters BICK.

All towns beginning with BICK or having BICK in their names are listed.



When the list is very long, you may enter one more letter in order to shorten the list.

5. Enter N.



All towns beginning with BICKN or having BICKN in their names are listed.

6. Tap the **Down** icon repeatedly until BICKNOR appears directly under the white entry field.

The entry BICKNOR has the focus.



- 20 - Lists

7. Tap ...

The **Address** screen reappears. BICKNOR is entered into the **Town** field.



4 User modes

Topics covered in this chapter:

4.1	Two different user modes	page 24
4.2	Changing the user mode	page 24
4.3	Standard mode	page 26
4.4	Extended mode	page 26

User modes - 23 -

4.1 Two different user modes

Survey

Mobile Map can be operated in two different user modes: Standard and Extended. This grants an optimum of usability for each user: Less experienced users and users who do not need using the complete functionality of the software work in standard mode. Experienced users who are ready to spend some time in getting used to operate the complete functionality word in extended mode.


Some configuration settings have an effect on the work in standard mode but can only be changed in extended mode. For further information, please refer to "Configuring Mobile Map", page 85.

4.2 Changing the user mode

You may at any time switch to the other user mode.

1. In the Main menu, tap Settings.

The **SETTINGS** screen appears:



The **User mode** entry is at the top of the list. If it is not selected, tap the **Up** icon repeatedly until **User mode** is selected.



2. Tap



The **User mode** screen appears:

Your current user mode is indicated on the **Current user mode** field.

3. Tap **Current user mode** to switch to the other user mode.

The name of the user mode you want to switch to becomes the caption of the entry field.

4. Tap **Save** to save the changes.



Note: When you switch to standard mode, a dialog window asks you whether you want to keep the configuration changes you have made in extended mode. This dialog window appears even when you have not made any configuration changes. Tap **Yes** if you want to keep these changes.

The **User mode** screen closes and you are in the Main menu of the user mode you have just switched to.

4.3 Standard mode

Survey In standard mode, the software is easier to operate. As it offers

reduced functionality, functions may be accessed quicker. So, if you do not need functions like Route planning or indicating a destination on the map, we recommend working in standard

mode.

Functionality In standard mode, you can:

⇔ Select another map

⇔ Enter a destination to navigate to (Address, POI)

⇔ Navigate home

⇔ Select a saved destination

⇔ Save destinations

⇔ Select a destination from the recent destinations list

⇔ Change some configuration settings

4.4 Extended mode

Survey In extended mode, you dispose of the complete functionality of

Mobile Map. You may for example indicate and navigate to more than one destination (route planning with stages). You may

change all configuration settings. If you want to use the complete

functionality, work in extended mode.

Functionality In addition to the functions of the standard mode, the extended

mode enables you to:

⇔ Indicate a direction directly on the map

Plan and save routes with several stages

Adjust the route options before each navigation

⇔ Change all configuration settings

- 26 - Standard mode

5 Navigation

Topics covered in this chapter:

5.1	General information on navigation	page 28
5.2	Starting Mobile Map Extended mode Standard mode	page 29
5.3	Basic settings	page 32
5.4	Indicating a destination Entering an address Selecting a point of interest Indicating destinations on the map Favourites Recent destinations Using your home address	page 35
5.5	Destination management Saving a destination Renaming a destination Deleting a destination	page 50
5.6	Indicating several destinations (Itinerary with stages) Indicating route points Editing, saving and managing itineraries Calculating the route Displaying the itinerary on the map Simulating the route	page 53
5.7	Starting navigation	page 64

Navigation - 27 -

5.1 General information on navigation

Use of *Mobile Map* is executed at your our risk.



Caution: To protect yourself and others from accidents, do not program the navigation system while driving. Enter or select your destination and activate the navigation system before you begin to drive!



Caution: Do not look at the display unless it is absolutely safe to do so! Safe driving is the first priority!



Caution: The rules of the road and traffic signs must be obeyed prior to following instructions from the navigation system.



Caution: Do not follow the instructions of Mobile Map unless circumstances and the road traffic regulations allow doing so. *Mobile Map* will guide you to your destination even when you have gone off course from your route.

Obstructed GPS reception

When you turn off the GPS receiver or when the reception of GPS-signals is obstructed *Mobile Map* does not close but navigation is interrupted.

As soon as the GPS receiver works again the navigation system notices a possible change of your current position and recalculates the route. You may simply continue navigation.

Quitting navigation mode

When you quit navigation mode by command the **Main menu** appears. You may then indicate another destination or reassume the by selecting the former destination from the **Recent** destinations list.

Arriving at your destination

When you have reached your destination the system pronounces the message "You have reached your destination!"

The map is no more presented in navigation mode. A small green arrow indicates your current position.

5.2 Starting Mobile Map

Starting the navigation software...

1. Turn your PNA on.

At the first start (and each time you had terminated *Mobile Map* via the **Quit** icon), the following message appears:



2. Tap the button. If you do not accept and if you tap the button, the software terminates.

5.2.1 Extended mode

The Main screen appears:

Main screen



All functions of the program are accessible via the Main screen.



Note: When you turn your PDA on it shows the screen which was displayed when it was turned off. Nevertheless, you may access the Main screen from all other screens by tapping



One destination

Tap the **Navigation** button to indicate a destination for navigation (one stage).



Navigation - 29 -



For details, please refer to "Indicating a destination", page 31.

Navigation homewards

Tap the **Home** icon to navigate to your home address.






For details, please refer to "Using your home address", page 50.

Route planning

Tap the **Route planning** button for itinerary planning purposes.





For details, please refer to "Indicating several destinations (Itinerary with stages)", page 53.

Display the map

Tap the **Show map** button to display the map which is currently in use..



Select map

Tap the **Map** button to select another map from the memory card which is currently inserted.





For details, please refer to "Working with the map", page 67.

Settings

Tap the **Settings** button to modify the settings of *Mobile Map*.





For details, please refer to "Settings", page 86.

Quit

Tap the Quit button to quit Mobile Map.



5.2.2 Standard mode

The **Main screen** appears:

Main screen





Note: When you turn your PDA on it shows the screen which was displayed when it was turned off. Nevertheless, you may access the Main screen from all other screens by tapping



One destination

Tap the **Navigation** button to indicate a destination for navigation (one stage).





For details, please refer to "Indicating a destination", page 35.

Navigation homewards

Tap the **Home** icon to navigate to your home address.





For details, please refer to "Using your home address", page 50.

Favourites

Tap the **Favourites** button to navigate to a favourite.





For details, please refer to "Favourites", page 47.

Recent destinations

Tap the **Recent destinations** button to select a destination entered previously.



Navigation - 31 -



For details, please refer to "Recent destinations", page 49.

Select map

Tap the **Map** button to select another map from the memory card which is currently inserted.





For details, please refer to "Working with the map", page 67.

Settings

Tap the **Settings** button to modify the settings of *Mobile Map*.





For details, please refer to "Settings", page 86.

Quit

Tap the Quit button to quit Mobile Map.



5.3 Basic settings

Basic settings

Before working with *Mobile Map*, we recommend

- indicating the time zone of the region you are staying in currently so that the system can indicate correct times of arrival in navigation mode,
- \Leftrightarrow entering the home address. You may then navigate home from anywhere.


Indicate the time zone...

1. On the MAIN SCREEN, tap Configuration.



The **Configuration** screen opens.

- 32 - Basic settings



2. Via the arrow buttons, select the **Time zone** screen.

3. Tap into the **Time zone** entry filed.

The **SELECT THE TIME ZONE** screen opens.



- 4. Select the time zone of the region you are currently staying in. (GMT without daylight saving time). The indication of capitals lying in the respective time zones makes the selection easier.
- 5. Tap **Ok**.
- 6. If there is currently daylight saving time, tap the **Daylight** saving time entry field. The entry switches to **Yes**.




Note: If there is a clock change or if you are travelling into another time zone, you will have to adjust the respective setting.

In *Mobile Map*, you may save your home address to quickly start navigation homewards from anywhere.

Navigation - 33 -

Saving your home address...

7. Via the arrow buttons, select the **Home Address** screen.



8. Tap Enter your home address.

The **DESTINATION** screen opens.



9. Tap the **Address** button and enter your home address as described in "Entering an address", page 36.



10. Tap the **Set as home address** button.

Mobile Map

Home address

Enter your home address

Home address:
B18 4 Birmingham
Bacchus Road 3

Cancel

The address is indicated on the **Home address** screen.

11. Tap **Save**.

The Main Screen opens.

5.4 Indicating a destination

Basic principle of navigation

In this chapter you will learn about the possibilities for indicating and managing destinations in *Mobile Map*.

For details on how to start navigation to a destination, please refer to "Starting navigation", page 64.

Indicating a destination

In *Mobile Map* there are several possibilities to enter or to select destinations:

- ⇔ Entering an address, see page 36
- ⇒ Selecting a point of interest, see page 37
- ⇔ Indicating destinations on the map, see page 44
- ⇔ Favourites, see page 47
- ⇔ Recent destinations, see page 49
- ⇔ Using your home address, see page 50

Navigation - 35 -

5.4.1 Entering an address

Extended mode

1. In the Main menu, tap Navigation.

The **DESTINATION** screen opens.



Tap the **Country** entry field and select the destination country if it is not yet indicated.



Note: Only countries of which at least a part is represented on the currently loaded map may be selected.

1b On the **Destination** screen, tap **Address**.

Standard mode

1. In the Main menu, tap Navigation.

The **DESTINATION** screen opens.



Tap the **Country** entry field and select the destination country if it is not yet indicated.




Note: Only countries of which at least a part is represented on the currently loaded map may be selected.

1b On the **Destination** screen, tap **Address**.

Indicating an address...

The **Address** screen opens.



2. Enter the destination town into the **Town or Postcode** entry field. Enter either its name or its postcode.



For information on working with lists, please refer to "Lists", page 18.

- 3. Enter the destination street into the **Street** entry field.
- 4. Enter the house number of your destination into the **Nr**. field, if you know it.



Note: If the house numbers of the respective street are stored in the database of places, you may tap the field besides the **Street** field.

If no house numbers are stored, the respective field is deactivated. The software navigates to the respective street

5. Enter the name of a crossroad into the **Intersection** entry field if you want to define an intersection as destination point (e.g. because the house number is not available).



For information on saving destinations, please refer to "Saving a destination", page 51.

5.4.2 Selecting a point of interest

Points of interest

Points of Interest, also referred to as POIs, are stored in the database of places and may be displayed on the map. Ports, airports, restaurants, hotels, petrol stations, public buildings, and others belong to the special destinations. Indicate a point of interest by selecting one

Navigation - 37 -

Point of interest nearby



Note: You may only select Points of interest nearby when the GPS receiver is turned on and when the GPS signal strength is sufficient.

Extended mode

1. In the MAIN MENU, tap Navigation.

The **DESTINATION** screen opens.



Tap the **Country** entry field and select the destination country if it is not yet indicated.



Note: Only countries of which at least a part is represented on the currently loaded map may be selected.

1b On the **DESTINATION** screen, tap **Point of interest**.

The **Point of interest** screen opens:



1c On the **Point of interest** screen, tap ...nearby.

Standard mode

1. In the MAIN MENU, tap Navigation.

The **DESTINATION** screen opens.



Tap the **Country** entry field and select the destination country if it is not yet indicated.



Note: Only countries of which at least a part is represented on the currently loaded map may be selected.

1b On the **Destination** screen, tap ...nearby.

Selecting a Point of interest nearby...

The POI NEARBY screen opens:



- 2. Enter the radius around your current position within which you want to search for points of interest into the **Radius** entry field.
- 3. Select the main category of points of interest to search for from the left one of the two **Category** list fields, e.g. "Garage". Only points of interest situated within the indicated radius will be displayed.
- Select the **Subcategory** of points of interest to search for from the right one of the two **Category** list fields, e.g. "Audi VW Seat Skoda".

For information on working with lists, please refer to "Lists", page 18.

Navigation - 39 -



Note: If you leave the **Subcategory** field empty, all points of interest matching with the selected main category will be listed in the **Point of interest** list field.

5. Select the correct destination from the **Point of interest** list field.



Note: You need not make entries into the **Category** and **Subcategory** fields. Their purpose is only to shorten the **Point of interest** list. This list may become very extensive, especially in big towns.



For information on saving destinations, please refer to "Saving a destination", page 51.

Point of interest in a certain town

Extended mode

1. In the Main menu, tap Navigation.

The **DESTINATION** screen opens.



Tap the **Country** entry field and select the destination country if it is not yet indicated.



Note: Only countries of which at least a part is represented on the currently loaded map may be selected.

1b On the **DESTINATION** screen, tap **Point of interest**.

The **Point of interest** screen opens:



1c On the **Point of interest** screen, tap ...in a town.

Standard mode

1. In the MAIN MENU, tap Navigation.

The **DESTINATION** screen opens.



Tap the **Country** entry field and select the destination country if it is not yet indicated.




Note: Only countries of which at least a part is represented on the currently loaded map may be selected.

1b On the **Destination** screen, tap ...in a town.

Navigation - 41 -

Selecting a Point of interest in a certain town...

The **POI in a town** screen opens:



- 2. Enter the name of the town in which you want to search for points of interest into the **Town or postcode** field.
- 3. Select the main category of points of interest to search for from the **Category** list field (e.g. Nightlife). Only categories matching your Town entry are listed.
- 4. Select the **Subcategory** of points of interest to search for from the right one of the two **Category** list fields (e.g. Cinema).
- 5. Select the correct destination from the **Point of interest** list field.



For information on working with lists, please refer to "Lists", page 18.



Note: You need not make entries into the **Category** and **Subcategory** fields. Their purpose is only to shorten the **Point of interest** list. This list may become very extensive, especially in big towns.



For information on saving destinations, please refer to "Saving a destination", page 51.

Point of interest of supraregional significance



This function is only available in "Extended mode".

For information on how to change the user mode, please refer to "Changing the user mode", page 24.

1. In the Main menu, tap Navigation.

The **DESTINATION** screen opens.



Tap the **Country** entry field and select the destination country if it is not yet indicated.



Note: Only countries of which at least a part is represented on the currently loaded map may be selected.

1b On the **DESTINATION** screen, tap **Point of interest**.

The **POINT OF INTEREST** screen opens:



1c On the **Point of interest** screen, tap ...nationwide.

Navigation - 43 -

Selecting a Point of interest of supraregional significance...

The **POI NATIONWIDE** screen opens:



- 2. Select the main category of points of interest to search for from the **Category** list field (e.g. Airports).
- 3. Select the correct destination from the **Point of interest** list field.



For information on working with lists, please refer to "Lists", page 18.



Note: You need not make entries into the **Category** field. Their purpose is only to shorten the **Point of interest** list. This list may become very extensive, especially in big towns.



For information on saving destinations, please refer to "Saving a destination", page 51.

5.4.3 Indicating destinations on the map

You may indicate a destination directly on the map. In addition to towns and streets, you may also select special destinations quickly..



This function is only available in "Extended mode".

For information on how to change the user mode, please refer to "Changing the user mode", page 24.

Extended mode

1. In the MAIN MENU, tap Navigation.

The **DESTINATION** screen opens.



Tap the **Country** entry field and select the destination country if it is not yet indicated.



Note: Only countries of which at least a part is represented on the currently loaded map may be selected.

Indicating a destination on the map...

1. On the **Destination** screen, tap **Select on map**.

The MAP screen opens:



2. Tap on the place you want to determine as destination and hold.

Navigation - 45 -

London

A circle of orange points appears round the selected place:

Database information on the respective place will be loaded and displayed. Below the information, there are command buttons for several functions which are available for the selected place.



You have the following options:

This function is only available when GPS reception is possible (The GPS-symbol must be **GPS ready**).

Tap the **Start navigation** button to start navigation to the selected place.

Caution: Using this function while you are already navigating deletes all current destinations (stage points and destination point).

Tap the **Save** button to save the selected place. You may then at any time select this place from the **FAVOURITES**.


Tap the **Search nearby** button to search for a point of interest near the selected place.

This function is only available in "Extended mode".

Tap the Add button to add the selected place to your itinerary. The selected point will be marked by a little flag. It will also be added to the list of route points of the **ROUTE**









Interim destination

PLANNING screen where it figures as destination point.

Using this function while you are already navigating causes an immediate recalculation of your route.

This function is only available in "Extended mode".

Tap the Interim destination button to make the selected point the next stage point of your itinerary. Your route will be recalculated immediately.

5.4.4 Favourites

Survey

All destinations you have saved by tapping the **Save** button are listed on the **FAVOURITES** screen. On this screen you may:

- ⇔ select destinations for navigation purposes,
- ⇔ rename destinations, and
- ⇔ delete destinations from the list.

Extended mode

1. In the Main menu, tap Navigation.

The **DESTINATION** screen opens.



Tap the **Country** entry field and select the destination country if it is not yet indicated.



Note: Only countries of which at least a part is represented on the currently loaded map may be selected.

1b On the **Destination** screen, tap **Favourites**.

Navigation - 47 -

Standard mode

1. In the Main Menu, tap Favourites.

Saved destinations

The **FAVOURITES** screen opens.



2. Tap the entry of the respective destination.



Note: An asterisk behind a name indicates that a voice command for the respective destination has been stored.



For information on working with lists, please refer to "Lists", page 18.

3. Tap

The **Address** screen opens. The address data of the selected destination is entered into the respective fields.





For information on deleting or renaming saved destinations, please refer to "Destination management", page 50.

5.4.5 Recent destinations

Survey

All destinations you have navigated to recently are listed on the **RECENT DESTINATIONS** screen. On this screen you may:

- ⇔ select destinations for navigation purposes,
- Add destinations to the **SAVED DESTINATIONS** list, and
- ⇔ delete destinations from the **RECENT DESTINATIONS** list.

Extended mode

1. In the MAIN MENU, tap Navigation.

The **DESTINATION** screen opens.



Tap the **Country** entry field and select the destination country if it is not yet indicated.



Note: Only countries of which at least a part is represented on the currently loaded map may be selected.

1b On the **DESTINATION** screen, tap **Recent destinations**.

Standard mode

1. In the Main Menu, tap Recent destinations.

Recent destinations

The **Recent destinations** screen opens.



2. Tap the entry of the desired destination.

Navigation - 49 -



For information on working with lists, please refer to "Lists", page 18.

3. Tap

The destination will be taken over. The address is entered into the respective fields.

5.4.6 Using your home address

Survey

If you have stored your home address you may quickly start navigation home at any place.

For information on saving your home address, please refer to "Home address", page 93.

Navigating homewards...

1. On the **Main menu** tap the **Home** icon.



The route is now being calculated and navigation starts.

The calculation is based on the settings you have configured in **Settings – Route options**.



For details, please refer to "Settings", page 86.

5.5 Destination management

Survey

Destinations may be stored in two lists:

- ⇔ the FAVOURITES
- ⇔ the Recent destinations list

Every destination you are indicating and the destinations from the **Recent destinations** list may be added to the **Favourites**. This makes sense if you want to navigate more often to the respective destination.

Destinations from the **FAVOURITES** may be renamed.

Items from both lists may be deleted.

5.5.1 Saving a destination

Precondition

You have entered a destination as described in "Indicating a destination", page 35

- OR -

You have opened the **RECENT DESTINATIONS** list as described in "Recent destinations", page 49.

1. Tap the **Save** icon.



If you have opened the **RECENT DESTINATIONS** list, tap the **Edit** icon.



The **Name of Destination** screen opens.



2. Enter a name for the destination.



For information on the use of the keyboard, please refer to "Software keyboard", page 12.



The destination has now been added to the **FAVOURITES**.

Navigation - 51 -

5.5.2 Renaming a destination

1. On the **DESTINATION** screen, tap **Favourites**.

The **FAVOURITES** screen opens.



2. Select the destination you want to rename.



For information on working with lists, please refer to "Lists", page 18.

3. Tap the **Edit** icon.

The **Name of DESTINATION** screen opens.



4. Enter the new name of the destination.



For information on the use of the keyboard, please refer to "Software keyboard", page 12.



The destination is now renamed.



5.5.3 Deleting a destination

Precondition

You have opened the FAVOURITES as described in "Favourites", page 47

- OR -

You have opened the **RECENT DESTINATIONS** list as described in "Recent destinations", page 49.


1. Tap the entry of the destination to be deleted.



For information on working with lists, please refer to "Lists", page 18.

2. Tap the **Delete** icon.

The **CONFIRM** screen opens.



to delete the destination from the list.

The destination is now deleted from the list.

5.6 Indicating several destinations (Itinerary with stages)



This function is only available in "Extended mode".

For information on how to change the user mode, please refer to "Changing the user mode", page 24.

Itinerary planning

You may plan itineraries without receiving GPS-signals, e.g. comfortably at home. Planned itineraries may be stored. Thus you may plan as many itineraries as you want, e.g. for holidays.

Navigation - 53 -





5.6.1 Indicating route points

Planning itineraries...

1. On the Main Menu, tap Route planning.

The **ROUTE PLANNING** screen opens:





2. Tap the **Add route point** icon to enter the first route point.

The **DESTINATION** screen opens.

3. Indicate the destination as described in "Indicating a destination", page 35.



4. Tap **Add**.

The **ITINERARY PLANNING** screen opens. The destination is added as stage point 1.



5. Repeat steps 2-4 for every stage point you want to add to the itinerary.



Navigation - 55 -

5.6.2 Editing, saving and managing itineraries

Survey You may plan as many itineraries as you want, e.g. for holidays.

You may save them and use them later for navigation purposes.

At any moment, you may add stage points, modify the order of

the stages, or display the itinerary on the map.

The following commands are available on the ITINERARY

PLANNING screen:

Selection

These icons are deactivated when the list does not contain any

route point.

Up Tap this icon to move the selection one route point up.

Tap this icon several times to move the selection several route

points up.

Down Tap this icon to move the selection one route point down.

Tap this icon several times to move the selection several route

points down.

Changing the order

Route point up Tap this icon to navigate to the respective stage point earlier

(example: stage 3 becomes stage 2).

Route point down

Tap this icon to navigate to the respective stage point later

(example: stage 2 becomes stage 3).

Deleting and adding route points

Delete route point Tap this icon to delete the selected route point from the list.

This icon is deactivated when not route point is selected.

Add route point

Tap this icon to add a stage point. The new stage point will be added before the stage point which currently has the focus. You

added before the stage point which currently has the focus. You may shift it using the **Route point up** and **Route point down**

icons.



Managing itineraries

Save itinerary



Only itineraries that contain at least one route point may be saved. Otherwise this icon is deactivated.

1. Tap this icon to save the itinerary you have planned.

The Name of the Itinerary screen opens.



2. Enter a name for the itinerary.



For information on the use of the keyboard, please refer to "Software keyboard", page 12.





Note: Only the route points will be saved. If you load an itinerary, you will have to recalculate it.


Load itinerary



This icon is deactivated if there is no saved itinerary available.

1. Tap this icon to load a saved itinerary, e.g. to modify it or for navigation purposes.

The **Select Itinerary** screen opens:



2. Select the itinerary you want to load.

3. Tap 🚺


Navigation - 57 -

Rename itinerary



1. Tap the **Load itinerary** icon. (This icon is deactivated if there is no saved itinerary available)

The **Select Itinerary** screen opens:





For information on working with lists, please refer to "Lists", page 18.

2. Tap the **Edit** icon.





3. Enter the new name of the itinerary.




For information on the use of the keyboard, please refer to "Software keyboard", page 12.





The **SELECT ITINERARY** screen reopens. The itinerary has been renamed.






5. Tap **OK** to load the renamed itinerary. - OR -

Tap the **Back** icon to open the **ROUTE PLANNING** screen without loading an itinerary.

Delete itinerary

1. Tap the **Load itinerary** icon. (This icon is deactivated if there is no saved itinerary available)








For information on working with lists, please refer to "Lists", page 18.



2. Tap the **Delete** icon to delete the selected itinerary.

The **CONFIRM** screen appears.

Navigation - 59 -



3. Tap 4

The **Select Itinerary** screen reopens. The deleted route is no more listed.



5.6.3 Calculating the route

An itinerary may be calculated even without GPS reception in order to get an impression on the route.

The system assumes then the first route point to be the start point of the route.



Note: When you start navigation, the system identifies your current position and makes it the start point. The first indicated route point is then the first stage point.



1. Tap this icon to calculate the distance and the estimated duration of the entire itinerary.

The **ROUTE OPTIONS** screen opens:



2. Determine the route options.




For detailed information on setting the route options, please refer to "Routing options", page 92.



Note: The standard settings for the route options may be changed on the **ROUTE OPTIONS** screen. For detailed information on changing the standard settings refer also to "Configuring Mobile Map", page 85.

3. Tap the Calculate route icon.

The route is being calculated. A message window informs you on the progress of calculation.



When the route is calculated, the total distance and the estimated duration from the first to the last route point are displayed below the route points list of the **ITINERARY PLANNING** screen.

Total distance: 16mls Time: 00 h 58 min

Furthermore, the distance and the estimated duration of each stage will be indicated with the selected route point entry.

Navigation - 61 -



5.6.4 Displaying the itinerary on the map

Show itinerary

Tap the **Show on map** button to display the entire itinerary on the map.

The map screen opens.



The itinerary is highlighted in orange.

The route points are marked by flags.

For information on working with maps, please refer to "Working with the map", page 67.

5.6.5 Simulating the route

Simulation

You may execute a simulated navigation along the itinerary when the route has been calculated.



Note: The reception of GPS-signals is not necessary for the simulation.

Simulation is restricted to routes of 60 miles max.

1. Tap the **Show on map** button.

The itinerary is displayed on the map.



2. Tap short on any place on the map.

The **Additional functions** screen opens.



Navigation - 63 -

3. Tap Simulation.

The route will be recalculated for simulation purposes.



Simulation starts when calculation has finished.

Stopping the simulation

You may quit a simulation at any moment.

- Tap short on any place on the map.
 The Additional functions screen opens.
- 2. Tap Stop navigation.

5.7 Starting navigation

Precondition

You have entered a destination as described in "Indicating a destination", page 35,

- OR -

You have selected a destination from the **FAVOURITES** as described in "Favourites", page 47,

- OR -

You have selected one of your **RECENT DESTINATIONS** as described in "Recent destinations", page 49,

- OR -

You have planned or loaded an itinerary as described in "Indicating several destinations (Itinerary with stages)", page 53.

Extended mode

1. Tap Start navigation.

The **ROUTE OPTIONS** screen opens:



2. Determine the route options.



For detailed information on setting the route options, please refer to "Routing options", page 92.



Note: The standard settings for the route options may be changed in **Settings** – **Route options**. For detailed information on changing the standard settings refer to "Settings", page 86.

The system calculates the route.

The map screen opens. Your current position is indicated by a green arrow. The route is highlighted in orange.





Note: When you start navigation after having planned or loaded an itinerary, then your current position is the start point of the route. The first indicated route point is then the first stage point of your route.


Navigation - 65 -

Standard mode

1. Tap Start navigation.

The system calculates the route.

The map screen opens. Your current position is indicated by a green arrow. The route is highlighted in orange.





Note: The route will be calculated with regard to the current route options settings. The standard settings for the route options may be changed in **Settings – Route options**. For detailed information on changing the settings refer to "Settings", page 86.

No GPS reception?

When the received GPS signal is not sufficient, the following message appears:



You have two possibilities:

- ⇔ Wait until navigation starts. This will happen as soon as the GPS reception is sufficient.
- ⇔ Tap Cancel and restart navigation as soon as the reception of GPS signals is convenient. You may notice that by watching the GPS symbol on the screen: it becomes GPS ready when the reception is good.

6 Working with the map

Topics covered in this chapter:

6.1	Selecting a map	page 68
6.2	Operating the map	page 69
6.3	Representation of the map in navigation mode	page 75
6.4	Displaying additional information on the map	page 77

6.1 Selecting a map

Selecting a map



To load another map which is available on the currently inserted memory card, proceed as follows:

- 1. If the desired map is on another memory card than the currently inserted one, open the **Main screen** and tap the **Quit** button.
- 1a Remove the memory card, which is currently inserted.
- 1b Insert the memory card, which contains the map you want to work with.
- 1c Start Mobile Map over.



Note: You need not execute steps 2 to 4 unless there is more than one map stored on the inserted memory card.

2. On the Main screen, tap the Map button.



The **Available maps** screen opens:



3. Tap the entry of the map you want to work with.



The selected map is now loaded. The MAIN SCREEN opens.

- 68 - Selecting a map

6.2 Operating the map

Survey There are various pieces of information available on the MAP

screen. Learn in this chapter about the possibilities for working with the map, which depend on whether you are in navigation

mode or not.

Displaying the map You may display the map

⇔ while planning an itinerary,

⇔ in order to show destinations on the map, or

 \Leftrightarrow in order to select destinations on the map.

Extended mode In "extended mode", you may display the map

⇔ Via the **Show map** button on the **MAIN MENU**



- ⇔ Via the **Select on map** button on the **Destination** screen
- Via the Show on map button on the ADDRESS screen after having entered an address.

Standard mode

In "standard mode", you may display the map

⇔ Via the Show on map button on the Address screen after having entered an address. The MAP screen opens.



The map is being displayed automatically when you start navigating.

Tapping the map

Tapping short any place on the map makes the **ADDITIONAL FUNCTIONS** screen appear. Depending on whether you are in navigation mode or not this screen offers different functions.

Tapping long a certain place on the map (tap and hold) makes information on that place appear. You may then, e.g., take over the data for navigation purposes.



For details, please refer to "Indicating destinations on the map", page 44.

Icons

Survey

The Map screen disposes several icons which allow altering the representation of the map.



Hide/show icons

(When without GPS-reception)

This icon allows you to hide all other icons in order to see more of the map.

Tap this icon again to show the other icons.



Automode

(When with GPS-reception)

Tap this icon to display the standard representation of the map after you have modified the view.

The settings of north orientation and auto zoom mode will be applied. Your current position will be centred. The icons will not be displayed.



For details, refer to "Automode", page 91.

Freeze

This icon is activated in navigation mode only.

Tap the **Freeze** icon





to toggle between "Frozen map" and "Frozen position".



Frozen position (default)

This mode (button down) makes the map scroll continually. Your current position (green arrow) is always centred in the bottom third of the map.



Frozen map

This mode (button up) freezes the map. Your current position (green arrow) moves over the map and may even leave it.

This mode applies automatically when you scroll the map in navigation mode. Otherwise the system would always try to keep your current position in the bottom third of the map.

Select this mode when you want to select a destination from the map while navigation is in progress.

Zoom / Scroll

Tap the Zoom/Scroll icon





to toggle between Zoom and Scroll mode.



Zoom

In Zoom mode (Button up) you may scale the map up or down. Zoom in by drawing a rectangle on the map, beginning with the upper left corner. Zoom out by beginning with the lower right corner.



Scroll

In Scroll mode (button down) you may scroll the map. Tap on the screen and drag to the desired direction.



Map in driving direction/north oriented



Entire route

Tap the **Itinerary** icon to display the whole itinerary.

Tap the In driving direction/North oriented icon





to switch between the two available modes of map orientation. (North orientation / orientation in driving direction).

North orientation

Tap this icon (button down) to orientate the map north up.

Tap this icon (button up) to orientate the map in driving direction.

3D view

Tap this icon to display the map in 3D mode (bee flight view).

2D view

Tap this icon to return to the 2D mode (standard).

Zoom in

Tap **Zoom in** to scale the map down.

Zoom bar

Tap one of the zoom bar sections to modify the scale of the map.

Zoom out

Tap **Zoom out** to scale the map up.

Additional functions

Tapping short any place on the map makes the **ADDITIONAL FUNCTIONS** screen appear. Depending on whether you are in navigation mode or not this screen offers different functions.

The range of offered functionality depends also on whether you are working in standard or in extended mode.

For information on how to change the user mode, please refer to "Changing the user mode", page 24.
















The **Additional functions** screen opens:



Tap this icon to toggle between "Day" and "Night" map view mode.



Tap this icon to switch the voice instructions on / off.



Preferences

Tap **Preferences** to display the **SETTINGS** screen. For details, please refer to "Settings", page 86.



Quit navigation

This function is only available in navigation mode. Tap **Quit navigation** to exit navigation mode.

Block road, Unblock

These functions are only available in navigation mode.



For details, please refer to "Blocking a route section", page 83.




Set interim destination

This function is only available in navigation mode. Tap **Set interim destination** to add a new route point to your itinerary. The route will be recalculated and the newly added route point will be the first destination to navigate to. Navigation to the other route points will be executed later.



For details, please refer to "Adding a stage point during navigation", page 82.



Route options

This function is only available in navigation mode. Tap **Route** options to modify them.



For details, please refer to "Routing options", page 92.



Next destination

This function is only available when you are navigating a route with at least one stage point and when you are working in extended mode.

Use this function if you want to skip the next stage point.

Example: You have planned an itinerary from your office to "Company A" and then to "Company B" and you are already on your way. Before you arrive at "Company A", a mobile phone call informs you that you need not visit Company A.

Tap the **Next destination** button to navigate to the stage point after the next (here: "Company B").

The system recalculates the route. "Company B" will be your next destination.



Refer also to "Next destination", page 83.

6.3 Representation of the map in navigation mode

In navigation mode, there is some assistance for navigation, some information on the itinerary and one more command button being displayed:

Assistance for navigation

The following assistance for navigation is being displayed at the left and at the bottom of the map:



Field	Information
①	If there are two manoeuvres to be executed quickly one after the other, the small upper arrow field indicates the manoeuvre to be executed immediately after the next manoeuvre.
2	The green arrow indicates your current position on the map. Since the displayed sector of the map changes continually your current position is centred on the map whenever possible (Moving Map).
3	The bigger arrow field indicates the next manoeuvre to be executed.
4	The distance field indicates the distance to the next manoeuvre. When you approach, the representations changes into a distance bar: The more yellow bars are displayed the nearer you are to the place where the next manoeuvre must be executed.
(5)	The upper street field indicates the name of the next street to turn on.
6	The lower street field indicates the name of the street you are currently on.

Signpost info

The upper part of the Map screen displays information on the signposts you have to follow:

M77 Kilmarnock



Note: This information can only be displayed when it is contained in the cartographic material.

Speed limit

The left part of the map screen shows possible speed limits:



Possible restrictions of validity are shown beneath (e.g. on rain, on snow, at certain hours etc.):





Note: This information can only be displayed when it is contained in the cartographic material.

Caution: Information contained in the cartographic material can be wrong, e.g. due to road works.



Traffic situation and road traffic regulations are absolutely prior to the information given by the navigation system.

Information on the itinerary

At the right of the map, the following information on the itinerary is being displayed:



Field	Information
 •	This symbol means "stage". All information displayed below refers to the next stage point.
1:03 am	ETA (Estimated time of arrival).
00h02'	Remaining time to arrival (estimated).
0.8mls	Remaining distance to arrival (estimated).



Tap this icon to repeat the last spoken instruction. All available information will be displayed.

The displayed information will be hidden after a few seconds.

6.4 Displaying additional information on the map

In *Mobile Map* you may determine which information is to be displayed on the map. Modifying any configuration begins on the **SETTINGS** screen.

Configuring the display of additional information...

- 1. Open the **SETTINGS** screen
 - ⇔ by tapping the **Settings** button on the **MAIN MENU**,
 - or by tapping short into the map and selecting Preferences.

The **SETTINGS** screen opens.

2. Select **Map information** using the arrow buttons:



Info bar

The **Info bar** at the bottom of the map displays the scale of the map, the compass, and the current speed. .

3. Tap the respective command button to display (On) or not (Off) the **Info bar**.




Points of Interest

4. Tap the respective command button to display (On) or not (Off) **Points of Interest** on the map.

Street names

5. Tap the respective command button to display (On) or not (Off) **Street names** on the map.

6. Via the arrow buttons select **Route information**:




7. Tap the command buttons to display (On) or not (Off) the respective information on the map.

The desired information on the entire itinerary (upper section) and on the current stage (lower section) will be displayed at the right hand side of the map.



Section	Information
	This symbol means "itinerary". All information displayed below refers to the final destination.
 0	This symbol means "stage". All information displayed below refers to the next stage point. This section is only available if you have indicated more than one destination to navigate to.
Line 2	ETA (Estimated time of arrival).
Line 3	Remaining time to arrival (estimated).
Line 4	Remaining distance to arrival (estimated).



8. Via the arrow buttons select **Signpost information**.

The **Show traffic signs** command indicates whether signposts indicating exits from motorways or highways are currently being displayed or not.

9. Tap the **Show traffic signs** command to toggle between On and Off mode.

The new mode is now indicated on the button.

10. Via the arrow buttons select **Speed limit**.



The **Speed Limit** screen allows you to determine whether you want to display speed limits in navigation mode and whether you want to be warned acoustically on speeding.

Setting	Significance
Show traffic signs	This command indicates whether signposts indicating speed limits are currently being displayed or not.
	Tap the Show traffic signs command and select whether speed limits should be displayed
	Always
	On speeding only or
	Never.
Warning in built-up areas	This command indicates from how much speeding on you want to be warned when driving within built-up areas. Tap the Warning in built-up areas command to select another value or to set it to Never .
Warning outside built-up areas	This command indicates from how much speeding on you want to be warned when driving outside built-up areas. Tap the Warning outside built-up areas command to select another value or to set it to Never.
Warning	This command indicates whether you want to be warned on speed limits that are valid on rain, on snow, or at certain hours. Tap the Warning command to set the
	value to Yes or to No .

11. Tap **Save** to save the modifications.

The modifications will be taken over and displayed on the map.

7 Useful functions for navigation

Topics covered in this chapter:

7.1	Adding a stage point during navigation	page 82
7.2	Next destination	page 83
7.3	Blocking a route section	page 83

Survey

In *Mobile Map* the following functions are available in navigation mode:

- Adding a stage point during navigation, see below
- ⇔ Skipping the next stage point, see page 83
- ⇔ Blocking a route section, see page 83

7.1 Adding a stage point during navigation



This function is only available in "Extended mode".

For information on how to change the user mode, please refer to "Changing the user mode", page 24.

Adding a stage point during navigation...

At any moment during navigation you may add a new stage point to your itinerary. The route will be recalculated in order to make the new stage point the next destination to navigate to. The other remaining stage points will be navigated to after the new one.

Adding a stage point...

<u>Precondition</u>: The map is being displayed in navigation mode.

- 1. Tap short on any place on the map.
- 2. Tap Set interim destination

The **Destination** screen opens.

- 3. Indicate the new stage point as described in "Indicating a destination", page 35.
- 4. Tap the **Set as route point** button.

The route will be recalculated in order to make the new stage point the next destination to navigate to.



Note: Select the new stage point directly on the map, just as described in "Indicating destinations on the map", page 44. Tap the respective place and hold. From the context menu, select **Add as route point**.

7.2 Next destination



This function is only available in "Extended mode".

For information on how to change the user mode, please refer to "Changing the user mode", page 24.

Next destination

Next destination

This function is only available when you are navigating a route with at least one stage point and when you are working in extended mode.

Use this function if you want to skip the next stage point.

Example: You have planned an itinerary from your office to "Company A" and then to "Company B" and you are already on your way. Before you arrive at "Company A", a mobile phone call informs you that you need not visit Company A.

Tap the **Next destination** button to navigate to the stage point after the next (here: "Company B").

The system recalculates the route. "Company B" will be your next destination.

7.3 Blocking a route section

Blocking a route section manually

You may block a route section manually in order to evade it. Manual blocking forces a recalculation of the route.

Presume that you are driving on a freeway and a radio message announces a traffic jam 4 miles ahead of your current position. With the "Block route sections" function you may instruct the navigation system to evade the announced traffic jam.

A manual blocking is only valid for the current navigation process. The respective route section will be unblocked for the next navigation or when you restart the software.

Blocking a route section...


<u>Precondition</u>: The navigation system is in navigation mode and the map is being displayed.

- 1. Tap short on any place on the map.
- 2. Tap Block road.

The **BLOCKING** screen opens.

- 2. Enter how many miles (from your current position on) you want to block.
- 3. Tap **OK**.

This forces a recalculation of the route. The indicated route section will be evaded. On the map, it will be highlighted in red.



Unblocking a route section

- 1. Tap short on any place on the map.
- 2. Tap Unblock.

The route section is now unblocked. The navigation system uses the route, which had been calculated originally.

8 Configuring Mobile Map

Topics covered in this chapter:

8.1 Settings page 86

User mode

Map information

Route information

Signpost information

Speed limit

Volume

Representation

Touch screen calibration

Automode

Routing options

Itinerary

Time zone

Format

Home address

Radio-Mute

Product information

8.1 Settings

Configuration

In *Mobile Map*, you may modify the following settings:

- ⇔ User mode, see page 87
- ⇔ Map information, see page 87
- ⇔ Route information, see page 88
- ⇔ Signpost information, see page 89
- ⇔ Speed limit, see page 90
- ⇔ Volume, see page 90
- ⇔ Representation, see page 90
- ⇔ Touch screen calibration, see page 90
- ⇔ Automode, see page 91
- ⇔ Routing options, see page 92
- ⇔ Itinerary, see page 92
- ⇔ Time zone, see page 93
- ⇔ Format, see page 93
- ⇔ Home address, see page 93
- ⇔ Radio-Mute, see page 94
- ⇔ Product information, see page 94

On the MAIN SCREEN, tap the **Settings** button to configure *Mobile Map*.

On the **Settings** screen, tap the arrow icons to select the configuration you want to modify.

Tap the **Save** button to apply your modifications if you have made some.

- 86 - Settings

8.1.1 User mode

User mode

On the **User mode** screen, you may effect the following modifications:

Your current user mode is indicated on the **Current user mode** field.

Tap **Current user mode** to switch to the other user mode.

The name of the user mode you want to switch to becomes the caption of the entry field.

Tap **Save** to save the changes.



Note: When you switch to standard mode, a dialog window asks you whether you want to keep the configuration changes you have made in extended mode. This dialog window appears even when you have not made any configuration changes. Tap **Yes**.

Restoring the factory settings...

- 1. If you want to restore the factory settings, tap the **Factory** settings command.
- 2. Confirm the restoration.

8.1.2 Map information



This function is only available in "Extended mode".

For information on how to change the user mode, please refer to "Changing the user mode", page 24.

Info on the map

On the **Map information** screen, you may effect the following modifications:

Element	Signification
Info bar	The Info bar at the bottom of the map displays the scale of the map, the compass, and the current speed. Tap the respective command button to display (On) or not (Off) the Info bar. 178yd 22 mph
Points of Interest	Tap the respective command button to display (On) or not (Off) Points of Interest on the map.
Street names	Tap the respective command button to display (On) or not (Off) Street names on the map.

8.1.3 Route information



This function is only available in "Extended mode".

For information on how to change the user mode, please refer to "Changing the user mode", page 24.

Route info

On the **Route information** screen, you may effect the following modifications:

Element	Signification
ETA at final dest.	ETA (Estimated time of arrival) at the final destination.
Time to final dest.	Remaining time to the final destination (estimated).
Dist. to final dest.	Remaining distance to the final destination (estimated).
	Tap the respective command buttons to display (On) or not (Off) the respective
	information on the map.
	All information displayed below refers to the final destination.
	1:47 am
	00h47'
	13mls
ETA at next dest.	ETA (Estimated time of arrival) at the next
-	stage point.
Time to next dest.	Remaining time to the next stage point (estimated).
Dist. to next dest.	Remaining distance to the next stage point (estimated).
	Tap the respective command buttons to display (On) or not (Off) the respective
	information on the map.
	All information displayed below refers to
	the next stage point.
	1:03 am
	00h03'
	0.8mls
	This section is only available if you have
	indicated more than one destination to
	navigate to

- 88 - Settings

8.1.4 Signpost information

Signpost information

On the **Signpost information** screen, you may effect the following modifications:

The **Show traffic signs** command indicates whether signposts indicating exits from motorways or highways are currently being displayed or not.

Tap the **Show traffic signs** command to toggle between On and Off mode.

The new mode is now indicated on the button.



Note: This information can only be displayed when it is contained in the cartographic material.

8.1.5 Speed limit

Speed control

On the **Speed LIMIT** screen, you may effect the following modifications:

Setting	Significance
Show traffic signs	This command indicates whether signposts indicating speed limits are currently being displayed or not.
	Tap the Show traffic signs command and select whether speed limits should be displayed
	Always
	On speeding only or
	Never.
Warning in built-up areas	This command indicates from how much speeding on you want to be warned when driving within built-up areas.
	Tap the Warning in built-up areas command to select another value or to set it to Never .
Warning outside built-up areas	This command indicates from how much speeding on you want to be warned when driving outside built-up areas.
	Tap the Warning outside built-up areas command to select another value or to set it to Never.
Warning	This command indicates whether you want to be warned on speed limits that are valid on rain, on snow, or at certain hours.
	Tap the Warning command to set the value to Yes or to No .



Note: This information can only be displayed when it is contained in the cartographic material.



Caution: Information contained in the cartographic material can be wrong, e.g. due to road works.

Traffic situation and road traffic regulations are absolutely prior to the information given by the navigation system.

8.1.6 Volume

Volume

On the **Volume** screen, modify the volume of the spoken indications of the navigation system.

Tap the **Volume** field and select another value.

8.1.7 Representation



This function is only available in "Extended mode".

For information on how to change the user mode, please refer to "Changing the user mode", page 24.

Representation

On the **Representation** screen, you may effect the following modifications:

Setting	Signification
Skin	Skins are made to personalize the user interface of <i>Mobile Map</i> . Tap the Skin field. Select one of the available skins and tap OK .
Darken at night	Tap this field and select whether the screen or your Pocket PC is to be darkened at night or not.

8.1.8 Touch screen calibration

Touchscreen calibration

If you think that the touch screen does not perceive contact positions correctly, *Mobile Map* may calibrate it.

Tap the **Start calibration** button and follow the instructions on the display.

- 90 - Settings

8.1.9 Automode



This function is only available in "Extended mode".

For information on how to change the user mode, please refer to "Changing the user mode", page 24.

Auto mode

On the **Auto Mode** screen, you may effect the following modifications:

Setting	Signification
Begin with	Select the default map view: 2D or 3D.
3D Autozoom	Select the default for navigation with 3D view:
	Autozoom or No Autozoom.
	With Autozoom, the system changes the scale of the map depending on your current speed: When you drive slowly, the scale becomes small. When you drive fast, the scale becomes high.
2D Autozoom	Select the default for navigation with 2D view: Low Autozoom, Standard Autozoom, High Autozoom, or No Autozoom.
	With Autozoom, the system changes the scale of the map depending on your current speed: When you drive slowly, the scale becomes small. When you drive fast, the scale becomes high.
	The lower the Autozoom, the lower the scale.
2D View	Select the default for navigation with 2D view: North oriented or In driving direction.

8.1.10 Routing options

Routing options

On the **ROUTING OPTIONS** screen, indicate your speed profile. This entry will have an effect on the calculation of the remaining time and of the **e**stimated **t**ime of **a**rrival (ETA).

- 1. Tap the **Speed profile** button. Select one of the available profiles and tap **OK**.
- 2. Tap the **Type of routing** field and select one of the following options:

Option	Signification
Fast route	The quickest route will be calculated.
Short route	The shortest route will be calculated.

3. Tap the **Motorways**, **Ferries**, and **Toll roads** fields successively and select one of the following options:

Option	Signification
Permitted	The respective kind of street will be regarded for route calculation.
Avoid	The respective kind of street will be avoided if reasonable.
Forbidden	The respective kind of street will be disregarded for route calculation.

8.1.11 Itinerary



This function is only available in "Extended mode".

For information on how to change the user mode, please refer to "Changing the user mode", page 24.

Proceeding automatically to the next stage point...

On the **ITINERARY** screen, determine whether you want to navigate automatically to the next stage point after having reached a stage point (Yes) or not (No).

Tap the **Proceed automatically to the next stage point** button to toggle between Yes and No.

If you don't proceed automatically, you may proceed as follows:

- 1. In navigation mode, tap short on any place on the map.
- 2. Select Next destination.

- 92 - Settings

8.1.12 Time zone

Calculation of arrival times

On the **TIME ZONE** screen, select the time zone of the region you are currently staying in. This is necessary for the system to indicate correct times of arrival in navigation mode.

Element	Signification
Time zone	Tap this entry field to select the time zone of the region you are currently staying in.
Daylight saving time	Tap this entry field to switch between daylight saving time (yes) and standard time (no).



Note: If there is a clock change or if you are travelling into another time zone, you will have to adjust the respective setting.

8.1.13 Format

Units

On the **FORMAT** screen, determine which units are to be used for time and distance indications.

Setting	Signification
Time	Tap the Time field to toggle between 12 hours (AM/PM) and 24 hours time format.
Distance	Tap the Distance field to toggle between kilometres or miles distance units.

8.1.14 Home address

Home address

On the **Home address** screen, you may save your home address to quickly start navigation homewards from anywhere.

1. Tap Enter your home address.

The **Destination** screen opens.

- 2. Tap the **Address** button and enter your home address as described in "Entering an address", page 36.
- 3. Tap the **Set as home address** button.

The address is indicated on the **Home address** screen.

8.1.15 Radio-Mute



This function is only available in "Extended mode".

For information on how to change the user mode, please refer to "Changing the user mode", page 24.

Radio-Mute

On the **RADIO-MUTE** screen, you may activate the radio-mute function if your hands-free kit is connected to the RADIO-MUTE jack of your car radio. Possible retardations of the hands-free kit will then have no negative effects on the spoken indications of the navigation system.

8.1.16 Product information

Product information

On the **Product Information** screen, the name and the version of the software are displayed.

Tap **Show intro** to make the system explain its most important functions.

- 94 - Settings

9 Glossary

COM-port

A COM port is a connector to a communications interface, usually the serial port. The ports are numbered by a number behind "COM". A communications interface is designed to connect hardware like a mouse or a GPS receiver.

GMT

GMT (Greenwich Mean Time) is the mean solar time at the Royal Greenwich Observatory in Greenwich near London, England, which by convention is at 0 degrees geographic longitude. Theoretically, noon Greenwich Mean Time is the moment when the Sun crosses the Greenwich meridian (and reaches its highest point in the sky in Greenwich). Up to 1972, GMT was the global time standard. Because of the Earth's uneven speed in its elliptic orbit, GMT has been replaced by UTC (Universal Time Coordinated) which is an ultra stable time standard based on atomic clocks.

GPS

The GPS (Global Positioning System) is based on 24 satellites which are in orbit round the earth. They are permanently emitting the time and their current position. The GPS receiver receives this information and calculates the longitude and the latitude of its own current position.

The signals of at least three satellites are needed to determine the longitude and the latitude. With the signals of at least four satellites the elevation may be calculated, too. The determination has an accuracy of about 3 yards.

HDOP

The Horizontal Dilution of Precision (HDOP) indicates the quality of position determination. Theoretically any value from 0 to 50 is possible. The smaller the value is, the more accurate is the position determination (value 0 = no deviation from the actual position). Values up to 8 are convenient for street navigation.

POI

Point of Interest (POI). See → Special destination.

Special destination

Special destinations, also called POI (**Points of Interest**), are covered by the map and may be displayed on it. Harbours, airports, restaurants, hotels, petrol stations, public buildings, and others belong to the special destinations. You may determine special destinations as itinerary points for navigation purposes.

Glossary - 95 -

10 Index

A	Ī	
Additional functions	Indication of destinations Favourites Home address	
В	On the map	
Ь	Points of interest	
Battery	Recent destinations	
Status	Saved destinations	
Blocking	Info bar	77, 87
Blooking 00	Information	
	Itinerary	78
C	Stage	76, 78
	Interim destination	73, 82
Current position 75	Itinerary	78, 92
	Itinerary planning	53
D		
Destination	K	
Delete	V ov do o o rd	1.0
Navigate to	Keyboard	
Rename 52		
Kename 32	M	
 E	Main screen	20 21
_	Map	
Energy 16	2D view	
ETA (Estimated Time of Arrival) 88	3D view	
Exit signposts 89	Day / Night	
3 P	Display	
	Freeze	
F	Hide/show icons	
	Info bar	
Favourites 47	Information	77
	Itinerary	72
G	Orientation	
	Points of Interest	
GMT 15	Route	72
GPS 8	Scroll	71
GPS icon	Signposts	7 <i>6</i>
Signals8	Speed limit	7 <i>6</i>
GPS receiver	Street names	77, 87
On/Off	Zoom	71
	Zoom in	72
	Zoom out	72
Н	Mobile Map	
	Quit	30, 32
HDOP 16	Start	29
Home address33, 50, 93		

Index - 97 -

N	Auto mode91
	Exit signposts89
Navigation	Format 93
Proceed automatically 92	Home address 93
Quit	Info on the map87
start 64	Itinerary92
5tart 51	Itinerary info88
	Representation 90
P	Route info 88
	Routing options 92
POI 37	Signposts 89
Points of interest 37	Speed control
In certain town 42	Speed profile
Nationwide 44	Touchscreen 90
Nearby 38	User mode
Points of Interest77, 87	Volume
Position	Signposts
Freeze 71	Skins 90
Proceed automatically	Software-keyboard
Troceca automatically	Speed control
	Speed limit
R	
	Speed profile
Recent Destinations	Stage
Remaining distance 88	Stage point
Remaining time 88	Street names77, 87
Route information	
Route options65, 66, 74	Т
Route planning 53	•
Route section	Time of arrival88
Block 83	Touchscreen
Unblock	Todolisci celi
Routing options	
Routing options	U
S	Units 93
Screen	
Additional functions 73	V
Configuration 86	
Destination	Voice command73, 76
Favourites 48	Volume 90
Itinerary planning54	
Point of interest	_
Recent destinations 49	Z
Settings	
Search facilities4	Zoom bar 72
Security information	
Settings	
Jordings	

- 98 - Index