

USER MANUAL

Spray Booth

CORALTEC INC.

User Guide

© CORALTEC INC.

130 Konrad Crescent • Suite 11

Markham, ON L3R 0G5, Canada

Phone 1.844.604.6234 • Email support@spraysizer.com • Web: www.spraysizer.com

Manual Release Date: February 2015

Manual Version: V1.0

1 Operation Procedure

The spray booth is a closed circuit system that does not require to be connected to an external water supply. However, the following steps should be followed to use the system:

 Install your desired nozzle on the system. If the system is used for demonstration purposes, use a nozzle which produces a full cone spray with medium spray angle. The nozzle thread must be 1/4" NPT. Warning: Do not use any nozzle that the total length of the body of the nozzle including the thread exceeds 1 inch, since the nozzle tip becomes too close to the device.

- 2. There are two valves in the system labeled as 1 and
 2. Valve 1 is for draining the system and valve 2 is connected to the nozzle. To use the system, valve number 1 should be in closed position and valve number 2 should be in open position
- 3. The pump is required to be wired prior using the system. The input power to the pump should **12VDC** with maximum current of **10A**.
- 4. Pour at least 4 litres of water in to the sink. The system is closed loop and it requires initial water supply for operation.
- 5. Place the device under the spray and prepare it for operation as described in the device manual.

The system is ready for operation. Connect the power supply to run the system and start the measurement.

The system can be used for several measurements and demonstrations. However the following steps should be followed to safely store the spray booth for future use:

- 1. Turn off the spray by cutting the electricity supply to the system.
- 2. Put the tip of the thin white hose into a proper container to empty the water in the system.
- 3. Open valve number 1 and close valve number 2.
- Run the pump to empty the water inside the system into the container.
- Once the water is drained, clean the system with a soft cloth and carefully put it back into its protective case.

It is recommended to carry the system with the help of a second person due to the high weight of the system. Preferably handle the system by grabbing the plastic handles on top or the aluminum bars. Avoid mechanical impacts since they can cause minor damages to the sink.

Warning: Never run the pump while both valves are closed or when there is no water in the system.

Note: Never handle the system by grabbing the steel tubes.

OPERATION PROCEDURE

Every once in a while inspect beneath the black sink to ensure that there is no leak in the system caused by mechanical impacts.

2 TERMS OF USE, WARRANTY & LIABILITY WAIVER

Coraltec Inc. (the "Company") offers its product named as "Spray Booth" (the "product") with the terms, conditions and notices as follows:

2.1 Terms of use

By purchasing and accepting the delivery of the product customer agrees to be bound by and accepts the following terms, conditions, warranty, and disclaimer.

2.2 Exclusive Obligation

This product may not be used for unlawful purposes and that use is expressly prohibited under the terms and conditions of the product.

2.3 Warranty

No warranty is offered on this product. However the company will do its best to resolve any unlikely problem with the system.

2.4 Guarantees

No guarantees are given or implied to the product efficiency, product performance and production or its improvement.

2.5 Limitation of Liability

To the maximum extent permitted by applicable law, in no event shall the Company, its suppliers, directors, shareholders and/or employees be liable for any damage whatsoever (including without limitation, special, incidental, consequential, or indirect damages for personal injury, loss of business profits, business interruptions, loss of business information, or any other pecuniary loss) arising out of the use of or inability to use this product, even if the Company has been advised of the possibility of such damages. In any case the Company's, its suppliers', directors', shareholders' and/or employees' entire liability under any provision of this agreement shall be limited to the amount actually paid by you for the product.

2.6 Other Statements

Coraltec Inc. employees or representatives, oral or other written statements, do not constitute warranties, shall not be relied upon by buyer, and is not part of the contract for sale or this limited warranty.

To the maximum extent permitted by applicable law, the Company and its suppliers disclaim all other warranties, either express or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose, with regard to the product and any related or accompanying written materials

2.7 General

This disclaimer statement is governed by the laws of Canada. You hereby consent to the exclusive jurisdiction and venue of the Courts of Canada, in all disputes arising out of or relating to the use of this product. Use of this product is unauthorized in any jurisdiction that does not give effect to all provisions of these terms and conditions, including without limitation this paragraph.

2.8 Modification of Terms and Conditions

Coraltec Inc. reserves the right to change the terms, conditions, and notices under which their products are offered.

2.9 Entire Agreement

The TERM OF USE, WARRANTY AND DISCLAIMER document states the entire obligation of Coraltec Inc. with respect to the products. If any part of this disclaimer is determined to be invalid, void, unenforceable or illegal,

including, but not limited to the warranty disclaimers and liability disclaimers and liability limitations set forth above, then the invalid or unenforceable provision will be deemed superseded by a valid, enforceable provision that most closely matches the intent of the original provision and the remainder of the agreement shall remain in full force and effects.