



CE

Breakfast trolleys

Original user guide

Issue: 2010-01-12

Rieber

Breakfast trolley – mobile body

For internal transport and breakfast distribution / sale.

1. Introduction

This guide contains important information about how you can use the product safely and correctly.



IMPORTANT

Protect yourself against potential hazards and prevent damage to your product.

- In any case, read the user manual before using the product for the first time.
- Keep this user guide in a safe place and pass it onto the next owner should you wish to part with the product.

Customers have often expressed their demand for a compact manual, as an alternative to numerous instructions for product variants with similar functions.

If there are any deficits from your point of view, please do not hesitate to let us know. With your help, we will try to get even better.

Address of manufacturer:

Rieber GmbH & Co. KG
Hoffmannstraße 44
D-72770 Reutlingen
Germany

Internet www.rieber.de
Email info@rieber.de
Tel +49 7121 518-0
FAX +49 7121 518-300

Contents

1. Introduction	2
2. Description of product	3
2.1 Brief description of appliances	3
2.2 Identification of components	4
2.3 Accessories and their use.....	4
3. Purpose of breakfast trolleys	4
4. General safety instructions	5
4.1 Basic rules	5
4.2 Appliance-specific safety instructions	5
4.4 Information about regulations to be followed	5
5. Before use	6
5.1 Transport	6
5.1.1 Check/handle any transport damage	6
5.1.2 Unpacking.....	6
5.1.3 Dispose of packaging material	6
5.1.4 Clean the appliance	6
5.2 Commissioning / recommissioning	6

6. Use of breakfast trolley.....	6
7. General information on using the product.....	7
7.1 Keep to the basic rules for operating the product	7
7.2 Accessories and their use.....	7
7.3. Before use	7
7.4. After use	7
8. Cleaning and maintenance.....	7
8.1 Choose the correct cleaning method	7
8.2 Clean and service stainless steel parts.....	7
8.3 Clean and service plastic parts	8
8.4 Dry the appliance to keep it ready its next use	8
9. Fault - What now?	8
10. Warranty and liability.....	8
11. Information about applicable standards, laws, guidelines.....	8

2. Description of product

2.1 Brief description of appliances

The following breakfast trolleys are available:

Type	Description	Support rails	External dim.	Weight in kg	Load capacity in kg
FSW-2-OSL	2 parts, without drawer	2 x 7	866x627x1080	28	120
FSW-2-1SL	2 parts,1 drawer	1x7 x 1 x 6	866x627x1080	30	120
FSW-2-2SL	2 parts,2 drawers	2 x 6	866x627x1080	32	120
FSW-3-OSL	3 parts, without drawer	3 x 7	1228x627x1080	38	120
FSW-3-1SL	3 parts,1 drawer	1 x 7, 1 x 7, 1 x 6	1228x627x1080	40	120
FSW-3-2SL	3 parts,2 drawers	1 x 7, 1 x 6, 1 x 6	1228x627x1080	42	120
FSW-3-3SL	3 parts,3 drawers	3 x 6	1228x627x1080	44	120

2.2 Identification of components

Identifies the parts which are important for understanding the subsequent sections.



- 1 Body of chrome nickel steel with integrated control casing, equipped with
1. Swivel caster with brake
2. Corner bumper
3. Support rails for holding trays or GN containers
4. Lockable drawer
5. fold-down board (accessory)
6. Pushing handle

2.3 Accessories and their use

The following accessories are available for the breakfast trolleys:

- 3-sided gallery made from rounded stainless steel material
- 3-sided resopal panelling, choice of colours
- Fold-down shelf, 300 x 560 mm on the left face side, mounted 900 mm high from stainless steel
- Clearing container, suspended, 21 litres, 345 x 245 x 270 mm

3. Purpose of breakfast trolleys

Generally, the following are intended uses for the product:

- For mobile meal services in catering, hotels and restaurants; also for managed care facilities and schools.
- For use by adults only. For use by instructed persons only.
- Comply with hygiene requirements according to HACCP.

Prevent any potential misuse in advance:

- **WARNING!** Never operate the product unsupervised.
- Not intended for private use at home.
- Do not lean against or sit on this product.
- Keep any combustible or explosive fluids away from heatable appliances. Otherwise a fire or explosion may arise.

4. General safety instructions

This section covers residual risks and hazards associated with the intended use of the product. We have provided a list of all generally valid safety instructions which must be followed. Safety information relating to a particular operation or situation are placed before the appropriate operation step or description of the situation in the following section.

4.1 Basic rules

This product meets the current state of the art and complies with all acknowledged technical safety-related regulations. Nevertheless hazards may still arise.

- Only use this product when it is in fault-free condition and according to the instructions in this user guide.
- During all phases of the product's life please ensure that the product is safely integrated into its environment.
- Do not make any conversions or modifications to the product.

Service

- **Only have the device repaired by qualified and authorised staff. Only use original spare parts.** In this way you can ensure that the appliance remains safe.



CAUTION

indicates potential damage to property without any damage to persons. Failure to follow these instructions may cause damage to property.

4.2 Appliance-specific safety instructions

This section provides information on general product-specific safety instructions of the appliances of these modular product series. In the following section, additional safety information relating to a particular operation or situation is placed before the appropriate operation step or description of the situation.

- Only move appliance with its drawers closed
- Only move appliance with trays fully pushed in
- Before working at the breakfast trolley, apply parking brake

4.4 Information about regulations to be followed

Alongside this user guide there are a range of health and safety and other regulations that are relevant for the operation of this cooking station; these include HACCP food hygiene regulations for example.

5. Before use

5.1 Transport

5.1.1 Check/handle any transport damage

- Immediately after delivery, visually check the appliance for any transport damage.
- Document any potential transport damage on the consignment note in the presence of the haulage contractor.
- Have the damage confirmed by the haulage contractor (with signature).
- Decide: Keep the appliance and report damage with consignment note or reject the appliance.
- This procedure ensures proper loss adjustment.

5.1.2 Unpacking

- Remove any packaging residues. When doing this, follow the product-specific instructions given on the dispatch note / label on the appliance.
- Open transport packaging at the positions provided for this purpose. Do not tear or cut.
- Check scope of delivery using the dispatch note.
- Remove any protective foils from the appliance.

5.1.3 Dispose of packaging material

- Dispose of packaging material in a proper and environmentally compatible manner.

5.1.4 Clean the appliance

- Clean the appliance thoroughly before using for the first time.
Clean with a damp cloth and rub dry with a clean cloth.
Rinse the accessories.

5.2 Commissioning / recommissioning

- Appliance has no defects or visible damage.
- Appliance has room temperature and is dry.

6. Use of breakfast trolley

General:

- Always use the pushing handle when moving the breakfast trolley.
- When transporting the appliance, ensure that the drawers are closed and trays are fully pushed in.
- Secure load before transport.
- Before working at the breakfast trolley, apply parking brake.
- Do not overload the trolley. The maximum carrying capacity is 120 kg in all models.



Note!

Wrong loading and moving on uneven surfaces may cause material damage

7. General information on using the product

7.1 Keep to the basic rules for operating the product

- Never operate the appliance unsupervised.
- Comply with hygiene requirements according to HACCP.
- Keep the product in a clean and hygienically spotless condition.

7.2 Accessories and their use

Ensure the accessories are operational.

7.3. Before use

Ensure that you are familiar with the product-specific use.

7.4. After use

Clean the appliance.

8. Cleaning and maintenance

This chapter will help you to meet with the hygiene requirements. Before reading this section, please read through the "General safety instructions" section thoroughly first.

8.1 Choose the correct cleaning method



Note!

Improper cleaning can damage or even destroy the appliance.
Improper cleaning can cause damage to the surface.

- Note: Not suitable for dishwasher cleaning, do not clean with high-pressure cleaning equipment.
- Be careful not to scratch the surface with sharp-edged objects. Do not use any abrasive or aggressive cleaning agents, e.g. oven sprays or a sponge with an abrasive side.
- Do not use any cleaning agents containing sand, sodium, acid or chloride or solvents.
- Do not use any cleaning agents containing acids. Cleaning agents must not contain any hydrochloric acid or hydrofluoric acid, as these acids might result in decolouration of the surfaces and even corrosion.

8.2 Clean and service stainless steel parts



Note!

Improper cleaning can cause damage to the surface.

- Clean the appliance with a mild detergent diluted in hot water. After cleaning, rub surfaces dry with a soft cloth.

User tip

- We recommend Rieber cleaning agent for stainless steel for cleaning stainless steel.
- Is an especially tough yet **soft** cleaner, produces a dazzling shine, cleans and protects in one.

8.3 Clean and service plastic parts



Note!

Improper cleaning can cause damage to the surface.

- Clean the appliance with a mild detergent diluted in hot water. After cleaning, rub surfaces dry with a soft cloth.

8.4 Dry the appliance to keep it ready for next use

- Dry the appliance. Allow residual moisture to escape.
- Store appliance at room temperature.

9. Fault - What now?

Fault:	Possible cause:	Possible remedy:
Wheel jammed	Wheel defective	Replace wheel
Drawer tight	Insufficient lubrication	Lubricate guide

Customer service, spare parts

If you have a fault you cannot remedy yourself, please get in touch with your Rieber dealer or the Rieber factory customer service (for address refer to page 2)

Disposing of your product

Your appliance is made of high-quality material which can be reused / recycled. For disposal, disconnect the appliance from mains supply. Unplug the mains plug. Cut off the cable directly at the casing. Dispose of the product properly via your local disposal facility.

10. Warranty and liability

Manufacturer liability and warranty shall no longer apply if

- the information and instructions in this user guide were not followed,
- the product was not used as per the specifications,
- conversions or functional modifications were made,
- non-original spare parts were used.

The "Sales and delivery terms and conditions" of Rieber GmbH & Co. KG shall apply for all warranty claims made against the manufacturer.

11. Information about applicable standards, laws, guidelines

Directive EC 852 / 2004	on food hygiene	
DIN EN 18867 - 4	Tray - clearing trolleys	
DIN EN 18867 - 8	Casters	