



Manual



LED Pool Ball 25 RGB
IP68

Table of contents

1. Safety instructions	3
1.1. FOR SAFE AND EFFICIENT OPERATION	3
2. Designated use	4
3. Introduction.....	5
4. The first steps.....	5
4.1. Before using.....	5
4.2. Control	5
5. Technical data	6

1. Safety instructions



- This device is suitable for outdoor use. But it is NOT allowed to charge it outdoors.
- All modifications to the device will void the warranty.
- Repairs are to carry out by skilled personnel only.
- Use only original parts as spare parts.
- Make sure to unplug the power supply before opening the housing.

1.1. FOR SAFE AND EFFICIENT OPERATION

Be careful with heat and extreme temperature

Avoid exposing it to direct rays of the sun or near a heating appliance.
Not put it in a temperature below 32°F /0°C, or exceeding 104°F /40°C.

To avoid placing on un-stable location

Select a level and stable location to avoid vibration.

Do not use chemicals or volatile liquids for cleaning

Use a clean dry cloth to wipe off the dust, or a wet soft cloth for stubborn dirt.

If out of work, contact sales agency immediately

Any troubles arose, remove the power plug soon, and contact with an engineer for repairing, do not open the cabinet by yourself, it might result a danger of electric shock.

Take care with the power cable

Never pull the power cable to remove the plug from the receptacle, be sure to hold the plug. When not using the device for an extended period of time, be sure to disconnect the plug from the receptacle.

Important:

Damages caused by the disregard of this user manual are not subject to warranty. The dealer will not accept liability for any resulting defects or problems. Make sure the electrical connection is carried out by qualified personnel. All electrical and mechanical connections have to be carried out according to the European safety standards.

2. Designated use

Regular breaks during operation increase the lifetime of your device.

Avoid convulsions or any form of forceful impact during the installation or the start-up of the device.

Operate the device not during thunderstorms. Surge voltages could destroy the device. Unplug the power supply during thunderstorms.

Make familiar yourself with the functions of the device before start-up. People without the experience should not handle with the device. The most cause of functional disorder is inappropriate handling.

Do not use chemicals or volatile liquids for cleaning. Use a clean dry cloth to wipe off the dust, or a wet soft cloth for stubborn dirt.

For transport use the original packing or designated accessory to avoid damages during the transport.

For reasons of safety unauthorized changes are forbidden.

A usage of the device which differs from usages which are described in this manual can cause damages of the device. In that case the warranty expires. Additional you should notice that every differed usage is related with dangers and can cause e.g. an electrical short, fire, electric shock or crash.

3. Introduction

When we send out the goods, they are well packaged and also at best condition. Every product was tested before delivery. If you recognize mistakes or damages please contact the delivery agent or the supplier. Please read this manual faithful. In this manual you can find information about the handling and the safety regulations of this product. If you disregard this manual we cannot give a warranty for it. Technical changes, which are for progress, may be possible at any time. They are not mentioned particularly in this manual, but affixed extra.

4. The first steps

4.1. Before using

1. Charge the device in a dry room.
2. Place the device on a flat surface.
3. Make sure to power off the light before charging.
4. Clean the charging station and the surface of the device with a dry and clean cloth.
5. Set the device on the charging station and connect the external adapter to the electrical outlet. It will begin to charge and indicator light on the furniture will change to red. Indicator light changes to green when the battery is fully charged. Before first use, charge the battery for 4-8 hours.

4.2. Control

1. On the bottom of the device is a „On/Off“ button. Press it for 2 seconds to power the device on/off. You can also power the device on by pressing the “On” button on the IR remote, or power it off by pressing the “Off” button on the IR remote.



- Before the first operation remove the plastic sheet of the battery.
- Always power off the light after use.
- Do not throw the appliance in the pool. Put it carefully on the water
- Never use a pool if at the same time swim the device people in the pool.
- Keep the remote control away from water, heat and fluids.
- Take the device out of the water when it is not used.
- Never use the device if it is damaged.

5. Technical data

Power supply	
Power consumption max.	6 W
Battery	Accu Li-ion / 3,7 V / 2000 mAh
Light source	
LM type	LED 3 in1
Color spectrum	RGB
Controlling	
Automatic	Yes
IR remote control	Yes
Hardware	
Protection class	IP68
Dimensions (L/B/H)	250 x 250 x 230 mm
Weight	0,94 kg

Importer:

B & K Braun GmbH
Industriestraße 2
D-76307 Karlsbad
www.bkbraun.com
info@bkbraun.com

