

PREMIUM E-CIGARETTES Vapage®

USER GUIDE

TITAN

PERSONAL VAPORIZER



WELCOME TO VAPAGE.COM -YOUR PREMIUM VAPING OUTFITTERS

Congratulations on purchasing your new Vapage product. We hope you have many hours of enjoyment. Before you use your Vapage product, please read the user manual to fully understand the product. This will help you to achieve the best performance from your new product.
The manual should be kept in a safe place for future reference.

KIT CONTAINS:

- | | |
|-------------------|-------------------------------------|
| 1-650mAh battery | 1-USB wall charger |
| 1-1300mAh battery | 1-Blank Cartomizer |
| 1- USB charger | 2-Pre-filled Cartomizers (TOB 18mg) |
| 3- Mouthpieces | |
| 1- User Manual | |

FEATURES

- The Titan is uniquely designed incorporating the latest technology for easy charging, and long lasting battery life to maximize vapor performance.
- The Titan system comes with two 3.7 volt Li-ion rechargeable Batteries: a 650mAh and a 1300mAh.
- The expected duration for one charge depends on usage, but average “in use time” should be between 5 to 10 hours .
- Titan charging is through a USB charger, and flat wall adapter included in the box.
- Recharge time is around 7 hours for a completely drained battery.
- Huge refillable cartomizers insure long vape times, and long lasting cartomizer.
- Titan Stainless Steel outer shell is durable, and retains its luster.

WARNING:

- DO NOT charge any other batteries on the charger provided with you kit.
- DO NOT charge the Titan battery on another charger – It may damage the battery.
- DO NOT dismantle battery compartment yourself. Opening will result in malfunction. Tampered products will not be accepted for claims.
- If the indicator light stays on continuously or the product becomes hot —immediately disconnect battery from cartridge to break the electrical connection
- ALWAYS keep the battery dry and away from moisture.

TITAN ASSEMBLY & USAGE:

The Titan consists of three main parts: battery, cartomizer, and mouthpiece. To assemble, start by screwing the cartomizer onto the battery. Do not use force when doing this, and do not over tighten the cartomizer, Just screw it on until you feel it bottom out. If there is force, inspect for dirt or damage to the threads. It is always best to check and clean the threads and contact points with paper towel first. Check to make sure there is e-liquid in the cartomizer, and the mouth-piece is correctly installed (all the way in, and not at an angle), now your Titan is ready for use. Simply take a puff, and the Titan tip will light up to indicate it is working; the Titan is an auto switch design. You are now using your Titan...Happy Vaping

OPERATION TIPS:

- When puffing on your Titan, the battery light will be blue, letting you know it is on. When the light flashes 3 times, this means the draw limit has been reached and it has turned off (usually 7-10 seconds).
- When the battery needs to be recharged the light will flash many times letting you know it’s time to recharge.
- While using your product, and there’s a reduced flavor or vapor. This indicates the e-liquid needs to be replaced or refilled. If you experience a burnt taste, you should immediately discontinue use, and refill with e-liquid. If after refilling, and there’s still a burnt flavor still, this may indicate that the heating element is bad, and needs to be replaced.
- Periodically check the thread area for e-liquid build-up. If the area has liquid around the threads or contact points, this will reduce performance. It is best to occasionally wipe this area with a towel to keep it clean and keep performance at its premium. At the same time remember to clean off the contact points of the atomizer or cartomizer threads.

CHARGING

The battery needs to be recharged when the unit produces a decreased vapor and or the battery indicator light blinks three times. To charge, unscrew the battery from the vaping components, then screw the battery onto the USB charger included with your kit. Insert the USB charger into the supplied wall charger, or USB port of your computer. The battery should flash five times and then turn solid in color. The charger should turn from green to red, indicating the battery is charging.
Once the light on the charger turns green; your Battery is now ready and fully charged.

PRECAUTIONS

We do not accept any warranty claims where there is a case of tampering with product. If you are carrying our product with you, please carry separately in order to avoid damage. The use of any non Vapage components could lead to the malfunction and damage of this product. Warranty claims for scratches on the body or components will not be accepted. For your safety, make sure that you do not leave product unattended while it is recharging. Keep away from high temperature and / or humid environments. Keep the device and its components out of children’s reach and avoid improper operation.

In the case of product problems please go www.vapage.com and either email or phone with your questions.