



User Manual V.1
Smart-G4 Android App
Beta




Figure 1
Landing Page of the app




Figure 2
Messages tab, here you can receive notifications on your mobile device or if you are in a community you can send or receive messages.




Figure 3

Security tab, here you can arm, disarm your Smart-G4 system.




Figure 4

In order to arm your Smart-G4 system, you need to enter the correct pin code if successfully entered you will be able to change the security state of the app.




Figure 5

To choose a room click on the “Home” tab on the top left corner of the app




Figure 6

As soon as you enter a room, the Lights tab will appear. You will be able to turn on/off and dim lights as you wish.




Figure 7

As soon as you choose your desired mood you can save the scene from the top right corner button.




Figure 8

Enter the name of the scene




Figure 9
Enter the name of the scene




Figure 10
The scene will automatically appear in the Lighting Scenes tab, when you press the “Reading” button it will restore the room’s lighting to your favorite mood.




Figure 11

To delete a scene keep on pressing the scene's button for 3 seconds a popup will appear click on "Delete Scene" to delete to cancel click "Return".




Figure 12

After you click on "Delete Scene" the scene will be deleted and eventually the "Lighting Scenes" tab will be removed automatically.




Figure 13

The Motors tab is for any motorized object, you can Open, Close and stop blinds and shutter as you wish.




Figure 14

In the "Air Conditions" tab you will be able to view current temperature in the room, change from heat, cool and fan and increase or decrease the set temperature of the room.




Figure 15

Under the “Nuvo Audio” tab you will be able to turn the music’s volume up and down, change sources, mute the system on and off and even turn your zone on and off.




Figure 16

Changing your source on your “Nuvo Audio” tab




Figure 17
Muting audio on your "Nuvo Audio" tab




Figure 18
The default edit button the Android shows a hidden menu.




Figure 19

To update your current configuration enter your Username and Password from your installer to update. Your mobile device needs to be connected to the Internet.




Figure 20

To change your security pin code you need to enter your old pin with your new desired pin.