

Operating Instructions P7805 Animal Chaser™

Congratulations on your purchase of the Animal Chaser™. Please read these operating instructions thoroughly before use. It is important for proper use of the product.

The Animal Chaser™ provides a convenient portable effective and humane way, to deter cats, dogs, even raccoons from your garden, yard and lawn without harm.

The Animal Chaser™ utilizes a sophisticated PIR (passive infrared) detection system to monitor a fan-shaped area with a 70 degree arc and a range up to 22 feet. When an animal enters the large area covered by the infrared sensor, the Animal Chaser™ produces a sound that is very unpleasant to animals but inaudible to the human ear. The unit switches off automatically when the animal has left the area for extended battery life.

WARNING

! Turn off the Animal Chaser™ if your pet is playing in the protected area. !

! When people are active in the protected area, turn off the unit to preserve battery life. !

! Do not immerse the unit in water or any other liquid. !

! Do not modify or tamper the unit or its internal components. Covering or painting over the front speaker grill can damage the unit and cause it to malfunction. !

! For best function keep the PIR lens clear. Use a damp cloth to wipe the lens. Do not use benzene, alcohol or paint thinner.

Features:

- **LED Lamp:** Indicates the unit has detected motion.
- **Test button:** Indicated by a check mark graphic. Press the button to test the unit's function. While the button is pressed the sound will be changed so that it is audible to humans. Unit will return to normal function when the button is released.
- **On/Off switch:** Indicated by "1" (On) and "0" (Off).
- **DC Power input:** Optional. Connect an external AC/DC adapter to power unit instead of using batteries.
- **Battery compartment:** Remove 2 screws and insert 6X AA batteries. Use only fresh alkaline batteries for best results. Dispose of exhausted batteries properly.
- **Mounting clip:** Use included screws and anchors (optional) to attach clip to a fixed surface with wider portion facing outwards. Attach Animal Chaser™ unit to clip by sliding over wings on mounting clip.

Use

- Remove 2 screws and insert 6X AA batteries.

- Turn the power switch to the "On" position (indicated by a "1")
- Allow a few moments for the PIR sensor to settle.
- When the unit detects motion, the LED indicator will light and the active sound will be generated.
- To verify correct speaker operation, press the test button (indicated by a check mark). Unit will temporarily change the sound range to be audible by humans. Release the test button to return to normal operation.
- Install unit aimed towards area to be covered. Unit will automatically respond to detected motion and generate audio signal which will disturb and drive away animals.

Specifications:

Model:	P7805
PIR Area Covered:	up to 295 sq. feet
Audio Frequency:	18Khz to 24Khz. up to 90dB
Power Supply:	6x AA batteries or 9VDC Adapter (not included)
Weight:	4.6 oz.
Dimensions:	3/4" x 5 1/2" x 2" (HxWxD)

Specifications subject to change without notice

P3 INTERNATIONAL CORPORATION LIMITED WARRANTY

P3 INTERNATIONAL CORPORATION ("P3") warrants to the original retail purchaser only that its product is free from defects in material or workmanship under the condition of normal use and service for a period of six (6) months from the date of purchase. In the event that a defect, malfunction or failure occurs or is discovered during the warranty period, P3 will repair or replace at its option the product or component part(s) which shall appear in the reasonable judgment of P3 to be defective or not to factory specifications. A product requiring service is to be returned to P3 along with the sales receipt or other proof of purchase acceptable to P3 and a statement describing the defect or malfunction. All transportation costs shall be borne by the owner and the risk of loss shall be upon the party initiating the transportation. All items repaired or replaced thereunder shall be subjected to the same limited warranty for a period of six (6) months from the day P3 ships the repaired or replaced product. The warranty does not apply to any product that has been subject to misuse, tampering, neglect, or accident or as a result of unauthorized alterations or repairs to the product. This warranty is void if the serial number (if any) has been removed, altered, or defaced. This warranty is in lieu of all warranties expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose which are expressly excluded or disclaimed. P3 shall not be responsible for consequential, incidental or other damages, and P3 expressly excludes and disclaims liability for any damages resulting from the use, operation, improper application, malfunction or defect of any P3 product covered by this limited warranty. P3's obligation is strictly and exclusively limited to the replacement or repair of any defective product or component part(s). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. P3 does not assume or authorize anyone to assume for it any other obligation whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you. It is the owner/user's responsibility to comply with local, state, or federal regulations, if any, that may pertain to P3 products or their use. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

If you experience difficulty in the operation of your product, or if your product requires service please contact:

P3 INTERNATIONAL CORPORATION
TECHNICAL SUPPORT
Tel: 212-741-7289 Fax:
212-741-2288
Email: techsupport@p3international.com

rev. 0713