

GIK10

ELECTRIC INSECT KILLER - 4 UV LEDs



USER MANUAL

USER MANUAL

1. Introduction

To all residents of the European Union

Important environmental information about this product



This symbol on the device or the package indicates that disposal of the device after its lifecycle could harm the environment. Do not dispose of the unit (or batteries) as unsorted municipal waste; it should be taken to a specialized company for recycling. This device should be returned to your distributor or to a local recycling service. Respect the local environmental rules.

If in doubt, contact your local waste disposal authorities.

Thank you for choosing Pere! Please read the manual thoroughly before bringing this device into service. If the device was damaged in transit, don't install or use it and contact your dealer.

2. Safety Instructions

	Keep the device away from children and unauthorised users.
	Never insert metal objects into the device: risk of electroshock. Touching live wires can cause life-threatening electroshocks.
	Do not use in areas where explosive gasses reside.
	Do not stare into the light source or permanent eye damage might occur.
	Always disconnect mains power when the device is not in use or when servicing or maintenance activities are performed. Handle the power cord by the plug only.

3. General Guidelines

Refer to the **Velleman® Service and Quality Warranty** on the last pages of this manual.

	Indoor use only. Keep this device away from rain, moisture, splashing and dripping liquids.
	Keep this device away from dust and extreme heat.
	Protect this device from shocks and abuse. Avoid brute force when operating the device.

- Familiarise yourself with the functions of the device before actually using it.
- All modifications of the device are forbidden for safety reasons. Damage caused by user modifications to the device is not covered by the warranty.
- Only use the device for its intended purpose. Using the device in an unauthorised way will void the warranty.
- Damage caused by disregard of certain guidelines in this manual is not covered by the warranty and the dealer will not accept responsibility for any ensuing defects or problems.
- Do not clamp or shorten the power cord and protect it against damage. Have an authorised dealer replace it if necessary.

4. Operating Instructions

IMPORTANT: Never touch the metal grid with your bare hands! If you need to clean the tray, follow the safety instructions carefully.

a. Switch the device ON/OFF

- Plug the power cord into a suitable mains outlet.
- Move the switch on the back of the device to the ON-position. The LEDs go on and the fan starts turning.
- To switch the device off, move the power switch to the OFF-position.

b. Discharging the device before maintenance

GIK10

- Unplug the device from the mains.
- Use a screwdriver with an insulated handle. Make sure you only hold the screwdriver by the handle.
- Short-circuit the 2 wires of the inner metal grid by gently touching them simultaneously with the metal shaft of the screwdriver. A spark may arise. Repeat this manipulation until no more sparks arise.

c. Cleaning the device

- Clean the insect killer regularly with a dry, clean cloth and plastic brush.
Do not submerge into any liquid.
- Make sure no dust accumulates on the LEDs as this will greatly reduce their effectiveness.
- Discharge the device.
- Remove the plastic grid:
push on the top lid of the grid (see arrow) and pull.
- Only use a plastic brush to clean the high-voltage grid. Brush gently to avoid damage.
- Place the plastic front grid back. Insert the bottom protrusion in the notch and click the grid in place.



d. Maintenance

- All screws should be tightened and free of corrosion.
- The housing and its accessories should not be deformed.

5. Technical specifications

input voltage	230VAC / 50Hz
grid voltage	800-1000V
effective area	50m ²
lamp	4 x water clear 5mm UV LEDs
dimensions	255 x 230 x 85mm
weight	975g

Use this device with original accessories only. Velleman nv cannot be held responsible in the event of damage or injury resulted from (incorrect) use of this device. For more info concerning this product, please visit our website www.perel.eu. The information in this manual is subject to change without prior notice.

© COPYRIGHT NOTICE

This manual is copyrighted. **The copyright to this manual is owned by Velleman nv.** All worldwide rights reserved. No part of this manual may be copied, reproduced, translated or reduced to any electronic medium or otherwise without the prior written consent of the copyright holder.