

LED DIGITAL DISPLAY LIGHTS

USER MANUAL



Led Par light 18*10w RGBW 4 in 1

Please read this manual carefully before use!

Thank you for purchasing this product.

To optimize the performance of this product prior to use, please read these operating instructions carefully to familiarize yourself with the basic operation of this unit.

Please keep the manual in a safe place for future reference.

This unit has been tested at our factory before being shipped to you, there is no assembly required.

Please take and put carefully once received this product.

Please check cautiously that whether the product was damaged or not during the transportation.

Checking Parts


Please check if the following parts are included:

1 x LED Light

1 x Power cable

1 x User manual

Installation




1. Please check the voltage whether is the same with the one showed on the equipment or not.
2. It must ask for the technical person and set the light safety when installation. And let the light beam at the suitable angle.
3. When install this equipment please make sure there's no flammable surfaces (decorated things, etc) within at least 2.5M and maintain minimum distance of 0.5M from the equipment to the walls.
4. Please make sure that there's no other equipment or decorating materials obstructed the exhaust fan and the vent-pipe.
5. Products should be install immobility.
6. In case of safety, it's very important that to connect the earth with line.

Attention



1. Please do not open the bottom cover yourself without permission.
Operate it accord the user manual. Call the technician when the machine breaks down.
2. Please do not see the led beam directly to avoid any damage.
3. This unit can be use in the outdoor with waterproof IP65.
4. Set the light immobility and try to avoid strong shake or hit.
5. Prevent dust into the equipment to avoid problems.
6. Please keep that there's no other equipment or decorating materials obstructed the exhaust fan and the vent-pipe when the equipment was working.
7. Before connect power, check the plug is immobility or not, power line should be connect well.
8. Please do not open or close the equipment frequently that's to avoid any affect to the life span of the led, and try the best to avoid the long time working.
9. Don't touch the light or draw the power line when your hand was wet.
And do not pull the electronic power line.
10. Maintain the distance at least 3M above from the equipment to the object.
11. This equipment does not have any parts can repair for the users, please do not open the equipment.
12. When the led became dim or damaged please contact the dealer timely.
13. When you want to retransfer the products, you'd better use the original package to shockproof.

1.As Imagic



- A. Fn
- B. Up
- C. Down
- D. Enter

Operating instructions:

Press Key A to get 8 of different function effects.

The first 2 number of the digital pipe stand for the present function(see the function table).

The last 2 number stand for the parameter of swift code or address code of the Present function.

Press B or C to change its parameter

Press D to Affirm.

2. LED displayer Function table

(Choose the function then press Key"D" to Affirm is ok)

No.	Display	Function
1	D001	7CH mode, (001—512) B、 C to adjust value
2	CC50	Color Jump, (01—99) B、 C to adjust speed
3	CP50	Color change gradually, (01—99) B、 C to adjust speed
4	DE50	Color change, (01—99) B、 C to adjust speed
5	BEBE	Sound mode
6	R255	Red color, (000—255) B、 C to adjust density
7	G255	Green color, (000—255) B、 C to adjust density
8	B255	Blue color, (000—255) B、 C to adjust density
9	W255	White color, (000—255) B、 C to adjust density

3. DMX512 Channel Instruction Manual

No.	Function	Description
CH1	Dimmer	R、G、B、Wdimmer from dark to bright
CH2	Strobe	R、G、B、W strobe from slow to fast
CH3	Function choose	0—50: DMX 8CH mode; 51—100: color jump; 101—150: color change gradually; 151—200: color pulse; 201—255: Sound
CH4	Speed	Speed from slow to fast
CH5	R dimmer	Red linear dimmer, from dark to bright
CH6	G dimmer	Green linear dimmer, from dark to bright
CH7	B dimmer	Blue linear dimmer, from dark to bright
CH8	W dimmer	White linear dimmer, from dark to bright

4. Function Feature:

Voltage:	110-240V
Power:	200W
Light source:	18pcs x 10W High brightness lamp bulb
Channel:	7CH
Function:	Digital displayer
Control method:	Sound control, Automatic, Strobe, Master & slave

5. Function Feature:

Easy Operation ,Humanity Design, Dimming without strobe or shake.

Can use for record Video, photograph or television (broadcast) station etc. occasion.

Maintenance

Maintenance should be performed every 15-day period, by using a sponge which is dipped with alcohol, rather than wet cloth or other chemical liquid, to clean the led.

Always disconnect from the mains when the device is not in use or before cleaning it.

Warning

Power must be disconnected before maintenance or repair. Do not look at the light source

To prevent or reduce the risk of electrical shock or fire. do not expose this unit to high temperature/rain or moisture.

Note

Don't separate device and repair them by yourself, otherwise no good repair service will be supplied.

Declaration

This device has left our premises in absolutely perfect condition. In order to maintain this condition and to ensure a safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes written in this user manual.

We cannot be made liable for damages caused by incorrect installations and unskilled operation!

Thank you very much for reading !