





**COMMERCIAL BOOSTER WATER HEATER
REPLACEMENT PARTS LIST
MODELS SBD 30 150 & SBD 30 199**



STATE WATER HEATERS

500 Lindahl Parkway, Ashland City, TN 37015
Phone: 800-821-2017 • Fax: 800-644-9306
www.statewaterheaters.com

| Item | Description | SBD 30 150 | SBD 30 199 |
|---------------------------|--|------------------|------------|
| 1 | Baffle, Flue | 195342 | 195342 |
| 2 | Base, Jacket Assembly | 194068 | 194068 |
| Blower Assembly: | | | |
| 3 | Blower | 194408 | 194408 |
| 4 | Outlet Assembly, Exhaust | 194424 | 194424 |
| *5 | Screw, TEK (Jacket-Cover/Base) | 194613 | 194613 |
| 6 | Burner, Orifice Bracket, Main | 98044 | 98044 |
| 7 | Burner Orifice, Main - Natural | 76243-39 | 76243-32 |
| 7 | Burner Orifice, Main - LP | 76243-52 | 76243-50 |
| 8 | Burner Assembly, Main | 192322 | 192322 |
| 9 | Burner w/Ignitor Bracket, Main | 195712 | 195712 |
| 10 | Bushing | 193404 | 193404 |
| Cleanout Assembly: | | | |
| 11 | Gasket | 99038 | 99038 |
| 12 | Pressure Plate | 99037 | 99037 |
| #13 | Screws, Machine | 69852-1(6) | 69852-1(6) |
| 14 | Control, Ignition Assembly | 194392 | 194392 |
| 15 | Cover, Burner | 98185-2 | 98185-2 |
| 16 | Cover, Cleanout | 181260 | 181260 |
| 17 | Cover, Control Box | 194395 | 194395 |
| 18 | Cover, Inner | 194388-8 | 194388-7 |
| 19 | Cover, Jacket | 194389 | 194389 |
| 20 | Collar, Pipe Nipple | 74060 | 74060 |
| 21 | Floor Shield Assembly | 193984 | 193984 |
| 22 | Ignitor, Flame Sensor | 195708 | 195708 |
| 23 | Insulation, Top | 194439 | 194439 |
| Labels: | | | |
| *24 | Cleanout | 193914 | 193914 |
| *25 | Flammable Vapors | 192872 | 192872 |
| *26 | Help Line | 190600 | 190600 |
| *27 | Instruction | 170345 | 170345 |
| *28 | Instruction, Bilingual | 193912 | 193912 |
| *29 | Instruction, ECO | 192282-1 | 192282-1 |
| 30 | L&O Label | 194401 | 194401 |
| *31 | Sandblaster | 195123 | 195123 |
| *32 | Relief Valve | 200042 | 200042 |
| *33 | Ultra Coat | 193860 | 193860 |
| *34 | Water Inlet | 161040 | 161040 |
| *35 | Water Outlet | 161040-1 | 161040-1 |
| *36 | Wiring Diagram | 194400 | 194400 |
| 37 | Leg | 194115 | 194115 |
| 38 | Manifold | 76244-2 | 76244-2 |
| *39 | Manual, Instruction | 196308 | 196308 |
| 40 | Plate, Mounting | 194391-000 | 194391-000 |
| 41 | Probe/ECO, Upper Thermostat | 194396 | 194396 |
| 42 | Probe/Lower Thermostat | 194397 | 194397 |
| 43 | Rod, Anode | 183523-16 | 183523-16 |
| 44 | Switch, Blower Prover | 194411-5 | 194411-5 |
| 45 | Switch, Low Gas Pressure - Natural | 191149-5 | 191149-5 |
| 45 | Switch, Low Gas Pressure - LP | 191149-4 | 191149-4 |
| 46 | Switch, Off/On | 193243 | 193243 |
| 47 | Thermostat, Digital | 195437 | 195437 |
| 49 | Tube, Outlet | 192627-1 | 192627-1 |
| 50 | Valve, Drain | 26273-4 | 26273-4 |
| 51 | Valve, Gas - Natural | 194536-1 | 194536-1 |
| 51 | Valve, Gas - LP | 194536-3 | 194536-3 |
| 52 | Valve, T&P | 99465-7 | 99465-7 |
| *53 | Wire Harness - Control | 194545 | 194545 |
| *54 | Wire Harness - Power | 194399 | 194399 |
| 55 | Hydro-Cannon | 195098 | 195098 |

*Items not illustrated. # Quantities shown in parenthesis next to part number. TBD To be determined.

Part numbers underlined are recommended stock items for emergency replacement. (Consider gas used in your area only).

Requests from PSD by giving all information such as model and series number, type of gas and specifications.

STATE WATER HEATERS
500 Lindahl Parkway, Ashland City, TN 37015
Phone: 800-821-2017 • Fax: 800-644-9306
www.statewaterheaters.com

