

VIDPEEP.COM

DDV1 User Manual



Specifications:

- 1- Screen size: 3.2 inch LCD
- 2- View angle: 160 degree
- 3- Sensor: 1.3 Mega Pixel CMOS
- 4- Power Source: 3 AAA batteries (good for approx 3000 peeps)
- 5- Size: 115 (W)x62(H)x16(D)mm
- 6- Net weight: 199g
- 7- Door thickness: 68-94 mm
- 8- Fits barrel hole: 14-28 mm
- 9- Materials: plastic and steel/brass
- 10- Certificates: CE FCC ROHS

Operation:

- 1- Press the power button, the unit will continue working for about 10 seconds. Then it will turn off automatically.
- 2- The batteries will last for about 4-6 months. If the image becomes blurred, please replace the batteries.

Attention: Read before using

- 1- DO NOT disassemble the camera or the mainframe. THIS WILL VOID WARRANTY.
- 2- Handle with care
- 3- Keep away from water and a moist environment
- 4- No impact or severe vibration
- 5- Operating temperature: -15°C to 50°C

Features:

- 1- Clear and large image (1.3 image sensor, 3.2 inch LCD)
- 2- Quick response: 1 second after pressing the button
- 3- Easy operation: just press the button
- 4- DDV1 will turn off automatically after 10 seconds to save power
- 5- Easy to assemble: no damage on the door, just the existing peephole, no tools needed, just a quarter.
- 6- No shadow can be seen from the outside, to ensure privacy

Before installation:

Replace the existing door viewer on the door or drill a 14-30 mm hole in the door at eye level


Installation:

- 1- Insert the camera from the outside door while inserting the washer between the back of the lens and the door. Make sure that the white mark on the camera points upwards
- 2- Fit the back cover of the main frame over the end of the lens. Then screw the locking barrel onto the threaded part of the camera, turn the mainframe clockwise for one turn to make it firmly tightened.
- 3- Connect the single cable from the lens to the white connector in the mainframe and put 3 AAA batteries in. FIG. A
- 4- Close the mainframe and hook the screen over the two little brackets in the top of the back cover. Push downwards to make it firmly secured.
- 5- Push the button to get the image displayed. If you get no video, please recheck connection. FIG. B

FIG.A



FIG. B



FOR ALL SERVICE AND WARRANTY ISSUES....PLEASE VISIT WWW.VIDPEEP.COM