

Instructions: Seat Back Gun Rack

15011



▲ **WARNING:**

TAKE CARE WHEN TRANSPORTING ANY FIREARM.

- **NEVER transport a loaded firearm**
- **NEVER transport firearms within the reach of children**

Materials list:

- 2 rack pocket sections
- 4 elastic hooked cords

Installation

1. If your seat has a removable headrest lift the headrest a couple inches.

Hang one of the pocket sections against your seat back with the pockets facing the back and the webbing straps at the top. Loop the webbing straps around the headrest posts or seat top and clip the side-release buckle together.

2. Repeat with the other pocket section.

3. CAREFULLY attach the hooked elastic cords to the D-rings on the bottom of each pocket section to the underside of your seat. Take care—if the hook does not catch the cord can release and cause injury.

4. Insert your rifles or shotguns into the pockets as shown above. Adjust the length of the webbing straps around the headrests as needed. Reposition any headrests.

Cleaning

Machine wash in COLD water. DO NOT USE SOAP as it may remove the protective coatings added by the factory. Line dry or machine dry on air or delicate.

Storage

Never store a wet Seat Back Gun Rack in a confined space. Your Gun Rack could mildew.

One Year Warranty

This product is factory warranted for workmanship and materials for one year after purchase. This warranty does not cover firearms carried in the gun rack.



Classic Accessories, Inc.
Kent, WA, USA 98032
www.classicaccessories.com
©2007

07cP53_6543