TP Zoomee Trampoline with Surround

TP455 7ft TP Zoomee Trampoline TP456 9ft TP Zoomee Trampoline TP457 11ft TP Zoomee Trampoline

INSTRUCTIONS FOR ASSEMBLY MAINTENANCE AND USE





Warning!

Important!

Max user weights/Age 7ft 85kg 6yrs+ 9ft 105kg 6yrs+ 11ft 130kg 6yrs+

Important!

These instructions must be followed for safe assembly and use. Please retain for future reference.

Vous devez suivre ces instructions pour que le montage et l'utilisation se fassent en toute sécurité. Veuillez conserver pour référence ultérieure.

Importante!

Per garantire sicurezza di montaggio ed uso, seguire gueste istruzioni e conservarle per futuro riferimento.

Importante!

Debe seguirse estas instrucciones para un armado y uso seguros. Sírvase conservarlas para consultarlas en el futuro.

Wichtig!

Diese Anweisung ist für sicheren Aufbau und Gebrauch zu befolgen. Für künftigen Gebrauch aufbewahren.

Importante!

Para assegurar uma montagem e uma utilização seguras, têm de ser seguidas estas instruções. Guardar para referência futura



IMPORTANT, BEFORE YOU BEGIN, READ THIS MANUAL

Thank you for buying this Trampoline. The trampoline is designed and manufactured to provide you and your family with many years of fun and exercise but, for your benefit and safety, please read this manual carefully and in full before assembling and using your trampoline. Then, please retain this manual for future reference.



! WARNING!

Do not land on head or neck. Paralysis or death can result even if you land in the middle of the trampoline mat (bed).



Do not land on knees.

To reduce the chance of landing on your head or neck, do not do somersaults (flips).



Only one person at a time on the trampoline.

Multiple jumpers increase the chances of loss of control, collision, and falling off.

This can result in broken head, neck, back, or leg.

YOUR NEW TRAMPOLINE

ASSEMBLY INFORMATION

Trampolines must be assembled by an adult. They must be erected exactly in accordance with the assembly instructions, which follow. Enlisting the aid of a helper will make assembly easier. This trampoline does not require any additional tools to assemble. Please take an inventory of all parts before assembly and ensure that all parts listed are included. Also please take care during assembly as the manufacturing process can sometimes result in the occasional sharp edge and small pieces of waste metalwork. The use of gloves to protect your hands from pinch points during assembly is also recommended. Should there be any missing parts, the toy must not be used until replacement parts have been fitted.


Spares: +44 (0)1562 733352

SITING

The trampoline must always be used in a well lit area. Under no circumstances should it be positioned on a hard surface such as concrete or asphalt, unless the ground under the trampoline plus the recommended freespace area is covered with a safety surface (please refer to diagram on page 16). Examples of suitable surfaces are grass, sand or a play surface intended for this use. The trampoline must be placed on a level surface. A minimum of 24ft of overhead clearance is required for this product. Adequate horizontal clearance must be maintained from objects and possible hazards including electric power wiring, tree limbs and fencing.

HIGH WINDS

It is possible for the trampoline to be blown about by high wind. If you anticipate high winds, the trampoline should be moved to a sheltered location, or be disassembled, or the round outside portion (top frame) should be tied to the ground using rope and stakes. At least three tie-downs should be used. Do not simply secure the legs to the ground, as they can pull out of the frame sockets.



GENERAL SAFETY GUIDELINES

USAGE

This trampoline is designed and made for family outdoor domestic use only. The trampoline is not intended for use outside of these guidelines. The user should be either barefoot, in socks, or wearing gymnastic shoes. Misuse can result in injury. Inspect the trampoline before use and always replace worn, defective or missing parts.

Warning for domestic use only!

SUPERVISION

Children should always be supervised while they are playing on trampolines and should be instructed not to use the trampoline in an inappropriate or hazardous manner. We recommend that they do not wear loose-fitting clothing or jewellery that may catch or snag during play. Ensure that younger children do not walk or crawl underneath the trampoline and keep the area around and underneath free from all solid objects at all times.

WEATHER CONDITIONS

Special care should be taken as weather conditions change. In particular, a wet trampoline mat (bed) is too slippery for safe jumping. Gusty or severe winds can cause jumpers to lose control. To reduce the chance of injury, use the trampoline only under appropriate weather conditions. In cold weather, tongues and lips can stick to metalwork at subzero temperatures. In warmer and sunnier weather, parts can become hot, and the temperature should be regularly checked during play, especially metal parts.

WATER PLAY

Many surfaces can become slippery during water play. Extra caution and supervision is required when combining water (e.g. paddling pools, agua slides etc.) with other forms of outdoor play.

USING YOUR TRAMPOLINE - IMPORTANT SAFETY INFORMATION

BEFORE YOU BEGIN. REMEMBER

- Trampolines are rebounding devices which propel the user to unaccustomed heights, and into a variety of body movements.
 Rebounding off the trampoline, striking the frame or springs, or improperly landing on the trampoline may cause injury.
- 2. All purchasers and all persons using the trampoline must become familiar with the manufacturers recommendations for the proper assembly, use and care of the trampoline. Each user must also be alert to his/her own limitations in the execution of trampoline skills. Assembly instructions, selected precautions and suggestions for the care and maintenance of the trampoline are included in this user's manual to promote safe, enjoyable use of this equipment.
- 3. It is the **responsibility** of the owner to ensure that all users of this trampoline are adequately informed of all warnings and safety instructions.
- 4. Never allow more than one (1) person on the trampoline at a time. Multiple jumpers increases the chance of someone becoming injured. Jumpers may collide with one another, fall off the trampoline, fall on or through the springs, or land incorrectly on the mat.
- 5. Always secure the trampoline against unauthorized and unsupervised use.
- Inspect the trampoline before each use and replace any worn, defective, or missing parts. The following conditions could represent potential hazards:
 - (1) Missing, improperly positioned, or insecurely attached frame padding,
 - (2) Punctures, frays, tears, or holes worn in the bed or frame padding,
 - (3) Deterioration in the stitching or fabric of the bed or frame padding,
 - (4) Ruptured springs,
 - (5) A bent or broken frame,
 - A sagging bed, or sharp protrusions on the frame or suspension system.
- Adult supervision of children Children should always be supervised while they are playing on the trampoline fitted with a Bounce Surround and should be instructed not to use it in an inappropriate or hazardous manner.

In particular be aware of:

Use trampoline surround only with mature, knowledgeable supervision

Do not attempt to jump over the barrier

Do not attempt to crawl under the barrier.

Do not intentionally rebound off the barrier.

Do not hang from, kick, cut or climb on the barrier.

Wear clothing free of drawstrings, hooks, loops or anything that could get caught in the barrier.

Do not attach anything to the barrier that is not a manufacturer-approved accessory or part of the surround system.

Enter and exit the surround only at the surround door or barrier opening designated for that purpose.

BOUNCING

- Always bounce in the centre of the bed. Bouncing near the edge of the bed can lead to injury and can also stretch the springs.
- 2. Avoid bouncing too high. Stay low until you can control your bounce and land consistently in the middle of the bed.
- 3. Learn basic bounces and body positions thoroughly before trying more advanced skills. Attempting a manoeuvre beyond present skill levels increases the chance of loss of control. A controlled jump is one where the landing is in the same spot as the take off. Before learning a more difficult manoeuvre, the preceding one should be performed consistently under control.
- 4. Do not attempt somersaults without proper instruction and supervision. Landing on your head or neck, even in the middle of the trampoline mat increases the risk of a broken neck, which can result in paralysis or death.
- 5. To regain control and stop your jump, bend your knees sharply when you land.
- 6. Do not bounce for too long or when tired.
- 7. Do not use the trampoline when under the influence of alcohol or drugs.

CARE AND MAINTENANCE OF YOUR TRAMPOLINE

GENERAL

Your trampoline is designed to stand outside all year round and generally requires very little maintenance. However, a little care and forethought can add years to your trampoline's life. Remember that the bed (mat) and frame pads are made of synthetic materials and are easily damaged by cigarette ends, fireworks and bonfire debris.

FRAME

Do not sit or stand on the frame or the frame pads while the trampoline is in use as this restricts the frames natural reflex action. Oil or petroleum jelly applied where the springs hook into the frame will reduce squeaking and frame hole wear. If surface rust appears it should be removed with either a wire brush or coarse sandpaper, and the area treated with a non-toxic paint.

THE MAT

The mat (bed) will, over the years, be gradually weakened by the effects of ultra violet radiation. Therefore, the more it can be protected from direct sunlight the longer it will last. A little mould or mildew should not harm the mat. Do make sure that shoes are removed before bouncing and ensure that any other sharp objects such as belt buckles, brooches and jewellery are removed too.

THE SPRINGS

Do not stand on the springs whilst the trampoline is in use. Try not to bounce on to the springs. They are not designed for this sort of stress and can become stretched, misshapen and weakened. If you find you have any stretched springs, it is important to replace them as soon as possible to avoid damage to the trampoline mat and avoid overloading and therefore damaging the remaining good springs

FIRE RISKS AND DISPOSAL

Never allow toys to be placed or used near a fire. When it becomes necessary to dispose of your equipment, remove all bolts and disassemble. Store out of the reach of children until it can be properly disposed of.

METHODS OF ACCIDENT PREVENTION

JUMPER'S ROLE IN PREVENTING ACCIDENTS

Education on the part of the user is a must for safety. Users must first learn a low controlled bounce and the basic landing positions and combinations before proceeding to intermediate skills. Jumpers must understand why they have to master "control" before they can start thinking about other moves. Understanding the proper progression of skills in jumping on a trampoline must be the first lesson.

SUPERVISORS ROLE IN PREVENTING ACCIDENTS

It is the responsibility of the supervisors of trampoline users to provide knowledgeable and mature supervision. They need to know and enforce all the rules and warnings set forth in this manual in order to minimize the likelihood of accidents and injuries and to inform users of these rules. During periods of time when supervision is unavailable or inadequate, this may require that the trampoline be disassembled, placed in a secure area, or otherwise secured against unauthorized use. It is the responsibility of the supervisor to be sure that the users are fully aware of the safety guidelines which are printed on the pads.


These instructions are issued in the interest of child safety, and we do ask you to follow our advice.


CONTENTS - Please Check TRAMPOLINE 1 FC1001 - 7ft FC1002 - 9ft 64 FC8699 - 11ft FC1003 - 11ft 6 FC9963 - 7ft 6 FC9966 - 9ft 8 FC9969 - 11ft 6 FC2051 - 7ft 6 FC2069 - 9ft 8 FC2056 - 11ft Tools 3 FC2017 - 7ft 3 FC2028 - 9ft


1 Allen Key


1 FC8681


FC4101 - 11ft






































Recommended Free Space:

The Safe Play Area refers to the zone extending 200cm (2 metres) beyond the toy on all sides and 700cm (7 metres) above the toy. The Safe Play Area must be free from all structures, landscaping, trees and branches, rocks, wires, sprinkler heads and other similar obstacles to safe play. Children can be seriously injured running or colliding into such obstacles.

Important Information

Register your new TP product on-line now at www.tptoys.com/productregistration

- For a chance to win £200 of TP products in our next quarterly on-line guarantee registration draw.
- For full terms and conditions please visit tptoys.com/terms

This Guarantee Number is:



Please retain your original till receipt and this instruction booklet should you need to contact TP Toys customer services.

Designed in the UK by TP Activity Toys (Tube Plastics Ltd), Zortech Avenue, Kidderminster, DY11 7DY, England. Made in China.

Customer Service:

Email: customerservices@tptoys.com

Phone +44 (0)1562 733352

Website: www.tptoys.com