

// INSTALLING BATTERIES //

1.



On right (R) earcup, press thumbs firmly on Saints Row logo and rotate disc slightly counterclockwise.

2.



Carefully remove the circular disc.

3.



Insert 2 AAA batteries, observing the correct polarity (+/-).

4.



Replace the battery lid disc and slide clockwise to secure.

// WEARING THE HEADPHONES //

- Place the headphones on your head with the cable on your left.
- Adjust the headphones by pulling up and down on the headband.

bleed area  
5.5in x 5.5in


// PLAY MODES //

/ MUSIC MODE /

- Connect the headphone plug to your AV device.
- Turn switch on left (L) earcup to MUSIC. The power indicator light will turn on.
- Turn the power on for your AV device.
- Use the inline volume control (+/-) to adjust the volume.
- Turn the power OFF when not in use to preserve battery life.

/ TALK MODE /

- Connect the headphone plug to your phone.
- Turn switch on the left (L) earcup to TALK. The power indicator light will turn on.
- Use the buttons on your cell phone to answer.
- Talk into the inline microphone to project your regular voice.
- Press the Z Button to turn the Zimos Effect on and off.
- Press the Headphone Button to turn the headphone monitoring on and off. This will allow you to hear your own voice through the headphones.
- Use the inline volume control (+/-) to adjust the volume.
- Turn the power OFF when not in use to preserve battery life.



/ FREESTYLE MODE /

(Hear your voice with the Zimos Effect without plugging them into an audio source)

- Turn switch on the left (L) earcup to TALK. The power indicator light will turn on.
- Press the Z Button to turn the Zimos Effect on
- Press the Headphone Button to turn the headphone monitoring on.
- This will allow you to hear your own voice through your headphones.
- Use the inline volume control (+/-) to adjust the volume
- Turn the power OFF when not in use to preserve battery life

// TROUBLESHOOTING // Cannot Hear Sound in Headphones.

- Check that the headphones are securely plugged into the AV device / phone.
- Verify that the AV device / phone is turned on.
- Turn up volume on the headphones and the AV device / phone.
- Replace the batteries.