

User manual

INTRODUCTION

Energy Sistem $\ensuremath{^{\mbox{\scriptsize B}}}$ thanks you for buying your new Energy $\ensuremath{^{\mbox{\scriptsize M}}}$ Wireless BT 5 we wish you enjoy using it.

Stereo Bluetooth® V3.0 headsets with circumaural design for high noise isolation offering a great music experience. Built-in noise cancelling microphone. Totally adjustable, foldable and with rechargeable li-ion battery.

We recommend you to read this user manual in order to enjoy the product in a safe way and with the best results.

CARE AND MAINTENANCE

- ► Do not expose your Energy[™] Wireless BT 5 to shock, dust, humidity or high temperatures.
- Do not use cleaners or scouring agents.
- ▶ Keep the unit clean and dust with a soft, dry cloth.
- Do not disassemble the device. Any repairs must be done by qualified service personnel authorised only by Energy Sistem Soyntec SA
- ▶ Switch off your Energy™ Wireless BT 5 when not in use.

TECHNICAL DETAILS

- ▶ Fully enclosed dynamic headsets.
- ▶ Hi sensibility and noise cancelling microphone.
- ▶ Clear sound with 96 dB sensibility.
- ▶ Total compatibility with Tablets, Smartphones, laptops, MAC and PCs.
- ▶ Function control PLAY, STOP, <<, >>, and VOLUMEN on the ear cup.
- Ergonomic and light weight design for a maximum comfort in long sessions.
- Effective use distance up to IOm.
- Rechargeable li-ion battery.
- Autonomy up to 15 hours.

PACKAGE CONTENT

- ► Energy[™] Wireless BT 5.
- ► USB cable.

GENERAL OVERVIEW

- I. ON / OFF SWITCH.
- 2. CONTROL TALK / PARING BUTTON.
- 3. PLAY / PAUSE.
- 4. VOLUME CONTROL.
- 5. NEXT/LAST.
- 6. MIC.
- 7. USB CONNECTION.
- 8. CHARGING LED.



ENGLISH

MAIN FEATURES

- Bluetooth® V3.0 Class 2 headset.
- ► Compatibility with ANDROID[™] and iOS devices.
- Easy pair without complex codes.
- Built-in microphone.
- Automatically call reception.

TURN ON / OFF YOUR DEVICE

Use the ON / OFF SWITCH (I) to use your device.

The device is on when the ear pad controls are lighted.

CHARGING

When the headset lacks sound or start to hear some interference in short distance, is time to recharge. Plug the mini USB cable end to your Energy™ Wireless BT 5 (73 and the other end to any other device with USB port that provides energy (such as PC, a USB wall charger, etc). The CHARGING LED (8) turns red when it is charging and when the charge is completes the CHARGING LED light stops.

NOTE: To keep the battery in good conditions, we recommend you to charge when the battery has completely run out. At the same time, do not interrupt the charging process until the battery is full.

BLUETOOTH PARING

Having your Energy[™] Wireless BT 5 on, press the PARING button (2) in the almost position for about 5 seconds, wait until the PLAY / PAUSE (3) starts flashing and changing color (red/blue) at that time your Energy[™] Wireless BT 5 is waiting for the paring with your other Bluetooth® device. When you reach the Energy[™] Wireless BT 5 in your device you only have to select and pair.

FUNCTION CONTROL

Once you have pair your Energy[™] Wireless BT 5 your audio device, you can control the main functions from the ear pad; increase or decrease the volume (4), go to the next or last song (5) and play/pause the song (3).

CONTROL TALK

Having your Energy[™] Wireless BT paired with your mobile or smartphone, you can receive phone calls and use the MIC (6) to answer calls.

To answer an incoming call, press the button (2) and when you finish, press the button (2) again to end the call. If you are listening to the music when you receive the call, the music will be paused and when you finish the call the music continue.

WARRANTY

Energy Sistem Soyntec SA is liable for any lack of conformity which exists at the time the goods were purchased during a period of 36 months. Batteries are excluded from the 36-month warranty, having a warranty period of 12 months.

This warranty covers any defects in workmanship or materials. This warranty doesn't cover any failure of the product due to accidents, misuse or alteration made by an unauthorized person.

The special 36-months warranty is valid for the European Union. For other countries, please refer to your specific legislation or your local distributor.

WARRANTY PROCEDURE

- Visit the Support section at http://support.energysistem.com and select your product to view the FAQ (Frequently Asked Questions). The solution to your problem is very likely to have been already published there. You will also be able to download user manuals, user guides, drivers and updates. You can check the availability of the user manual in your language at http://www.energysistem.com/es-es/support/manuals
- If you cannot find an appropriate solution in the Support section, you may send us your enquiry or warranty service request by email: support@energysistem.com
- 3. Alternatively, you may prefer to contact the distributor from which you purchased the product, presenting the purchase receipt or invoice.

Important: This warranty doesn't cover any damage or loss to any data stored in the product memory, therefore Energy Sistem's Technical Service will not assume any loss of the above mentioned information so it is recommended to make a backup of your data and to remove any data or personal info from its internal memory before you send the product, or to send it only with the original factory default values.

Specifications are subject to change without notice.

Trademarks. All company, brand and product names are trademarks or registered trademarks of their respective companies.

© 2012 by Energy Sistem®. All rights reserved.

CE

DECLARATION OF CONFORMITY

17/09/2012

Manufacturer Name: Energy Sistem Soyntec S.A.

Address: Pol. Ind. Finestrat, C/. Calpe, I - 03509, Finestrat Alicante (Spain)

Tel: 902 388 388

Fax: 902 119 034

NIF: A53107488

We declare under our own exclusive responsibility that the product:

Energy Sistem[®] Energy[™] Wireless BT 5.

Manufacturing country: China

Is in compliance with the essential norms and standards of the Directive 2004/I08/EC of the European Parliament and of the Council of December I5th 2004.



This symbol on the product or the instructions means that your electrical and electronic equipment should be disposed at the end of life separately from your household waste. For more information, please contact the local authority or dealer where you purchased the product.