


HRDE4X4 Front Panel Operator Guide

1 Easily Monitoring Live Video and Audio




In single channel view only:
Press **SEQ** to automatically cycle through each camera view.
Press **SEQ** again to stop cycling.

Only audio from the selected camera will be heard. The **Audio Out** connection on the back of the unit must be connected to an amplified speaker to hear audio.

Press numbered arrow key 1 - 4 to select and display camera 1 - 4.

Press **SEL** to display 4 (quad) cameras


2 Quick Search to Find Incident Video



Timeline Search is easiest.

Use **Go To** if you know the approximate incident time.
Use **Event Search** for motion or alarm video.

3 Using Timeline Search




To change the month, press **◀REW**, **FF▶**. Days colored red have saved video.
Use arrow keys to select the day to play. Press **SEL**.



Red line = Video recorded
Green line = Audio recorded

Use arrow keys to move the vertical yellow bar to the **Hour** and **Minute** to play back. Press **SEL**.

4 Playback Video and Audio



Select one camera to play. Audio is only heard for that camera.



Play Cameras in Quad (4). Camera displayed with yellow lettering plays audio.



Back to Search

▶/|| PLAY/PAUSE ◀◀ REW ◀◀ F/REW F/ADV ▶▶ FF ▶▶



- 1 Play/Pause video
- 2, 5 Fast forward/reverse
Click to toggle speed 2 – 16x
Speed shows at the bottom of the monitor
Audio only plays in lowest (▶) speed
- 3, 4 In Pause: Advance/Reverse 1 image
In Play: Jump 1 minute forward/reverse



5 A. Mark Evidence for Archiving B. Copy to USB Memory Stick

5A Locate an incident (steps 2, 3, 4).
Display a single camera to Archive.
Press **ARCH**, select **STILL** or **VIDEO**.
You will see the message **VIDEO OK**.
Press **ESC** to return to the Search screen.

5B Put USB Memory stick in the front panel.
Select **ARCHIVE** search and press **SEL**.
Select the day of the incident and press **SEL**.
Highlight the clip/still image name.
Press **SEL** to play.
Press **ARCH**, select **YES** to save.
When finished you will see the message **SAVE SUCCESS**.

5B



6 Play and Review Evidence AVI on Microsoft® Windows XP/2000

Put the USB Stick in a Windows PC.
Double-click the AVI file to launch it.
Use Windows Media Player to play the clip.
The folder uses a YearMonthDay name (20060203 = 2006 February 03).
The file uses a HourMinSecCamera name (130808C1 = Starts at 13:08:08 Camera 1).
Playback using VCR-like controls.

Folder



Video file

Single images are saved in JPG format and can be viewed with Internet Explorer.

AVI files are played with Windows Media Player.
It may be necessary to install a CODEC on your PC to play clips.
See the User Manual or contact technical support for assistance installing CODECs, in North America call 1.800.796.CCTV.

Honeywell

Video Systems

www.honeywellvideo.com

+1.800.796.CCTV (North America only)

© 2006 Honeywell International Inc.