

WARRANTY

This Limited Product Warranty shall apply to Hyndsight Vision Systems, Inc. products including all accessories as contained within the original package. Hyndsight Vision Systems, Inc. warrants that products from its authorized distributors and retailers will meet the applicable product specifications and be free from all defects in material and workmanship during the Limited Product Warranty Period, one year starting from the date of original purchase, assuming the products are used in accordance with the user manual and other documentation provided at the time of purchase.

This Limited Product Warranty is subject to the following terms and conditions:

1. To obtain warranty service, a proof of purchase in the form of an original or copy of the sales receipt from the original retailer is required.
2. This Limited Product Warranty is only valid and enforceable in the country/region where the product is sold.
3. This Limited Product Warranty is at sole option of Hyndsight Vision Systems, Inc. to either repair or replace the defective product during the Limited Product Warranty Period. Hyndsight Vision Systems, Inc. will not replace missing components from any package purchased through online auctions.
4. To obtain warranty service, contact your local Hyndsight Vision Systems, Inc. authorized retailer or Hyndsight Vision Systems, Inc. for shipping instructions and an RMA number.
5. This Limited Product Warranty covers expenses for inspecting and repairing the product during the Limited Product Warranty Period. The defective product shall be delivered by the purchaser at his/her own expense to the designated premises together with the proof of purchase and RMA number.
6. Hyndsight Vision Systems, Inc. will return the repaired or replaced product to the drop-zone for collection by the customer in good working condition. All replaced faulty products or components will become property of Hyndsight Vision Systems, Inc..
7. If Hyndsight Vision Systems, Inc. repairs or replaces the product, the repaired or replaced product shall continue to be warranted for the remaining time of the original warranty period or for three (3) months from date of repair or replacement, whichever is longer.
8. Hyndsight Vision Systems, Inc. reserves the right to add, delete, or amend the terms and conditions at any time without prior notice on its website, www.hyndsightvision.com.
9. A two (2) year warranty is extended to the Flush Mount, as well as to all purchases made in the United Kingdom.
10. This limited warranty shall not apply if the damage was caused by any of the following:
 - a. The product serial number has been removed, erased, defaced, altered, or is illegible.
 - b. The damage resulting from the use of the product in a manner other than its normal and customary manner.
 - c. Deterioration of the product due to normal wear and tear.
 - d. The damage arising from improper installation, unauthorized repair, alteration, or modification to this product by third parties other than Hyndsight Vision Systems, Inc. or its designee.
 - e. The damage arising from operation with components or accessories not officially authorized or provided by Hyndsight Vision Systems, Inc. or used in ways other than its intended use.
 - f. The damage arising from exposure to abnormally corrosive conditions or operation with extreme heat/cold or humidity.

Manufactured in China for Hyndsight Vision Systems, Inc.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada licence-exempt RSS-210 standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.



Hyndsight Vision Systems, Inc. Instructions for Use



Operating instructions for the CRUZ and Journey product lines by Hyndsight Vision Systems, Inc.

Applies to HVS-001C camera and HVS-001M monitor



TABLE OF CONTENTS

Product Specifications2

Intended Use2

Important Safety Notice3

Caution3

Kit Contents3

Charging4

Single Camera Set-Up4

Multi-Camera Set-Up5-6

Flush Bracket Mounting7

Troubleshooting7

Warranty8

PRODUCT SPECIFICATIONS

Transmission Frequency: 2.4 GHz
 Unobstructed Effective Range: up to 300 ft.
 Power Supply Input, per adapter: 100-240 V AC 50/60 Hz 0.2A
 Power Supply Output, per adapter: 5V DC 1.0A
 Monitor (CRUZ & Journey 1) - 5.0" sunlight-readable display (4.8" viewable)
 Monitor (Journey 2) - 4.8" TFT LCD
 Camera (CRUZ) - Tight Angle Lens
 Camera (Journey 1 & 2) - Wide Angle Lens
 Screen Resolution: 800x480
 Live video stream without recording capabilities
 Styles and colors may vary.

INTENDED USE

Hyndsight Vision Systems wireless cameras and monitors are to be used as an aid for visualizing blind spot conditions or for monitoring locations not always in clear sight. Use of your own common sense and judgment is always indicated before and during use of this product. Hyndsight is not responsible for accidents or actions that result under use of this product.

FLUSH BRACKET MOUNTING

To attach the Camera or Monitor to the desired smooth, clean, flat, non-porous surface, follow the instructions below. Note: The mounting surface and the Suction Cup should be clean and dry. Wipe with a clean, damp cloth and let dry completely. The Flush Mount should be installed at room temperature (avoid extreme heat or cold). Do not moisten the Suction Cup.

- Thoroughly clean the smooth, flat, non-porous surface, making sure the surface is dry and free of scratches.
- Twist the Camera or Monitor onto the flush mount's threaded mounting stud. Do not remove the Rubber Washer.
- Hold the Camera in place and firmly tighten the Lock Ring.
- Position the Suction Cup Lever in the "down" position.
- Position the Suction Cup on your mounting area. In order to remove the Flush mount easily, HVS recommends that the Suction cup Release Tab be at the bottom of the installation area.
- Push the Suction Cup firmly against the mounting surface (the Suction Cup Lever should be in the "down" position). Press the Suction Cup Button and pull the Suction Cup Lever up and over the Button. You will feel the Button move out during this procedure; this action locks the Suction Cup into place.
- Loosen the Flush Mount Adjusting Knob, position the Camera or Monitor, and then retighten the Adjusting Knob.
- Check the Camera's position as necessary by loosening the Adjusting Knob. Tighten securely when in position.
- To release the Suction Cup, move the Suction Cup Lever back into its "down" position. Lift the Suction Cup Release Tab to help break the hold.

TROUBLESHOOTING

Problem	Solution
Camera won't pair automatically	Press the Menu button Select Pair by pressing Enter The Monitor's green indicator light should flash and the screen will go white, during which time you should press the Pair button on the Camera.
Camera 1 icon is displayed as in use, but no image is showing and I can't pair to it	Press the Menu button Select Enable Multi-Camera Select Pair by pressing Enter Toggle to an inactive (gray) Camera icon Press Enter The Monitor's green indicator light should flash and the screen will go white, during which time you should press the Pair button on the Camera Remember to Unpair Cameras 2-4 before Powering off.
No Signal	Make sure antennas are attached and devices are within effective range. Weather, interference and other such factors may reduce the unit's ability to convey video.
Difficulty seeing screen	Adjust angle of Monitor. Also, polarized sunglasses may affect viewing.
All four Camera icons are blue but I don't have all 4 Cameras paired	Unpair unused Camera icons using Monitor; turning off the Camera alone does not unpair it from the Monitor. Press the Menu button Toggle to a camera icon that shows to be paired but is not. Select Unpair by pressing Enter Repeat the above steps to Unpair any occupied camera icons that actually do not have a paired Camera








For screen shots and instruction videos, please visit our website at www.hyndsightvision.com or check out our YouTube page.

A digital copy of the instruction manual can be found at www.hyndsightvision.com

Select

To view the image from one specific Camera when multiple Cameras are paired, use the Select setting. A blue camera icon means that camera is already paired, a red camera icon means that camera is selected, and a gray camera icon means that camera is inactive.

To Select







- ✓ Press the Menu  button.
- ✓ Toggle using  or  until the Select setting is colored red.
- ✓ Choose *Select* by pressing the Enter  button.
- ✓ Toggle using  or  until the next desired corresponding Camera icon is colored red.
- ✓ Press Enter  to display the image from the Selected Camera.

Repeat the above steps to Select a different Camera view.

Scan

Use the Scan setting to watched a looped broadcast from all paired cameras. Each Camera's image will be displayed for 7 seconds before switching to the next Camera's image.

To Scan








- ✓ Press the Menu  button.
- ✓ Toggle using  or  until *Scan* is colored red.
- ✓ Select *Scan* by pressing the Enter  button.
- ✓ Toggle using  or  until ON is colored red.

Repeat the above steps and toggle to OFF to stop Scanning through all paired cameras

Unpair

Use the Unpair setting when you no longer need the image from the corresponding camera. It is suggested to Unpair cameras 2, 3, and/or 4 before shutting down your unit.

To Unpair




- ✓ Press the Menu  button.
- ✓ Toggle using  or  until *Unpair* is colored red.
- ✓ Select *Unpair* by pressing the Enter  button.
- ✓ Toggle using  or  until the next desired corresponding Camera icon is colored red.
- ✓ Press Enter  to Unpair the image from the Selected Camera.

Note: Never leave Camera 1 unpaired before shutting down the unit - it will complicate Pairing the next time you Power On.

Disable Multi

Once you are done using multiple cameras, disable the Multi-camera setting. Disable Multi is only available when in Multi-Camera mode.

To Disable Multi:

- ✓ Press the Menu button
- ✓ Toggle using  or  until *Disable Multi* is colored red
- ✓ Select *Disable Multi* by pressing the Enter  button
- ✓ Press the Menu button to exit the menu screen and return to Camera 1's image

To Power Off Your Hyndsight System

- Please refer to Power Off instructions posted under SINGLE-CAMERA SET-UP on page 5.


IMPORTANT SAFETY NOTICE

Program your settings before you operate any vehicle.
 Do not program product while driving or while in motion. When adjusting settings, stop in a safe and legal manner before doing such operations.
 Hyndsight Vision Systems, Inc. products are designed for use in outdoor activities. While using your Hyndsight product, safety rules must be followed to prevent accidents that can result in injury or death to yourself and/or others. Distractions can be dangerous and result in an accident in which you or others could be injured. Please do not solely rely on screen image alone. No technology is a replacement for your attentiveness.
 Do not disassemble the Camera or Monitor.
 Do not attempt to remove the internal, non-replaceable battery in the Camera or the Monitor. Do not expose the product to abnormal conditions such as extreme heat or humidity or prolonged sun exposure.
 When disposing of the unit, have the batteries removed and recycled by a professional waste electronics treatment provider. Do not use paint thinner or rubbing alcohol to clean unit.
 Do not subject unit to strong impact. Do prevent the Camera and Monitor from falling.
 Do not submerge the Camera or Monitor in water. Do not subject unit to prolonged exposure to rain, snow, and other outside environments.
 Do charge the units indoors in dry conditions. Do not charge the units around water or during rain when unit is installed outdoors. Doing so may cause electrical shock and/or injury to you or the device.
 Sunglasses with polarized lenses may impair the visibility of the display.
 This monitor is not intended to be used as a medical monitor and its use should not replace proper adult supervision. You should check your child's activity at regular intervals as this monitor will not alert parents to the silent activities of a child.
 Strangulation Hazard - Children have STRANGLED in cords. Keep cords out of reach of children.

CAUTION

In order to prevent improper operation of the AC Adaptor, please read the user manual carefully. For your safety, please use only the AC Adaptor provided. The manufacturer will not be responsible for any losses caused by converters and chargers not provided by the manufacturer. IMPORTANT Please use only the socket match with the AC Adaptor. Use of improper socket may cause electrical and fire damage. Only charge the Camera and Monitor in dry environments. Charging the Camera and/or Monitor in the rain or in a wet environment may cause electrical shock, fire, personal injury and/or product destruction. Improper use of the Camera and/or Monitor and accessories will void the warranty.

KIT CONTENTS



CHARGING

Fully charge both devices before using.

To Charge Your Hyndsight System



- Connect the USB cable to the Wall Charger.
- Insert the straight jack into the Camera/Monitor.
- Plug in the Wall Charger.
- Red light appears when charging. Red light turns off when charge is complete (3-4 hours).

Hyndsight Systems are equipped with multiple functions depending upon if Multi-Camera mode is Disabled (only one camera can be used) or Enabled (more than one camera can be used).






SINGLE CAMERA SET-UP

Remove the protective screen cover from the Monitor before using. HVS recommends pairing Cameras before mounting them to desired surfaces. Using your best judgment, attach Camera and Monitor Antennas either before or after mounting Devices to desired surfaces. Note: Unpair, Select, and Scan settings are disabled in Single Camera mode.

To Power On* Your Hyndsight System

- Hold Monitor Power  button for 3 seconds until the orange Hyndsight screen appears. Green Indicator Light will light up to show Monitor is on.
- Hold Camera Power  button for 2-3 seconds. An image will appear on the Monitor after you release the Power button. Indicator Light will illuminate to show Camera is on.








*Always power up Monitor before Camera to help sync automatically. If Camera and Monitor do not sync automatically, follow the steps below:

- ✓ Press the Menu  button.
- ✓ Scroll to *Pair* using  or .
- ✓ Select *Pair* by hitting the Enter  button.
- ✓ Monitor screen will go white and the Green Indicator Light will flash.
- ✓ While Monitor's Green Indicator Light is flashing, press the Pair  button on Camera and an image will appear on Monitor.

After Single Camera is paired, the viewing perspective may be changed between Mirror-image or Forward-facing views. Single Camera mode defaults to a Mirrored view. Mirrored view is ideal when backing up to provide you with an accurate view of the locations of objects behind you.

Forward-facing View



Displays a view consistent with what you would see if you were viewing an object head-on.

- To Switch to Forward-facing View
 - ✓ Press the Menu  button.
 - ✓ Scroll to *Mirror* using  or .
 - ✓ Select *Mirror* by hitting the Enter  button.
 - ✓ Toggle using  or  to highlight *F* in red.
 - ✓ Select *F* by hitting the Enter  button.



To revert back to the Mirror-image view, repeat above steps but select *M* instead of *F*.

Brightness

The brightness of the unit can easily be decreased or increased.

- To Adjust Brightness
 - ✓ Press  to decrease brightness.
 - ✓ Press  to increase brightness.

To Power Off your Hyndsight System

- Hold Camera Power button  for 2-3 seconds until image disappears from Monitor. Monitor screen will be white and will display *Signal Lost* along the top of the screen.
- Hold Monitor Power button  for 3 seconds until screen goes black.

Note: To place Monitor in power save mode at any time, press Monitor Power button for 1 second to display a dim image. Press the Monitor Power button again for 1 second to restore full color display. Your Monitor is not fully Powered Off until both the Monitor Green Indicator Light is off and the screen is dark black. Power save mode is ideal for conserving Monitor battery life without having to fully turn off the system when not in immediate use.


MULTI-CAMERA SET-UP













Note: This product can accept up to 4 cameras. To order an additional camera (HVS-045J), please contact our Customer Service Department by phone at 1-844-SEE-SAFE or visit www.hyndsightvision.com

To pair additional Cameras, you will need to enable Multi-Camera mode by following the instructions below. A blue camera icon means the camera is already paired, a red camera icon means the camera is selected, and a gray camera icon means the camera is inactive. To change brightness, please see Brightness section under Single-Camera Set-Up.

Note: Mirror-image view is disabled in Multi-Camera mode.

Pairing a Second Camera:

After the first Camera is synchronized, you may turn on the second Camera by pressing the Power  button until a green light illuminates on the Camera, indicating the Camera is on. Follow the steps below to Enable the Multi-Camera setting and to Pair the additional camera(s).

- To Enable the Multi-camera setting
 - ✓ Press the Menu  button.
 - ✓ Toggle using  or  until the Enable Multi-camera setting is colored red.
 - ✓ Select *Enable Multi* by pressing the Enter  button.
- Now you can Pair an additional Camera(s)
 - ✓ Press the Menu  button.
 - ✓ Toggle using  or  until *Pair* is colored red.
 - ✓ Select *Pair* by pressing the Enter  button.
 - ✓ Toggle using  or  until the next desired corresponding Camera icon is colored red.
 - ✓ Select Camera to be paired by pressing the Enter  button. The Monitor's green indicator light will begin to flash.
 - ✓ While Monitor's indicator light is flashing, press the Pair  button on the Camera to sync the Devices.

Repeat the above steps to Pair Cameras 3 and 4.