

Bluetooth® Speakerphone User Guide



CBTH3

1. Notice Before Using

Thank you for purchasing the Cobra **Bluetooth®** Visor Speakerphone CBTH3. Your Cobra CBTH3 is a **Bluetooth®** wireless technology device that enables a cable-free connection between your speakerphone and **Bluetooth®** wireless technology enabled handset.

2. Package List

Please inspect your packaging contents and refer to the package list below to confirm that there are no shortages or defects. The packaging contents include the following items:

- ▶ CBTH3 **Bluetooth®** Visor Speakerphone....1
- ▶ User Guide.....1
- ▶ Warranty Card.....1
- ▶ USB Cable.....1
- ▶ Vehicle Charger..1
- ▶ Removable Metal Clip.....1

If you find any shortage or defect, please contact your retailer where you purchased your **Bluetooth®** wireless technology speakerphone.

Getting Started

1. Charging the CBTH3 Handsfree Visor Speakerphone

The CBTH3 includes a built-in rechargeable Lithium Polymer battery. **IMPORTANT:** For first time use, charge the speakerphone for at least 5 hours before pairing using the included vehicle charger or via your PC using the USB cable.

1. Connect the USB charging cable to the charging port on CBTH3. Connect the other end of the USB charging cable to the vehicle charger or the USB port of your PC/Notebook.
2. Charging is indicated by a RED charging LED on the side of CBTH3 near "DC IN". It may take up to 5 hours, depending on the power source you are using. Charging is complete when the RED charging LED indicator is no longer illuminated.

NOTE:

- Only use supplied charger or original Cobra products to charge the speakerphone.
- Do not charge for more than 24 hours.
- Recharge speakerphone only within temperature range of **41 degrees F** to 113 degrees F.

2. Power On/Off

IMPORTANT: To conserve battery power, it is a good idea to turn the CBTH3 off during storage or during long periods of non-use.

1. To POWER ON press and hold the multi-function button for **5+** seconds. The BLUE indicator will slowly flash and a **low-high tone** will be heard.
2. To POWER OFF press and hold the multi-function button for **1+** seconds until you hear the **high-low tone**. The RED indicator will flash momentarily and then the unit will power down.

NOTE: If the **Bluetooth®** wireless technology link to your phone is disconnected or you take your paired phone out of range for 10+ minutes, the CBTH3 will automatically power down to conserve battery life.

3. Pairing the CBTH3 Speakerphone

IMPORTANT: Your Cobra **Bluetooth®** CBTH3 Speakerphone and your **Bluetooth®** wireless technology enabled phone or other **Bluetooth®** wireless technology devices, must be "paired" together before first time use.

1. Ensure the CBTH3 is powered off (no flashing indicator lights).
2. Press and hold the multi-function button for **7+ seconds**, until the unit alternates RED and BLUE flashes.
3. Ensure your mobile phone has the **Bluetooth®** wireless technology function, and start the **Bluetooth®** wireless technology new device searching function. Please follow the instructions of your mobile phone to proceed with the pairing operation.
4. Activate the **Bluetooth®** "discovery" function in the mobile phone or other **Bluetooth®** device. (See phone manual for specific **Bluetooth®** wireless technology pairing instructions.)
5. When **Bluetooth®** wireless technology speakerphone is recognized by your phone, "CBTH3" will appear in the list of found devices.
6. Scroll to select or highlight "CBTH3" and press OK
7. You will get prompted to enter the speakerphone password "1234" and press OK.
8. If pairing is successful, the BLUE indicator will flash slowly. Your speakerphone is now paired and ready to use.
9. If pairing is unsuccessful, the unit will continue to alternate RED and BLUE flashes. Please repeat the pairing process again from step 1.
10. Certain phone models may require you to press "connect" or "add to trusted devices" (See phone manual for specific **Bluetooth®** wireless technology pairing instructions.)

NOTE: Recommended distance between mobile phone and speakerphone during pairing is 1 to 3 feet. If speakerphone is not successfully paired within 2 minutes, it will automatically abandon pairing mode and revert to standby mode.

4. Using the CBTH3 Speakerphone

Option 1: Handsfree table-top speakerphone

Option 2: Vehicle visor speakerphone (Slide the metal clip onto your car's sun visor)

1. Hold the multi-function button for **5 seconds** to power the unit on.

2. Rotate the microphone to point toward your voice for optimal clarity of your voice.

NOTE: If the microphone is quite close to the speaker, you may hear an echo in your telephone conversations. To correct, position the microphone away from the speaker.

3. Adjust the volume on the front of the CBTH3 using the Volume Up (+) and Volume Down (-) key to your preferred listening level.

NOTE: If you hear an echo in your telephone conversations, reduce the volume level using the Volume Down (-) key.

Option 3: PC speakerphone

The CBTH3 can be used with a **Bluetooth®** wireless technology enabled PC as a handsfree device for applications such as Skype. Please refer to your PC or software user manual for exact instructions on connecting CBTH3 to your PC. Remember to make sure that any software applications you wish to use with the handsfree are configured to route audio through the **Bluetooth®** wireless technology system and not through the PC speakers.

5. Reconnecting to Your Mobile Phone (after initial pairing)

1. The CBTH3 will automatically establish a connection with the phone when the CBTH3 is powered on, a confirmation tone will be heard.

2. If the speakerphone does NOT automatically reconnect, press the multi-function button once.

NOTE: If your phone enters the required operating range (33 feet) in less than ten minutes, the devices will automatically reconnect.

6. Making an Outgoing Call

1. Dial your desired phone number using your handset and press “send”. Call recipient’s voice will be heard on the speakerphone.

7. Making a Call Using Voice Dialing*

***IMPORTANT:** Your mobile phone and carrier must support this feature and/or it must be activated to work properly.

1. Briefly press and release the multi-function button to activate voice dialing and follow your mobile phone instructions to proceed with the voice dialing.

8. Answering and Ending an Incoming Call

1. Press the multi-function button briefly and release to answer an incoming call.

2. Press the multi-function button to end the call.

9. Muting Microphone

1. Press the mute button (next to microphone arm) to mute the microphone.

Speakerphone will continuously “beep” to signify that mute function is on.

2. Press the mute button again to turn off the mute function.

10. Call Waiting*

***IMPORTANT:** Your mobile phone and carrier must support this feature and/or it must be activated to work properly.

1. During a phone call, hold the volume down (-) button for 2 seconds; the call is then placed on hold.

2. You will now be connected to incoming caller or you can make an outgoing call.

3. Hold the volume down (-) button again for 2 seconds to return to original your call.

11. Transferring Active Call From the CBTH3 to Handset

1. Hold the volume up (+) key for 2 seconds. The audio is transferred from CBTH3 to your handset.

2. Hold the volume up (+) key again for 2 seconds to transfer the call back to the speakerphone.

12. Rejecting an Incoming Call*

*IMPORTANT: Your mobile phone and carrier must support this feature and/or it must be activated to work properly.

1. Hold the multi-function button for 2 seconds.

13. Redialing*

*IMPORTANT: Your mobile phone and carrier must support this feature and/or it must be activated to work properly.

1. Hold the volume down (-) key on the CBTH3 for 2 seconds and release after you hear a confirm tone.
2. The last number is automatically redialed.

14. Resetting the CBTH3

You may need to reset your speakerphone in the event that it locks or freezes during operating. Use the end of a paperclip (diameter less than 1 mm) and insert it into the reset hole located on the back of the unit on the left hand corner of the visor clip.

15. Safety Instructions

1. Read the speakerphone manual carefully and use the speakerphone correctly by following the instructions.
2. Keep the speakerphone away from children.
3. Do not use cleaning liquid/spray to clean the speakerphone.
4. Do not clean the speakerphone while charging it.
5. Do not disassemble the speakerphone.
6. If you encounter a problem, contact your retailer.

16. Specification

Product Model No.	CBTH3
Standard Convention/ Signal Output	Bluetooth® V2.0
RF Frequency Range	2402 ~ 2480 MHz
Talk/ Standby Time	Up to 15 hours / Up to 400 hours
Supporting Profile	Headset & Handsfree
Safety Regulation	CE, FCC, BQB
Size (inches)	4.02 x 2.76 x 0.98
Power Capacity	1300 mAh Li-Polymer Battery
Operation Range	33 feet
Operation Temperature	32 ~ 113 °F
Storage Temperature	-4 ~ 140 °F
Initial Charge Time	5 - 6 hours
Standard Recharge Time	4-5 hours

17. Declaration of Conformity

FCC (FCC ID: RS6 BTDSK08): CBTH3 is FCC certificated as this device complies with part 15 of the FCC rules.

CBTH3 has been manufactured in accordance with the European R&TTE directive.

BQE Qualification:

CBTH3 is a speakerphone with **Bluetooth®** wireless technology. The product is approved by a qualified Bluetooth Qualification Expert (BQE) which ensures that the product is in compliance with the all applicable Bluetooth standards at the time of listing.

Federal Communications Commission (FCC) Statement

15.21

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions:

1. this device may not cause interference and
2. this device must accept any interference, including interference that may cause undesired operation of the device.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The **Bluetooth®** word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Cobra Electronics Corporation is under license. Other trademarks and trade names are those of their respective owners.

Cobra, Nothing Comes Close to a Cobra and the snake design are registered trademarks of Cobra Electronics Corporation, USA. Cobra Electronics Corporation is a trademark of Cobra Electronics Corporation, USA.

MADE IN TAIWAN

18. Limited Warranty

FREE OF CHARGE WARRANTY SERVICE:

1. All defective units within the applicable Warranty period will be repaired or replaced, in the case those faulty goods were handled normally.
2. If you use device commercially, the warranty period will be reduced by half.

FREE OF CHARGE WARRANTY DOES NOT APPLY TO:

1. Defects or damage resulting from use of the unit in other than its normal and intended manner, eg, in excess of their maximum specifications or operating instructions.
2. Defects or damage from misuse, accident, neglect, improper testing, installation, alteration, modification of any kind, and/or spillage of food or liquid.
3. Faulty is caused by natural disaster.
4. Capacity of expendables is exhausted.

Product Name	Cobra Handsfree Visor Speakerphone
Model Number	CBTH3
Purchase Date	
Place of Purchase	
Customer Name	
Customer Address	
Telephone #	
Warranty Period	1 year

Aries
2001 West Kelley Court
Libertyville, IL 60048
www.CobraHandsfree.com
866.610.9322 (USA only)