



## ATOMIC BATTERY CASE FOR GALAXY S4 I9500

Please read this user manual thoroughly before operating the product.



### Introduction

Thank you for choosing the Maxboost Atomic for Samsung S4. This powerful portable battery is designed to help you charge the Samsung Galaxy S4 quickly and easily. Please make sure to read this instruction manual carefully to learn how to get the most out of your new Maxboost Atomic Battery Case.

### Package Includes

Maxboost Atomic Battery Case for S4  
Instruction Manual

**USB Cable Not Included**

**(Atomic is Compatible to Original MicroUSB Cable for Galaxy S4)**

### Charging Your Maxboost Atomic

1. To charge the Atomic, use the micro-USB cable (Original cable came with your S4) and connect the case to a USB power source (e.g. a computer or USB wall-outlet).

#### Technical Specifications

Capacity	2,000
Input	5V/1.0A
Output	1.0A
Dimensions	5.5x2.6x0.7 inches
Weight	3 ounces

### How to Charge the Samsung Galaxy S4 with the Atomic

1. Slide the Samsung S4 phone into the case.
2. Make sure the charging connector is firmly attached to the phone.
3. Turn the power switch ON (from RED to Green) on the back of the case.
4. The phone will then indicate that it is charging.

### Power Level Indicator Instructions

1. To determine the current battery power of the Atomic, simply press the power button once. The table below depicts number of lights to corresponding power levels

LED Light Indicator	Battery Capacity
4 Lights ON	100%-75% power
3 Lights ON	75%-50% power
2 Lights ON	50%-25% power
1 Light ON	25%-1% power

## Troubleshooting Tips

1. Make sure that the phone is firmly connected to the Atomic Battery Case.
2. Verify that the Maxboost Atomic has power by pressing the power button located on the front of the device. At least two LED lights should be displayed otherwise the Maxboost Atomic needs to be charged.
3. Make sure that the device that needs to be charged has a working battery.

## FAQ

### 1. How long does it take to charge my Atomic?

While there are many different ways to charge the Atomic, the average time to charge from a desktop computer is about 1-2 hours. Some chargers might be faster or slower depending on output.

### 2. What kind of cable should we use to charge the battery case?

The original micro-USB cable (which came with your S4), is specifically built to yield the most efficient results while charging. Therefore, it is highly recommended that you use the original cable. However, you can use other charging cables but efficiency may be greatly reduced.

### 3. How do I keep my battery healthy?

We recommend charging your battery at least once every month. We also recommend that you do not drain the battery completely to zero before recharging.

## Warnings

Read all the instructions before using this product. Failure to read and follow these safety instructions could result in fire, explosion, electrical shock or other hazard, causing serious and/or fatal injury and/or property damage, for which damages you, ("Purchaser") not Maxboost are liable.

1. Do not modify, disassemble, open, drop, crush, puncture or shred the product.
2. Do not expose the product to rain or water.
3. Keep away from open flame or sunlight to prevent heat build-up.
4. Keep away from high voltage devices.
5. This product is not intended for children and is not a toy. Keep away from children.
6. Ensure that all persons who use this product are familiar with the safety guidelines set forth in this manual.

## Warranty

We at Maxboost, are committed to building quality products that demonstrate superior performance and 100% customer satisfaction. We are so confident in our products that we provide a 1-year warranty from the date of purchase on all of our products. Make sure to check out [maxboostpower.com](http://maxboostpower.com) for more information.