

Philips
CD Soundmachine

MP3

AZ1856



Rip it all, play it back!

With the advanced AZ1856 CD Soundmachine, you can now convert your favorite CDs, radio programs and tape music to MP3 format with a single touch of a button. No computer required!

Continuous enjoyment of your favorite music

- Plays MP3/WMA-CD, CD, CD-R & CD-RW
- Enjoy MP3/WMA music directly from your portable USB devices
- Rip music from CDs, radio and cassette onto a USB device

Powerful sound you can hear and feel

- Bass Reflex speakers deliver a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic sound

Easy to use

- One-touch buttons for easy recording
- Handy remote control

PHILIPS
sense and simplicity

Specifications

Connectivity

- **USB:** USB host
- **Headphone:** 3.5 mm

Audio Playback

- **Loader Type:** Top
- **Playback Media:** CD, CD-R, CD-RW, MP3-CD, WMA-CD
- **Programmable Tracks:** 20
- **Disc Playback Modes:** Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- **Cassette Deck Technology:** Mechanical
- **Number of decks:** 1
- **USB Direct Modes:** Delete, Fast Backward/Fast Forward, Play/Pause, Previous/Next, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- **Tuner Bands:** FM
- **Antenna:** FM Antenna

Sound

- **Output power (RMS):** 2 x 1W / 60W PMPO
- **Sound System:** Stereo
- **Speaker diameter:** 3"
- **Volume Control:** rotary

Loudspeakers

- **Built-in speakers:** 2
- **Finishing:** Metal
- **Loudspeaker types:** Loudspeakers

Convenience

- **Display Type:** LCD

Accessories

- **Included Accessories:** AC Power Cord, User Manual, Warranty certificate
- Remote control

Power

- **Battery type:** LR14
- **Battery voltage:** 1.5 V
- Mains power
- **Number of batteries:** 6

Dimensions

- **Packaging dimensions (W x H x D):** 452 x 210 x 298 mm
- **Product dimensions (W x H x D):** 400 x 162 x 238 mm
- **Weight:** 3.14 kg
- **Weight incl. Packaging:** 4.15 kg

Audio Recording

- **Recording Media:** Tape, USB device
- **Tape Recording Enhancement:** CD Synchro Start Recording
- **USB recording modes:** Instant record, Programmed tracks, Single disc, Single track
- **USB recording sources:** CD, Tape, Tuner

Product highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

USB Rip All

With this smart feature, you can easily listen to all your music content on your Hi-Fi system directly from your portable MP3 player. Simply rip your desired music content from CDs, cassette tapes, radio programs or line-in music from your system directly to your USB device. Store your favorite cassette tapes and convert its content into MP3 format - without using a PC. You can also preset timer recording of your favorite radio show on your system and it will automatically record the show onto your USB device.

