

Method1 Charging the GoPro Hero3 Battery

- 1. Insert the GoPro Battery in the battery slot of the USB dongle, then connect the dongle to a USB port on the Power Bank
- 2. Press the Power Bank start button((U)) to turn on the devices (dongle status LED will be red)
- 3. When the battery is fully charged, the dongle status LED will turn green for a couple seconds, then both the Power Bank and dongle will switch off automatically

Charging the GoPro Hero3 Camera

- 1. Connect the GoPro Hero3 Camera to the Tenergy Power Bank with a mini USB to standard USB cable
- 2. Press the Power Bank start button((U)) to turn on the Power Bank (camera status LED will be red)
- 3. When battery is fully charged, both the Power Bank and camera will switch off automatically

Charging other devices using the Power Bank

The Power Bank can charge your smart phones, tablets, handheld gaming consoles and other mobile devices using the USB-OUT port of the unit. Connecting your mobile device to the USB-OUT port of the Power Bank using a compatible charging cable. Simply press the Power Button on the Power bank to start charging.



Charging the Power Bank

The Power Bank can be charged by connecting its micro USB input port to any standard USB port of a computer or USB wall charger using the charging cable came with the package (or any other micro USB to USB cable).

