

Tokio Smartphone

Tokio Smartphone 2.0



User Manual

1 What's Included

The following components are included with your purchased product:

- Tokio Smartphone
- Power Adapter
- USB Cable
- User Manual

2 Appearance and buttons



- 1. Touch screen**
- 2. Front camera**
0.3 mega pixels front camera
- 3. Earpiece**
- 4. Menu**
- 5. Home screen**
- 6. Back to previous step**
- 7. Volume +, Volume-**
- 8. Power switch**
- 9. 3.5mm headset jack**
- 10. Micro USB port**
You can use it to connect to PC for data transmission, charging or connection with external USB devices.
- 11. Back camera**
2.0 mega pixels back camera
- 12. Flashlight**
- 13. Speaker**


3 Getting Started

Before operating your Tokio Smartphone for the first time, please read this manual carefully and follow the instructions as described below.

4 Installing the SIM card/Micro SD card

Please install the SIM card/Micro SD card according to below procedures:

- With the phone turned off, hold your phone securely with the front facing down, lift up the back cover from the notch with your thumb or finger.
- Install the SIM cards/Micro SD card according the correction directions, see below:



- Install the battery according to correct direction.
- Align and secure the cover and press it down to close the back cover.

Note: the phone supports 2 GSM SIM cards and 2 GSM SIM cards are at standby mode after installation. It supports maximum 32GB micro SD card.

5 Battery charging



The smartphone is equipped with a built-in rechargeable Lithium battery. It is suggested to fully charge the battery before use.


We strongly recommend to use the power adapter provided in the packaging, using other adapter may damage the Phone and void the warranty.

Charging Process:

- Connect one end of the USB cable with power adapter, and then connect the other end of USB cable with your smartphone.
- Plug the power adapter into the nearest electrical outlet.
- Users can still use the Smartphone while it is being charged.

6 Turn ON/OFF Phone

1. Turn On: after the battery has been fully charged, press & hold the power switch for around 3 seconds to turn on the phone. Screen lock will be showed after starting up.
2. Turn Off: When the phone is ON, press & hold the power switch for around 3 seconds and the system will popup out “power off” option, tap on the option to turn off the phone
3. Sleep mode: when the phone is ON, briefly press the POWER button to turn off the display temporarily and switch your phone to Sleep mode. Your phone also automatically goes into Sleep mode when you leave the phone idle after a certain period of time. To wake up the phone from Sleep mode, just briefly press the POWER button again to wake it up.
4. Unlock screen: screen lock will be appeared after you start up your phone or the phone wakes up from sleep mode, to unlock the screen, Press and hold lock key  to drag it to unlocking icon  to unlock it to enter the main interface:



Remarks:

- When battery power has been used up, the phone will shut down itself automatically.
- If you illegally turn off the device, restart will scan and restore the memory, it may take longer time to enter into system.

7 Touch Operations

Tap: quick tap on an icon on the screen to enter that application.

Swipe or slide: slide your finger across the screen to go to next screen interface or page



































Press and hold: press and hold an icon to open the available options.

Press, hold and drag: Press and hold your finger on an app with some pressure before you start to drag. While dragging, do not release your finger until you have reached the target position.

Pinch: for some applications, like Photos or the web browser, you can “pinch” the screen using fingers to zoom in or zoom out.

8 Notification icons

These are the icons that may appear on the notifications area of the status bar:


	Connected to GPRS mobile network		Roaming
	GPRS in use		No signal
	Call in progress		No SIM card installed
	Missed call		Vibrate mode
	Call on hold		Ringer is silenced
	Call forwarding is on		Phone microphone is mute
	Mobile network signal strength		Battery is very low
	Connected to a Wi-Fi network		Battery is low
	Bluetooth is on		Battery is partially drained
	Connected to a Bluetooth device		Battery is full
	Airplane mode		Battery is charging
	Alarm is set		An open Wi-Fi network is available
	Speakerphone is on		Downloading data
	New Gmail message		Uploading data
	New text or multimedia message		Call in progress
	Problem with text or multimedia message delivery		Phone is connected via USB cable
	New Google Talk message		Data is syncing

Opening the Notifications panel

When a new notification icon displays in the status bar, press and hold the status bar, then slide your finger downward to open the Notifications panel.

If you have several notifications, you can scroll down the screen to view more notifications.

On the notifications panel, there are below shortcut settings easily for you to setup:



1. Owner: to setup the owner info of your phone.
2. Airplane mode: tap on it to turn on/off the Airplane mode.
3. Battery status: tap on it to see the battery consumption status.
4. Wi-fi: tap on it to turn on/off the wi-fi connection.
5. Bluetooth: tap on it to turn on/off the Bluetooth connection.
6. GPS: to determine location through Wi-Fi
7. Data connection: to turn on/off Mobile data connection.
8. Data Usage: tap on it to see the data usage details.
9. Audio Profiles: to select the phone modes: General, Silent, Meeting, Outdoor.
10. Brightness: tap on it to adjust the brightness of the screen.
11. Timeout: tap on it to setup different phone idle time before screen goes to sleep mode.
12. Auto rotation: tap on it to turn on/off “Auto rotation of screen”.

9 Personalize Your Phone

● Language

Go to “Settings”, and find “Language & input, then select your desired language, default your desired input method and Android keyboard.

● Set Date and Time

Go to “Settings”, and find “Date & time”, then tap on it to enter and select the correct time zone and setup your desired date and time.

● Display settings

Go to “Settings”, and find “Display” menu, then tap on it to enter, you can setup your desired screen Brightness, Wallpaper, Auto-rotate screen, Screen lock style, Animation, Screen timeout, font size etc.

- **Change ringtone**


Go to “Settings”, and find “Audio profiles” setting, then tap on it to enter and then select the right phone mode(General), then enter to default the Volumes, Phone ringtone, Message ringtone, Notification ringtone.

- **Setup screen lock**



Go to settings, and find “Security”, then tap on it to enter and setup your screen lock(Slide, Pattern, PIN or password).

10 Connection with PC

The phone has a micro USB connector which allows it to communicate with a computer. After connecting the phone with PC through the cable provided, then below USB connection screen interface will pop up, tap **“Turn on USB storage”** to connect to PC.




Then tap “OK” to confirm the message to connect your phone with PC. Then go to “Settings”→“Development Options”, then tick on “USB debugging”, then your phone will be connected to PC, and an additional external drive can be found on your PC.





11 Phone Desktop Screen

1. After starting up, you will enter into below main desktop screen:











2. On the main desktop screen, you can manage the app icons: press on the icon and hold it for 3 seconds, then you can drag it anywhere on the main desktop screen.
3. Delete icons: press the icon and hold it for 3 seconds, and drag the icon onto the “ Remove” icon, then you can delete that icon from desktop.
4. Touch on the blank area on the main desktop screen(not on icons) and hold for around 3 seconds, the dialog box “Choose wallpaper from” will pop out as shown below, tap on the sources(Gallery, Live Wallpapers, Video Wallpaper, Wallpapers) to select and change the wallpaper, see the below screenshot.





5. On the main desktop screen, you can touch the icon  to see all the APPS, tap on any App icon and hold it for around 3 seconds, you can drag that App icon onto main screen interface.

12 Phone Calls


1. Making Calls

- A. Go to app list and find phone call icon , tap on it to enter, then find the dial panel to input the phone number which you are going to call, tap  to delete the wrong number inputted, after inputting the right phone number, tap on icon  to initiate the call, system will remind you to choose SIM 1 or SIM 2 to make the call.
- B. If you want to make a call to the one whom you just called or who just called you, you can tap on the call log icon  view the call history, find the phone number and tap on icon  to start the call.
- C. You can also make a call from the Contacts directory, just tap on the Contacts icon  to enter into Contacts directory and find the your contact to start the call right away.
- D. You can also tap on  to hide the dial pad and tap on  to add the contact into contacts directory.




2. Receive Calls

When a call comes in, you will see below screen interface:




Slide call icon  rightward to answer the call.



3. Refuse Calls




Slide lock icon leftward onto the icon  to refuse the call.


4. Missed Calls

If you missed a call, the icon  will be displayed on the status bar, press and hold on the status bar then drag it down to see the missed call. Tap on the missed call to call back.


5. Call Log



Go to app list and find phone call icon , tap on it to enter, then find the Call Log icon , tap on it to see all the call history.

Tap on “All” to view all the call history, tap on  to see the phone numbers you have called, tap on  to see the phone numbers which have called you, tap on  to see the missed calls.

If you want to delete all the call history, tap on Menu icon , system will prompt option to delete call history, tap on it and confirm the selection to delete all call history.


6. Create Contacts

- When you initiate a call, after you input the phone number, you can tap on “” to add the current phone contact into your contact lists.
- When you view the call log, tap on specific phone number, then tap on icon “Add to Contacts” to add that contact into your Contacts directory.
- You can also add contacts by running the Contacts application, go to

app lists and find the Contacts app icon , tap on it to enter, then tap on icon  to create new contact by following the steps.

7. Options during the call


There are many options during your call, see below:



1) Adjust Volume

During the call, you can adjust the volume by pressing volume+ or volume-.

2) Switch Call


During the call, you can tap on icon  to switch the call.

3) Add Call

During the call, you can tap on icon  to add another call, input the second call number and make second call at the same time.

Note: this function needs SIM card to have multiparty call feature.

4) Dial Pad

During the call, you can tap on icon  to run the dial pad.

5) Loudspeaker

During the call, you can tap on icon  to open the loudspeaker.


6) Mute

During the call, you can tap on icon  to mute the MIC, this way, the callee will not hear your voice.

7) Contacts


During the call, you can tap on icon  to view your contact lists.

8) Record The Call



During the incoming call, you can tap on menu icon  to record the call.

13 Messaging

1. Check message

- 1) Tap on “Messaging” icon  to enter.
- 2) Then all messages will be displayed automatically, tap on specific message to see the contents.

2. Send SMS message



- 1) Tap on “Messaging” icon  to enter.
- 2) Tap on icon “Compose new message” to compose new message.
- 3) Input the phone number which you want to send the message to, or select the contacts from your phone Contacts by tapping on .
- 4) Input the text message and send.

3. Send MMS message

When creating message, it was defaulted as SMS, it will be changed to MMS automatically when you add an attachment.



Note: you can send messaging to multiple contacts at the same time.


14 SIM management


On the Desktop screen, tap , and then you can see all the apps, tap the Settings icon , and then select "SIM Management", then you can start up below settings:


- 1) SIM INFORMATION
The SIM information will be displayed here, and you can activate or deactivate the SIM by sliding the ON/OFF bar.
- 2) DEFAULT SIM
Since this is a smartphone supports dual-SIM, you can default one SIM as the defaulted SIM for Data connection.
You can also turn off the “Data connection” here for both SIM's.
- 3) GENERAL SETTINGS
You can turn on/off Roaming for each SIM, and select the roaming reminder type(Once, Always or Never)

15 Wi-Fi settings


On the main desktop screen, tap , tap the Settings icon , and then select "Wi-Fi", then turn on Wi-Fi by sliding the Wi-Fi bar, the phone will automatically scan display all available Wi-Fi networks:



Connecting to a Wi-Fi network: tap on your Wi-Fi network and start to connect. If the Wi-Fi network does not need a password, tap "connect" to start the connection. If the Wi-Fi network needs a password, then input the password and tap "connect" to start the connection. If the Wi-Fi network has been successfully connected before, that information will be stored, connection will be done automatically. Once your phone connects to Wi-Fi successfully, the Wi-Fi icon  will appear on the status bar.


If your Wi-Fi network has been hidden, you need to tap on "" to manually setup your Wi-Fi network.

16 Bluetooth

Go to Settings , then select the "Bluetooth", turn on the Bluetooth by sliding the Bluetooth bar, the phone will automatically scan all available Bluetooth devices and list them immediately or you can tap on "SEARCH FOR DEVICES" to scan the Bluetooth devices manually.

Tap on your desired bluetooth device to pair it right away.

Your phone name will be showed on screen, tap on it to make your phone visible to other nearby Bluetooth devices, tap on it again to make your phone invisible to other nearby Bluetooth devices.



17 More Settings

In the Settings menu, touch on "More" menu to access more settings for the phone:

Aeroplane mode: select to turn on/off the Airplane mode.

VPN Settings: to set up & manage Virtual Private Networks.

Tethering & portable hotspot: to share your phone's mobile data connection via USB or as portable Wi-Fi hotspot.


Mobile networks: settings on our mobile network:

- Data connection: to see the data used in current period.
- Access Point Names: to set up the APN for each SIM
- Network operators: to set up network operators for each SIM.
- Mobile data service prefer: Mobile data service preferred is used to improve the data transmission efficiency at the cost of lower call receiving rate.


USB internet: sharing windows PC internet via USB cable

18 Audio Profiles

In the Settings menu, touch on "Audio profiles" menu to customize the phone's sound settings based on your requirements.





First, please select the correct phone mode before your specific settings.



- Vibrate: Select to vibrate the phone for incoming calls.
- Volume: Select to adjust the volume of the incoming call, alarm, notification and media etc.
- Phone ringtone: to select the desired ringtone for your incoming calls.
- Message ringtone: to default the desired ringtone for your message.
- Notification ringtone: to default the desired notification ringtone for your phone.
- Audible touch tones: select to make your dial pad with touch tones.
- Touch sounds: select to play sound when making screen selection.
- Screen lock sound: select to make your screen lock/unlock with sound.
- Vibrate on touch: vibrate when pressing soft keys and on certain UI.
- Vibration intensity: setup your touch feedback vibration intensity.


19 Display Setting



- Lock Screen notifications: select it to choose screen lock style.
- Workspace transition effect: tap on it to setup the workspace transition effect.
- Brightness: click the settings bar , slide to adjust the brightness of the screen, and then click "OK" to confirm or "Cancel" to exit.
- Wallpaper: tap on it to setup the wall paper, you can import the wallpaper from Gallery, Live Wallpapers, or the existing built-in Wallpapers gallery.
- Auto-rotate screen: select it to allow the screen automatically rotate according to the position of phone.
- Font size: select it to adjust the screen font size.
- Sleep: tap on it to setup the time of inactivity for screen to enter into sleep mode.
- Horizontal calibration: tap on it to calibrate horizontally using accelerometer.

20 Storage

You can select the memory source to install the applications, you can also check the storage details of external SD card, internal phone storage and phone storage. You can also erase all data on the phone storage, such as music and photos, and you can also unmount the SD card safely here.




【Remarks】 :


If you want to safely remove the Micro SD card, please tap on the option "Unmount SD Card", and confirm the selection, after this, you can safely remove SD card.

21 Applications

In the Settings menu, touch on "Apps" menu to customize the phone's application settings based on your requirements.




- Manage applications: tap on the directories(Downloaded, SD card, Running or All) and select the application which you want to uninstall, you will enter into the following interface, tap on Uninstall, then you can remove that application from your phone.



22 Add account

You can add account by tapping "Add account". You can add corporate, Email or Google account.




23 Security


Tap on the "Security" to set up:



Screen lock: You can completely disable the screen lock, but it is recommended to use protection, such as pattern password.




Select "Pattern" and then click "Continue"




Perform the unlock pattern by connecting at least 4 points, and then click continue, to save a pattern.

PIN: The PIN code will be a screen lock:



Enter 4 digits, and then tap OK to lock the screen. When the device is switched on or off, you will be prompted for a code to unlock the screen.

Password: Enter the password that will be used to lock the screen.



When you turn on your Phone or unlock the screen, you will be prompted for a password.

SIM Card Lock: tap on “Set up SIM card lock”, you will need to tick the option of “Lock SIM card”, then you will be required to input PIN number to lock the SIM card. Once you lock the SIM card, you need PIN to use the phone.

Make passwords visible: tick this option to make your passwords visible when you input the passwords.


Device administrators: to add and remove device administrators. If you do not have administrators, tap menu ico to add the administrator.

Install from SD card: tap on it to install the certificates fromm SD card.

Set password: to set or change the credential storage password.

24 Language, keyboard, voice

Touch the "Language & input" to access to the following settings:



Language settings:

In addition to the English language, the phone supports different languages . You can scroll the languages list to select your desired language.


Keyboard & input methods:

You can perform different settings on the Android Keyboard and input methods.

25 Backup & reset


Factory data reset


Allows you to erase all personal data from the phone.



Warning: once you perform the “Factory data reset”, it will erase all personal data in Phone, make sure to back up your personal data before performing this function.


26 Date & time

Tap the "Date & Time" to access to the settings. Uncheck the box  of "Automatic date & time" to manually setup the date, time and time zone.



Set the date:

- In the settings, chose the correct day, month and year, and then tap the "Done" button to confirm.




Select your time zone:

Select the correct time zone according to your location.

Set time:

In the settings, chose correct hour and minute, and then tap the "Done" button to confirm.




24-hour format: allows you to set the time 0-24

Select the date format: allows you to set the appropriate date format.

27 Schedule Power On/Off



You can setup to schedule the power on/off your phone.



28 Accessibility

You can download the accessibility related applications from Play store.


You can also have more settings here to help blind and low vision users.



29 Developer options

More advanced settings for the phone.

Once you connect your phone with PC, please make sure to turn on the USB debugging, this way, your phone can connect with PC.



30 About phone

Additional informations about your Phone


31 Apps Installation

You can download the Apps from Google Play Store and install them online, or you can install the Apps from your Micro SD card. Just tap on the APK file and run the installation, you can finish the installation and run that App right away.

32 Introductions of Typical Applications

- **Browser** 

After connecting your phone to Wi-Fi network, tap the **Browser** icon on desktop to open web browser. The following interface pops up immediately:



Then you can start web surfing now, during web surfing, tap on the menu icon to get more options:

Refresh: to refresh the page

Forward: if you go back to previous page, use Forward to go to the page just visited.

Stop: to stop the web browsing.

Home: to go to home page.

Save to bookmarks: save your current site to Bookmarks.

Close: option of Minimize the page or quit the web browsing.

Save for offline reading: to save this page for offline reading.

Share Page: share the page with your friends via mail.

Find on page: to search on page.

Request desktop site: to set the page as desktop site.


Bookmarks/History: to see your most visited websites and Bookmarks.

Settings: more settings on General, Privacy&security, Accessibility, Advanced, Bandwidth management, Labs.

- **Calculator**




The phone is with built-in calculator, tap on the **Calculator** icon to carry out your calculations:



- **Calendar**





Users can use the Calendar to check date, time and memorandum or add memorandum etc.





- **Camera** 

Tap on the Camera icon to run the application

The front camera is located at the centre of Phone top, aim at it when you take photo or video.

If you want to take photo, tap on the icon  to take photo; tap on the icon  to switch front/rear cameras.

Tap on the icon if you want to take video, tap on icon  to take video,




The photos or videos will be saved automatically (File Location: File Mang →sdcard/Phone storage→DCIM→Camera).


You can also view your previous photos or videos by tapping on the photo icon at the top right corner of screen. When you view the photos or videos, you can send the photo/video by Messaging, Bluetooth, or Email, you can also delete the photo/video. Tap on Menu icon, there are more options of Slideshow, Edit, Print, Rotate left, Rotate right, Crop, Set picture as, Details.


- **Clock** 

Tap on the **Clock** icon to run the application.

After running the **Clock** application, you can create a new alarm.




Tap on  you can add more city to your phone, then you can view the local time of different worldwide cities.



The Clock application also offers Timer and Stopwatch functions as well.

- **Downloads** 

Tap to check all downloads history




- **Email**



You can enter one or more personal email address which you would like to access through this Phone.

Tap on **Email** icon to setup your email account according to the procedures. You can receive or send e-mails after setup.

To read emails, tap on the **Email** icon, if you setup only one email account, it opens immediately, if you have setup multiple accounts, they will be listed in the **Accounts** screen. Tap on the desired email account, all emails will be listed, tap on the email which you want to open. You can also **Reply**, **Reply all**, **Forward** or **Delete** the emails.

On the Inbox screen, you can **Compose New Email**, **Refresh Inbox**, type on menu icon  for more settings on your Email account.



- **File Manager**



Tap on **File Manager** icon to browse the files saved in your memory devices(SD card or Phone storage). You can sort the folder by categories, you can create folder, search file.

Tap on corresponding memory devices(SD card or Phone storage) to see the files inside.

Tap on the file folder/file and hold it for 3 seconds, you will have the options of: Copy, Cut, Delete, Rename, and Details.



- **Play Store**



Before you log into the Play Store, you need to add a Google account to the device.

1. If you do not have a Google Account, then tap “Create” to create a new Google account, if you already had a Google Account, tap on “Sign in” to sign in,
2. After tapping on “Sign in”, you need to input your Gmail address and password, then tap “Sign in” to go forward.
3. Then you have to accept the Google Play Terms of Service to enter into **Google Play**. You can download more apps from the **Google Play Store**.


If you want to download apps from **Google Play**, tap on the app icon which you want to download, follow the procedures to download the app and install it onto your phone.

- **Music**



To play the music, tap on the **Music** icon to run the application.



All songs will be listed and tap on your desired song to play it.





- **Sound Recorder** 

To start the sound recorder, tap on the Sound Recorder icon to run the application.



Tap on the icon  to start recording.

Tap on the icon  to pause recording, tap on  to resume the recording.

Tap on the icon  to finish and save the recording.

Tap on the icon  to play the recording just recorded.


The recorded files can be found at File Manger → sdcard/Phone storage → Recording



- **Gallery** 


To play the videos or photos, tap on the **Gallery** icon to run the application.

All videos and photos will be listed and tap on your desired video or photo to play it.



- **Contacts** 


Tap on **Contacts** icon to run the application.

If you want to add new contacts into the directory, just tap on icon  to create new contacts into the directory.

To search for contacts, tap on the icon 


If you want to edit the existing contact, tap on the contact and hold it for 3 seconds, then system will prompt the options, choose the option of “Edit contact” to edit the contact.

Tap on the contact and hold it for 3 seconds, system will prompt the options of “Call contact, Text contact, View contact, Edit contact, Delete contact, Add to speed dial, Share contact”, you can choose different option to achieve your requirement.




- **Videos** 

To play the videos, tap on the **Videos** icon to run the application. All videos will be listed and tap on your desired video to play it.



- **FM Radio** 

To play the FM Radio, tap on the **FM Radio** icon to run the application. Before you start listen to the radio, you need to connect your earphone headset(which is not included in your purchase), the earphone headset will be used as radio antenna.



33 Important maintenances precautions

In order to offer your phone good maintenances, please always follow the below basic precautions:

- Keep it in a safe distance from the strong magnetic field.
- Keep it away from water.
- Keep it and its accessories away from children.
- Prevent the device from falling or impact during usage, as this may cause damage to the phone.
- Do not use the device in a extremely humid environment or in the rain, because moisture penetrates inside and may damage the phone without the possibility of repair.
- Do not clean your phone using harsh chemicals, detergents and chemicals that can dissolve the plastic.
- Do not use headphones at maximum volume. This is dangerous and can lead to permanent hearing loss.
- Do not place other objects on LCD screen, as it may crush and damage the LCD screen.
- Do not use any sharp objects to touch the LCD screen, as this will scratch the screen.
- Only use the AC adapter included with the device. Using any other power adapters will damage your phone and void the warranty.
- Do not attempt to dismantle the phone by yourself to do any repair, this will damage the phone and void the warranty.

34 Battery Management

The battery is not fully charged from factory, so it is recommended that you charge the battery for at least 4 hours before you start to use the device.

The rechargeable battery is designed and manufactured to be used and recharged frequently. As same with all of lithium batteries, the capacity of the battery reduces each time it is charged. However, you can still try to prolong the battery's lifetime by following the suggestions below:

- Use your Phone at least once a week.
- Fully charge the battery regularly.
- Never leave the battery fully discharged for a long period of time.
- Always keep the device and the battery away from heat and moisture.