



AX155

Quick Start Guide



Activating the
Speakerphone



Recording a
Voice Dial



Sending a
Text Message

Getting to Know Your Phone




Navigation Key

- ^ Calendar
- v Contact List
- > Alltel Shop
- < Ringers

Left Soft Key

Talk Key

Vicemail Key



Speaker

Right Soft Key

OK/
Menu Key

Power/
End Key

Back/
Speakerphone
Key



Space Key



Activating the Speakerphone

Need to take a phone call while performing other tasks?
Want to have an impromptu conference call? Do both
with the AX155's powerful speakerphone.

1. During a phone call, press and hold **BACK/⟲** to activate the speakerphone.
2. To deactivate the speakerphone, press and hold **BACK/⟲** once more.




Recording a Voice Dial

Quickly call frequently accessed contacts using voice dialing. You can record voice dials for up to 30 entries in your address book.

1. From standby mode, press **OK MENU** to access the main menu.
2. Select **Voice Service (4)**, then **Voice Dialing (1)**.
3. Press the **Left Soft Key** for **New**.
4. Highlight the contact for whom you wish to record a voice dial, then press **OK MENU**.
5. Press **OK MENU** to begin recording.
6. After the prompt, say the contact's name. You'll be asked to repeat the name for increased accuracy.


Note: After recording a voice dial, you can use this feature with one touch. From standby mode, press and hold **TALK**. After the prompt, say the name of the contact you want to call. The AX155 will automatically dial the associated number for you.



Sending a Text Message

Have a conversation without saying a word! Text messaging is an efficient, discreet way to chat when you're in a loud environment or don't want to disturb those around you.

1. From standby mode, press the **Right Soft Key** for **Message**.
2. Select **New Text Message (1)**.
3. Enter a phone number or e-mail address, or press the **Right Soft Key** to select someone from your address book, recent calls, or groups.
4. Scroll down the text field and enter your message using the alphanumeric keypad. You can add graphics, animations, or sounds by pressing the **Right Soft Key** and selecting **Add (1)**.
5. When you're finished, press **OK** to send the message.



Optional Accessories

Maximize your phone with these cutting-edge accessories at www.LGmobilephones.com/AX155.



Vehicle Power Charger



Headset



USB Data Cable

©2008 LG Electronics, Inc. All rights reserved. All other trademarks are property of their respective owners. All phone images are simulated.



Mixed Sources

Product group from well-managed forests, controlled sources and recycled wood or fiber

www.fsc.org Cert no. XXX-XXX-XXX
© 1996 Forest Stewardship Council

