


SE21 :: Basic Inductive Phone Neckloop

Inductive neckloop for send voice signals to micro earpiece and connect to most kinds of mobile phones

Exclusive designed wire box and high-strength cable wire.

Physical Introduction



Package Includes

Basic neckloop is packed in a plastic bag. Each set include below items. If anything missed please contact with seller.

- 1pc SE21 basic black neckloop with microphone clip and microphone sponge cover

Frequently Asked Questions

Q: Why voice is low?

A: Please wear neckloop slantly to get louder volume. Refer to step II in right side.

Q: Can I Use Battery on SE21 Neckloop?

A: No, SE21 is non-power inductive transmitter, and exclude power circuits. Microphone on SE21 is use power from mobile phone.

Q: How to enlarge the power of neckloop?

A: You can choose new model 3.5watt SE26 to get very powerful signals.

Q: What is the package/bag of SE21?

A: SE21 is pack in plastic white bag. You can order EVA bag to pack SE21 neckloop.

Quick Start

Connect with Mobile Phone

SE21 comes with new jack, 3.5mm 4pins the key feature of TE21 is built in Microphone. Including Answer Button and AV Switcher. 2 colors available, beige and black.

AV Switcher : control the switch iphone or NOKIA joint. Upward is for Iphone, SAMSUNG, HTC, MIUI and HUAWEI etc. Downward is for NOKIA


Answer button: Short press it to receive the call. For some mobile phones, to press twice or three times of the button can realize the controlling the up or down of playing music

Plus 3.5mm jack into headset socket in mobile phone, then confirm the neckloop is for "Audio Output/Input" if mobile phone remind you to choose the headset type.

Wear Neckloop

Wear neckloop on your ear and put microphone in collar position with microphone clip.

If you need louder volume in earpiece, please wear the neckloop slantly same as below sketches showing



Use Neckloop with Earpiece

Now you can load button battery into spy earpiece, then wear earpiece in left or right side of ear canals.

Make a call or play music in mobile phone, you will hear sounds in spy earpiece.

Warranty

The default warranty of SE21 basic neckloop is 1 year since ship date. Warranty will be invalid in below conditions:

1. Passed more than 12 months since ship date.
2. Open case or and change circuits with our authorization.
3. Other kinds of problems caused by wrong operations.