

USER'S MANUAL



MAGNA-JET[®] For HydroBaths



MAGNA-JET[®]



Sensor/Control Box

CLEAN- RELIABLE- WORRY FREE



When using electrical equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read and follow all instructions before using the equipment
2. Do not play with the magnetic impellers
3. Do not place the magnetic impellers close to each other
4. Keep the cord out of heavy traffic area. To avoid fire hazard NEVER put the cord under rugs, near heat generating devices
5. Always turn off the equipment before servicing
6. Do not drop or insert any object into any openings
7. Do not operate any equipment with a damaged parts
8. Any other use not recommended by the manufacturer may electrical shock or injury to persons
9. Never use outdoors
10. Do not attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void the warranty.

After reading this owner's guide, if you have any questions or comments, please call +1-817-633-1080 or contact our technical support department at support@luraco.com or visit our website at www.luraco.com for more information

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

FEATURES - OPERATIONS

MAGNA-JET Features

- Powerful massage Jet-streams
- Jet assembly can be detached from the pump for quick cleaning and sanitizing
- Built-in electronics sensor for pump control
- Automatic shutdown when the jet head is removed from the pump
- Long life AC motor
- Low power consumption
- The Sensor/Control Box supports up to 6 JETs.
- Built-in controlled port for color light
- **Proudly Manufactured in U.S.A**

MAGNA-JET System Installation

1. Determine the surface of the tub that you want to install the unit, ensure that the surface is flat
2. Locate a position to drill a hole with the dimensions as shown in Fig. 1
3. Insert the unit into the hole from inside the tub
4. **Use a hand screwdriver to tighten the four screws**
5. Plug the power cord of the unit into the Magna-JET Sensor/Control Box




Figure 1. Drill Instruction

Cleaning Instructions

1. Ensure the unit is off and clean the JET head one at a time
2. Use the key to remove the JET head from system (Please refer to figure 2 below)
3. Use anti bacterial solution to clean and sanitize all the plastic parts
4. Reassemble the system



Step 1: Place the key in the locking position

Step 2: Pull to remove the JET head

Figure 2. JET Head Removal Instruction

WARRANTY INFORMATION

Two (1) YEAR LIMITED WARRANTY

1. This Warranty applies only to the original purchaser of this product.
2. This Warranty applies ONLY to repair or replacement of any supplied or manufactured parts of this product. The warranty does not cover normal wear, coating, dropped or abused unit.
3. Unless otherwise proscribed by law, The LURACO technologies, Inc. shall not be liable for any personal injury, property or any incidental or consequential damages of any kind resulting from malfunctions, defects, misuse, improper installation or alteration of this product.

Attention: Any modification to the MAGNA-JET without our instruction will void the warranty

THANK YOU FOR BUYING LURACO TECHNOLOGIES' PRODUCTS

LURACO TECHNOLOGIES, INC.

1132 107TH STREET

ARLINGTON, TX 76011

TEL: +1-817-633-1080

FAX: +1-817-633-1085

WWW.LURACO.COM