

SIMPLE HOW TO'S FOR HONEYWELL KEYPADS

VISTA / ADEMCO / FIRST ALERT

Reset	Enter your code Then press the number 1
Arm (See note below)	Enter your code Then press one of the following: AWAY - to leave and motion/s will be activated STAY - while at home motion/s are de-activated. can also be used to leave and not have motion/s on INSTANT/ NIGHT - doors are on instant (no delay) and motion/s are deactivated MAX - Everything on and entrance delay off - best used for extended away like a vacation
Disarm	Enter your code Then press the number 1
Bypass	Enter your code Then press the number 6 Then enter the 2 digit Zone number that you want to bypass (e.g. 01)
Silence Fire	Enter your code Then press the number 1
Silence Beeping	Enter your code Then press the number 1
Chime On/Off	Enter your code Then press the number 9
Trouble Misc	Will appear on Display
A/C Loss	"NO A/C" The power light will be off
Low Battery	"BAT" Beeping or Zone #
Communication Failure	"FC" will appear

Note: To ARM system -there are some variations with different models. Please refer to your User Manual or call us if you have any questions. (User Manuals can also be downloaded from this website)