

# LED Daytime Running Light Controller <u>LC-DRL06</u> User's Manual

# **Product Features:**

- Multi-purpose controller have auto ON/OFF, including LED Daytime running light, LED Strip light and various LED lights.
- Install to Car battery directly, do not need any wires to ignition switch, and light ON/OFF will be followed with battery, easy for operation and installation.
- Automatic light: When engine of car start, DRL will automatic to work always mode.
- Reduce 50% DRL brightness once light on Headlight.
- Automatic delay turn off function: Approx. 10 ~ 15 seconds delay as you turn off key ignition.
- Defend Electromagnetic Interference.
- Small and exquisite design, easy for operation and installation.

## **Product Description:**

- Suitable for 12VDC Vehicle.
- Load Power: 24W (Max.)
- Box Size: 40x18x21mm (LxWxH)
- With 3pcs connector.
- Controller is anti-vibration and 100% waterproof.

### **Installation Instruction:**

- Please install wires according to below drawing, please do not connect with other wires.
- If there is no working, please double check all wires.



### Warning:

- Please check before using this controller firstly, or there will be no function.
  - (1) Battery voltage must be over 13.3VDC once engine turn on.
  - (2) Battery voltage must be below 13.3VDC after engine turn off.
- Please install this product according to user's manual and also by professional shops.
- Installation carefully and do not pull wire excessively, in order to avoid any damage of wire.
- Our company will not be responsible for the damage of changing product.