

## Trouble Shooting Bunk Lift Control Box 1510000199 For In-wall Slim Rack Systems

© Copyright Power Gear Issued: January 2013

#82-S0530, Rev. OA

Read, understand and follow all instructions in Installation and Service Manual 3010002675 before starting. This trouble shooting is for the In-wall Slim Rack Bunk Lift with control box part number 1510000199.




## **MARNING**


Always make sure that the bunk path is clear of people and objects before and during operation of the bunk lift. Always keep away from the bunk lift rails when bunk is being operated. The gear assembly may pinch or catch on loose clothing.


Table of Contents: Page: Introduction 1 Wiring diagram 2 Bunk lift will not move when touch pad is pressed 3 "A" 1 green LED and 2 red LED flashing on touch pad 4 "B" 1 green LED and 6 red LED flashing on touch pad 5 "C" 1 green LED and 4 red LED flashing on touch pad 6 "D" 2 green LED and 4 red LED flashing on touch pad 7 Engage park brake LED is flashing on touch pad 8 Low voltage LED is flashing on touch pad 9 Additional reference documents 10


1217 E. 7<sup>th</sup> St. Mishawaka, IN 46544 www.powergearus.com




















## Additional Reference Documents Located At www.powergearus.com.

Document #	<u>Description</u>
3010002678	Owner's manual slim rack in-wall bunk lift system control box part number 1510000199
3010002675	Installation & service manual slim rack in-wall bunk lift system control box part number 1510000199
82-S0531	Encoder test 1 Dual planetary gear motor sync with control box 1510000199
82-S0532	Encoder test 2 Dual planetary gear motor sync with control box 1510000199