



DOLL CRIB WITH STORAGE DRESSER AND TRUNDLE DRAWER

MODEL NUMBER:
01726

Assembly Instructions.
Adult Assembly Required.



Visit us online at www.badgerbasket.com

Toll-Free Customer Service: 1-800-236-1310 (Monday to Thursday 7:30 AM-4:30 PM CST)

Web: <http://www.badgerbasket.com/parts> • **E-mail:** parts1@badgerbasket.com

Mail: PO Box 227, Edgar, WI 54426-0227 • **Phone:** 715-352-2311 • **Fax:** 715-352-3163



BEFORE YOU BEGIN ASSEMBLY:

Check all parts and hardware.

If anything is missing or not satisfactory,
please **DO NOT** call the store or return the product to them.

Contact Badger Basket for assistance.

Most problems are resolved without you needing to leave home.

When contacting us, please have this instruction manual, your product model number, and your product version code ready.

For fastest service, go to

<http://www.badgerbasket.com/parts>

Your Product Version Code is: 1.0/0508/TG

USE AND CARE INSTRUCTIONS:

Wipe the wood/MDF clean with a damp cloth and mild soap as needed. Hand washing or spot cleaning is recommended for the fabric parts to prolong the life of the toy.














WARNING - CAUTION

READ ALL INSTRUCTIONS before use of this product. Product and/or hardware may include small parts or screws with sharp points.


Choking Hazard! Keep unassembled parts out of the reach of small children.

Use only the parts and hardware provided by Badger Basket.

Keep instructions for future use. Do not use the product if it is damaged or broken. Periodically inspect the product and retighten hardware if needed. **This item is a toy for dolls only.** It is never to be used for real children or pets. **For children ages three (3) years and older.**

 <p>FOOTBOARD Ax1</p>	 <p>SIDE RAIL Bx2</p>	 <p>BOTTOM PANEL Cx1</p>	 <p>HEADBOARD Dx1</p>
 <p>DRESSER TOP Ex1</p>	 <p>DRESSER END Fx1</p>	 <p>DRESSER SHELF Gx1</p>	 <p>DRESSER BOTTOM Hx1</p>
 <p>DRAWER BACK Ix1</p>	 <p>DRAWER SIDE Jx2</p>	 <p>DRAWER BOTTOM Kx1</p>	 <p>DRAWER FRONT Lx1</p>
 <p>DRAWER WHEEL Mx4</p>	 \varnothing 5x50mm Nx16	 \varnothing 4x35mm Ox14	 \varnothing 4x10mm Px16
 <p>TOOL REQUIRED (NOT INCLUDED)</p>	<p>PARTS NOT SHOWN: Qx2 - BASKET Rx2 - BASKET BOTTOM Sx1 - FABRIC LINER Tx1 - LOWER MOBILE ARM Ux1 - UPPER MOBILE ARM Vx1 - MUSIC BOX Wx1 - MOBILE CROSS ARMS Xx4 - MOBILE SHAPE Yx1 - FABRIC BLANKET Zx1 - FABRIC PILLOW</p>		


①




GROOVES ON PART B FACE THE INSIDE AND ARE ON THE BOTTOM.



②




3





Ø5x50mm
Nx4

4





Ø5x50mm
Nx4

5





Ø4x35mm
Ox4

6




Ø4x35mm
Ox10

7




Ø4x10mm
Px16

8



9

ASSEMBLE THE BASKETS (PART Q) BY OPENING/UNFOLDING THEM AND INSERTING THE BASKET BOTTOMS (PART R). THE BLANKET (PART Y) AND PILLOW (PART Z) ADD TO THE FUN!

