

MODEL 790-6 SOLID STATE AMPLIFIER INSTALLATION AND OPERATION INSTRUCTIONS

DESCRIPTION

The Raymer Model 790-6 is a monaural all silicon solid state amplifier with an audio output of 6 watts sine wave (RMS). The amplifier is designed for use with a high impedance microphone in Public Address installations, or with a ceramic or crystal phono cartridge, a tuner, or other auxiliary equipment. The amplifier has speaker outputs of 8 ohms, 25 volt line, 70 volt line.

UNPACKING:

The unit is to be removed carefully from the carton and inspected for any possible damage in transit. If there is any evidence of any damage which might have occurred in shipment, notify your dealer at once, or the transportation company which delivered it. Claims for damage sustained in transit must be made upon the Carrier. Save all packing material for inspection by the claim agent who will furnish you with the proper forms and will also give you the necessary instructions for filing a claim. In addition to the Unit, there should be a warranty card included in the carton.

To insure proper servicing and to protect your rights under the warranty, be sure to fill in the warranty registration card without delay and mail to the factory.

WARRANTY

This unit has been very carefully inspected and should require no further service. Each unit is warranted to be free from defects in material and workmanship under normal use and service for a period of one year from date of delivery to the original purchaser. If this unit appears to be defective, the factory will repair any unit returned within said one year, providing all transportation charges are pre-paid, and which our examination shall disclose to our satisfaction to be defective.

This Warranty does not include free labor, nor is it applicable to any unit which shall have been subject to accident, tampered with, mis-used, abused, or altered in any manner whatsoever. Further, this Warranty shall not apply to any unit which has been connected improperly.

It is recommended that any unit on which service is required, be processed through your dealer wherever possible.

This Warranty is expressly in lieu of all other Warranties, expressed or implied, and of all other obligations or liabilities on our part. We neither assume nor authorize any other person to assume for us any other liability in connection with the products manufactured by Trutone Electronics, Inc.

INSTALLATION:

Because of its attractive appearance this unit may be placed on a table or a shelf. Although the unit has ample vents for normal ventilation, sufficient space should be allowed around it to permit free air flow. DO NOT PLACE it on top of vacuum tube equipment. DO NOT STORE OR OPERATE it in areas where the ambient temperature exceeds 140 degrees Fahrenheit. If installed in a cabinet, ample ventilation must be allowed around the unit.

Plug the AC line cord in any outlet furnishing 105 to 120 volts, 60 cycles AC.

An AC receptacle is located on the back of the chassis to supply power to other components such as phonograph motor, etc. The auxiliary equipment connected to the AC receptacle is controlled by the POWER on-off switch so that turning off the unit turns off all equipment.

CONNECTIONS

All connections are made on the rear panel of the unit.


The microphone input connection is made by means of a phone plug. The high level input connection is made by means of a phono plug. A slide switch on the rear of the unit is provided to select the proper input.

The microphone input jack is for an unbalanced line only. If it is necessary to use a balanced input, an outboard matching transformer such as Raymer Model LMT-150 must be used. If the signal source is a telephone line or a 500 ohm input, the connection can be made to the amplifier by means of a Raymer Telephone Matching Adaptor TM-1.

To avoid possible supersonic oscillation which might result in damage to the unit, it is mandatory that a shielded (metal cover) microphone plug be used.

The speaker(s) or line matching transformers are connected to the screw terminal board located on the rear panel. For short distances, any ordinary insulated wire, such as parallel lamp cord, may be used.

Connecting to the 25 volt or 70 volt tap on the unit permits the use of a number of speakers each with its own corresponding line matching transformer, thereby eliminating the necessity of calculating impedances. The tap on the line matching transformer is selected to give the power desired for each speaker. The total of all the power settings should be no greater than the amplifier output rating.



TRUTONE ELECTRONICS, INC.

7315 FULTON AVE., NORTH HOLLYWOOD, CALIFORNIA