



Service Manual

For the complete PDF manual
please visit www.LaserPros.com.

Optra™ SC 1275

5040-001

- ***Table of Contents***
- ***Start Diagnostics***
- ***Safety and Notices***
- ***Trademarks***
- ***Index***
- ***Manuals Menu***



*Lexmark and Lexmark with diamond
design are trademarks of Lexmark
International, Inc., registered in the
United States and/or other countries.*

First Edition (January 1998)

The following paragraph does not apply to any country where such provisions are inconsistent with local law: LEXMARK INTERNATIONAL, INC. PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time. Publications are not stocked at the address given below; requests for publications should be made to your point of purchase.

A form for reader's comments is provided at the back of this publication. If the form has been removed, comments may be addressed to Lexmark International, Inc., Department D22A/035-3, 740 New Circle Road NW, Lexington, Kentucky 40550, U.S.A. Lexmark may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Lexmark and Optra are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

Other trademarks are the property of their respective owners.

© Copyright Lexmark International, Inc. 1997. All rights reserved.

UNITED STATES GOVERNMENT RESTRICTED RIGHTS

This software and documentation are provided with RESTRICTED RIGHTS. Use, duplication or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 and in applicable FAR provisions: Lexmark International, Inc., Lexington, KY 40550.

Contents

Notices and Safety Information	viii
Laser Notice	viii
Laser Advisory Label	ix
Class 1 Laser Statement Label	ix
General Information	1-1
Maintenance Approach	1-1
Tools	1-1
Abbreviations	1-2
Paper Feed Operation	1-2
Drum Cartridge Toner Full Detection	1-6
Synchronizing Rollers	1-7
Paper Type Detection	1-8
Development	1-10
Toner Empty / Toner Cartridge Detection	1-10
AIDC Sensor and Erase Lamp	1-11
Diagnostic Information	2-1
Start	2-1
Initial Check	2-1
Operator Error Message Table	2-2
Status Messages	2-2
Line 1 Status Messages	2-3
Line 2 Messages	2-10
Supplies Status Messages	2-11
Attendance Messages	2-11
Service Error Message Table	2-26
Symptom Table	2-29
Service Checks	2-33
Fuser Service Check	2-33
Developing Motor Service Check	2-34
Transport Motor Service Check	2-34
Image Transfer Belt Service Check	2-35
Paper Jam Service Check	2-35
Toner Cartridge Rack Service Check	2-38
Printhead Cooling Fan Service Check	2-39
Power Supply Cooling Fan Motor Service Check	2-39
Suction Fan Motor Service Check	2-39
AC Power Service Check	2-40
Marks on Paper Service Check	2-41
Image Quality Troubleshooting	2-42

Sensor Service Check	2-47
Diagnostic Aids	2-48
Basic Printer Paper Passage Test	2-48
Operator Menu Disabled	2-48
Diagnostic Mode.	2-48
Diagnostic Menu Group	2-48
Setting Printer Registration	2-50
Print Tests	2-50
Quality Pages.	2-51
Clean Engine Test	2-51
LCD Hardware Test	2-51
Button Test.	2-51
DRAM Memory Test.	2-51
ROM Memory Test.	2-52
Parallel Wrap Test	2-53
Serial Wrap Tests.	2-54
Input Tray Sensor Test.	2-55
Size Sensing Sensor Test	2-55
Base Sensor Test.	2-56
Quick Disk Check.	2-57
DISK Test/Clean.	2-57
Flash Test.	2-58
Setting the Page Count	2-58
Viewing the Permanent Page Count	2-58
Viewing the Error Log.	2-58
Clearing the Error Log	2-59
Exiting Diagnostic Mode.	2-59
Print Quality Test Page	2-60
Print Quality Test Page	2-61
Repair Information	3-1
Precautions for Disassembly and Cleaning	3-1
Instructions for Handling the PWBs with MOS ICs.	3-1
Precautions for Handling the Drum Cartridge	3-2
Parts not to be touched	3-2
Precautions for Handling the Laser Equipment	3-3
Adjustment Procedures	3-3
Registration Adjustment.	3-3
Rack Lever Solenoid Adjustment.	3-5
Removal Procedures	3-5
Outer Cover Removals.	3-5
Image Transfer Roller Removal	3-6
Drum Cartridge Removal	3-6

Waste Toner Bottle Removal	3-7
Image Transfer Belt Removal	3-7
Fuser Removal	3-8
Oil Coating Roller Removal	3-9
Heater Lamp Removal	3-10
Printhead Removal	3-11
Paper Exit Removal	3-12
High Voltage (HV1) / Sub High Voltage Board (PWB-F) Removal	3-12
Shield Plate Removal	3-13
Power Supply Removal	3-13
Mechanical Control Board Removal	3-14
Power Supply Frame Removal	3-14
Printhead Frame Removal	3-15
Toner Empty / Toner Cartridge Detecting Board (PWB-B) Removal	3-16
Toner Cartridge Rack Removal	3-16
Mechanical Controller Board Frame Removal	3-19
Paper Size/Cassette Detecting Board (PWB-E) Removal	3-19
Paper Take-Up Removal	3-19
Suction Assembly Removal	3-25
Suction Fan Motor Removal	3-27
Locations	4-1
Parts of the Printer	4-1
Parts of the Printer	4-2
Printing Process	4-6
Switches and Sensors	4-7
Gears and Rollers	4-10
Electrical Components	4-12
Connectors	4-18
Printed Circuit Boards	4-19
Parts Catalog	5-1
How to Use This Parts Catalog	5-1
Housing	5-2
Frames 1	5-6
Frames 2	5-10
Drive	5-14
Paper Take-Up 1	5-18
Paper Take-Up 2	5-22
Image Transfer Belt	5-24
Image Transfer Belt	5-26
Transfer Roller	5-28

Paper Transport	5-32
Rack	5-34
Fuser 1	5-38
Fuser 2	5-40
Fuser/Exit	5-42
Exit	5-44
Electrical Parts	5-46
Second Cassette (Tray 1)	5-50
Third Cassette (Tray 2)	5-54
Paper Tray	5-56
Controller Card	5-58
Index	X1

For the complete PDF manual
please visit www.LaserPros.com.