




LASERJET PRO CP1520

COLOR PRINTER SERIES

For the complete PDF manual
please visit www.LaserPros.com.

Service Manual





HP LaserJet Pro CP1520 Color Printer series

Service Manual

Copyright and License

© 2010 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number: CE873-90934

Edition 1, 9/2010

Trademark Credits

Microsoft®, Windows®, Windows® XP, and Windows Vista® are U.S. registered trademarks of Microsoft Corporation.

ENERGY STAR and the ENERGY STAR mark are registered U.S. marks.

Conventions used in this guide

 **TIP:** Tips provide helpful hints or shortcuts.

 **NOTE:** Notes provide important information to explain a concept or to complete a task.

 **CAUTION:** Cautions indicate procedures that you should follow to avoid losing data or damaging the product.

 **WARNING!** Warnings alert you to specific procedures that you should follow to avoid personal injury, catastrophic loss of data, or extensive damage to the product.

Table of contents

1 Removal and replacement	1
Introduction	2
Removal and replacement strategy	2
Electrostatic discharge	3
Required tools	3
Service approach	3
Before performing service	3
After performing service	4
Post-service test	4
Print-quality test	4
Parts removal order	4
Removal and replacement procedures	5
Remove the print cartridges	5
Rollers	6
Pickup roller	6
Separation roller	7
Transfer roller	8
Feed assembly	9
External panels, covers, and doors	10
Right cover	10
Left cover	13
Front door and Tray 1 door	15
Control-panel module	19
Rear-side cover	21
Rear-upper cover	22
Rear door and rear-lower cover	23
Top cover	25
Internal assemblies	27
Main motor	27
Fuser motor	29
Intermediate transfer belt (ITB)	30
Reinstall the ITB	35
DC controller PCA	37
Special consideration	37

Remove the DC controller PCA	37
Formatter PCA	40
Special consideration	40
Remove the formatter PCA	40
Wireless PCA	42
Power supply (high-voltage)	43
Power supply (low-voltage)	47
Power supply (fuser)	53
Fuser	56
2 Solve problems	59
Solve problems checklist	60
Menu map	61
Troubleshooting process	62
Pre-troubleshooting checklist	62
Power-on checks	64
Tools for troubleshooting	65
Diagrams	65
Plug/jack locations	65
Locations of major components	66
General timing charts	68
General circuit diagram	69
Use HP ToolboxFX	70
View the HP Color LaserJet CP1520 Series Toolbox	70
HP ToolboxFX sections	71
Status	71
Event log	71
Help	71
System Settings	71
Print Settings	74
Network Settings	74
Shop for Supplies	74
Other Links	75
Internal print-quality test pages	75
Interpret the Print Quality Page	75
Clean the product	76
Configuration page	76
Print-quality troubleshooting tools	77
Repetitive image defects	77
Calibrate the product to align the colors	77
Control panel menus	78
Reports menu	78
Quick Forms menu	79

System Setup menu	79
Service menu	82
Network Setup menu	83
Interpret control panel messages	84
Control panel message types	84
Control panel messages	84
Paper feeds incorrectly or becomes jammed	95
The product does not pick up paper	95
The product picks up multiple sheets of paper	95
Prevent paper jams	95
Clear jams	96
Jam locations	96
Jam in Tray 1	97
Jam in Tray 2	99
Jam in the fuser area	100
Jam in the output bin	101
Solve image quality problems	102
Use the correct paper type setting in the printer driver	102
Change the paper type setting for Windows	102
Change the paper type setting for Mac	102
Adjust color settings in the printer driver	103
Change the color theme for a print job	103
Change the color options	103
Use paper that meets HP specifications	104
Print a cleaning page	105
Calibrate the product to align the colors	105
Check the print cartridges	105
Print the Supplies Status page	106
Inspect the print cartridge for damage	106
Repeating defects	107
Use the printer driver that best meets your printing needs	107
Clean the product	109
The product does not print or it prints slowly	110
The product does not print	110
The product prints slowly	110
Solve connectivity problems	111
Solve direct-connect problems	111
Solve network problems	111
Poor physical connection	111
The computer is using the incorrect IP address for the product	111
The computer is unable to communicate with the product	112
The product is using incorrect link and duplex settings for the network	112
New software programs might be causing compatibility problems	112
The computer or workstation might be set up incorrectly	112

The product is disabled, or other network settings are incorrect	112
Service mode functions	113
Service menu	113
Service menu settings	113
Restore the factory-set defaults	113
Secondary service menu	113
Open the secondary service menu	113
Secondary service menu structure	114
Engine resets	114
Engine test page	114
Cold reset	115
NVRAM initialization	115
Product updates	115
3 Parts and diagrams	117
Order parts by authorized service providers	118
Order replacement parts	118
Related documentation and software	118
Supplies part numbers	118
Whole-unit replacement part numbers	118
How to use the parts lists and diagrams	120
Assembly locations	121
Base product (no optional trays or accessories)	121
Covers, panels, and doors	122
Internal assemblies	124
Alphabetical parts list	134
Numerical parts list	137
Appendix A Service and support	141
Hewlett-Packard limited warranty statement	142
HP's Premium Protection Warranty: LaserJet print cartridge limited warranty statement	143
Data stored on the print cartridge	144
End User License Agreement	145
OpenSSL	147
Customer support	148
Repack the product	149
Appendix B Product specifications	151
Physical specifications	152
Power consumption, electrical specifications, and acoustic emissions	152
Environmental specifications	152

Appendix C Regulatory information	153
FCC regulations	154
Environmental product stewardship program	155
Protecting the environment	155
Ozone production	155
Power consumption	155
Paper use	155
Plastics	155
HP LaserJet print supplies	155
Return and recycling instructions	156
United States and Puerto Rico	156
Multiple returns (more than one cartridge)	156
Single returns	156
Shipping	156
Non-U.S. returns	156
Paper	157
Material restrictions	157
Disposal of waste equipment by users in private households in the European Union ...	157
Chemical substances	157
Material Safety Data Sheet (MSDS)	157
For more information	158
Declaration of conformity	159
Declaration of Conformity (wireless models)	161
Safety statements	163
Laser safety	163
Canadian DOC regulations	163
VCCI statement (Japan)	163
Power cord instructions	163
Power cord statement (Japan)	163
EMC statement (Korea)	163
Laser statement for Finland	164
GS statement (Germany)	164
Substances Table (China)	165
Restriction on Hazardous Substances statement (Turkey)	165
Additional statements for wireless products	166
FCC compliance statement—United States	166
Australia statement	166
Brazil ANATEL statement	166
Canadian statements	166
European Union regulatory notice	166
Notice for use in France	167
Notice for use in Russia	167
Korean statement	167
Taiwan statement	167

For the complete PDF manual
please visit www.LaserPros.com.